

### Price groups

PG 140, 41B, 41E, 41F, 41G, 41H, 41J, 42F, 42J

#### Introduction

#### Motor starter protectors/ circuit breakers

SIRIUS 3RV2 motor starter protectors/ circuit breakers up to 80 A

General data

7/21 For motor protection **NEW** 

For motor protection with overload relay function NEW

For starter combinations **NEW** 

For transformer protection **NEW** 

7/29 For system protection according to UL 489/CSA C22.2 No. 5 NEW

For transformer protection according to UL 489/CSA C22.2 No.5 NEW

Accessories

7/31 - Mountable accessories

7/34 - Busbar accessories

7/37 - Rotary operating mechanisms

7/38 - Mounting accessories

- Enclosures and front plates

7/46 3RV29 infeed system

SIRIUS 3RV1 motor starter protectors/ circuit breakers up to 100 A

7/51 General data

7/63 For motor protection

7/64 For motor protection with overload relay function

For starter combinations

7/66 For fuse monitoring

7/67 For system protection according to

UL 489/CSA C22.2 No. 5

7/68 For distance protection

Accessories

7/69 - Mountable accessories

- Busbar accessories

7/73 - Rotary operating mechanisms

7/75 - Mounting accessories

- Front plates

SIRIUS 3RV1 molded case motor starter

protectors up to 800 A

7/78 General data

7/83 For motor protection

7/84 For starter combinations

Accessories

7/86

- Mountable accessories

- Rotary operating mechanisms, mounting accessories

#### Overload relays 7/87 General data

SIRIUS 3RU2

thermal overload relavs

3RU2 up to 80 A

for standard applications **NEW** 

7/103 Accessories SIRIUS 3RU1

thermal overload relays

7/106 3RU11 up to 100 A for standard applications

7/112 Accessories

> SIRIUS 3RB3 electronic overload relays

3RB30, 3RB31 up to 80 A 7/114 for standard applications **NEW** 

7/122 Accessories

> SIRIUS 3RB2 electronic overload relays

7/124 3RB20, 3RB21 up to 630 A for standard applications

7/133 Accessories for 3RB20, 3RB21 7/135 3RB22, 3RB23 up to 630 A

for High-Feature applications

7/143 3RB24 for IO-Link, up to 630 A for High-Feature applications

7/150 Current measuring modules for 3RB22, 3RB23, 3RB24

7/153 Accessories for 3RB22, 3RB23, 3RB24

#### Notes:

The 3RV1, 3RU1 and 3RB2 devices (sizes S00/S0 to S12) can be found

- in the Catalog Add-On IC 10 AO · 2015 at the Information and Download Center
- in the interactive catalog CA 01
- in the Industry Mall

Conversion tool, e.g. from

- 3RV1 to 3RV2
- 3RU11 to 3RU21
- 3RB20/3RB21 to 3RB30/3RB31

www.siemens.com/sirius/conversion-tool

Click on the Article No. in the catalog PDF to access it in the Industry Mall and get all related information.

#### Article-No



Or directly in the Internet, e. g. www.siemens.com/ product?3RA1943-2C

### **Protection Equipment**

### Motor Starter Protectors/Circuit Breakers

### Introduction

### Overview



Size Spot			( 6	(6)		1,0			1.5	(6)		(,0	10		M			
Applications	Туре		3RV2	20		3RV2	21		3RV2	23		3RV2	24		3RV2	27	3RV2	28
System protection	SIRIUS 3RV2 motor starte	r pro	tecto	rs/c	ircuit brea	kers	up t	o 80 A										
** Motor protection	Applications																	
Motor protection with overload release   Section   Se	System protection		<b>√</b> 1)			<b>✓</b> 1)									/		/	
Starter combinations	Motor protection		1															
Size		i				1												
Size   Son   Son	Starter combinations								1									
Size SOO	Transformer protection											/			1		/	
<ul> <li>Size S00</li> <li>A Up to 16 or Size S0</li> <li>A Up to 16 or Size S0</li> <li>A Up to 16 or Size S0</li> <li>A Up to 40 or Size S0</li> <li>A Up to 80 or Up to 80 or Size S0</li> <li>Boy AC2</li> <li>Boy AC3</li> <li>Boy AC3</li></ul>	Size		S00,	S0, S	32	S00,	S0, S	32	S00,	S0, S	S2	S00,	S0, 5	32	S00,	S0	S00,	S0
• Size S0	Rated current I <sub>n</sub>																	
Rated frequency	<ul><li>Size S00</li><li>Size S0</li><li>Size S2</li></ul>	Α	Up to	40		Up to	32		Up to	o 40		Up to	25 0		Up to		Up to	
CLASS 10 (S00 S2)   CLASS 10   CLASS 1	Rated operational voltage $U_{\rm e}$ according to IEC	V	690 A	4C <sup>2)</sup>		690 /	4C <sup>2)</sup>		690 /	AC <sup>2)</sup>		690 /	4C <sup>2)</sup>		690 A	/C	690 A	AC .
CLASS 20 (S2)	Rated frequency	Hz	50/60	)		50/60	)		50/60	0		50/60	)		50/60	)	50/60	)
A   70 80 80   70 80   70 80   70 80   70 80   70 80   70 80   70 80   70 80   70 80   70 80 80   70 80   70 80   70 80   70 80   70 80   70 80   70 80   70 80   70 80   70 80 80   70	Trip class					CLAS	SS 10	)				CLAS	SS 10	)				
A multiple of the rated current  13 times  13 times  13 times  13 times  20 times  4)  4)  4)  40 vacapacity I at 400 v Ac  Pages  7/21 7/23  7/25  7/26, 7/27  7/28  7/28  7/29  7/30   Accessories  For sizes  Soo So	Thermal overload releases				16 up to			16 up to	None	e <sup>3)</sup>				16 up to				
Comparison of the property o	Electronic release A multiple of the rated current		13 tir	nes		13 tir	nes		13 tir	nes		20 tir	nes			nes		nes
Accessories   Son	Short-circuit breaking capacity I <sub>cu</sub> at 400 V AC	kA	20/55	5/65/	100	55/65	5/100	)	20/55	5/65/	100	55/65	5/100	)	4)		4)	
For sizes   S00   S0   S2   S00   S0   S2   S00   S0   S	Pages		7/21	7/2	23	7/25			7/26,	, 7/27	7	7/28			7/29		7/30	
Auxiliary switches	Accessories																	
Signaling switches	For sizes		S00	S0	S2	S00	SO	S2	S00	SO	S2	S00	S0	S2	S00	S0	S00	S0
Signaling switches  V V V V V V V V V V V V V V V V V V V	Auxiliary switches		1	/		/	/	/	1		/		/	/				/
Undervoltage releases  V V V V V V V V V V V V V V V V V V V	•		/	/	/	/	/	/		/	/	/	/	/				
Shunt releases	Undervoltage releases		1	/	/				1	/	/	/	1	/	1	1	1	✓
Insulated three-phase busbar system  Busbar adapters  V V V V V V V V V V V V V V V V V V V	Shunt releases		/	/	/				1	/	/	/	/	/	/	/	1	/
Busbar adapters	Isolator modules		1	/	1	1	1	1	1	1	1	/	1	1				
Door-coupling rotary	Insulated three-phase busbar system		1	1	1				1	1	1	1	1	/				
Comparating mechanisms	Busbar adapters		1	/	1	1	1	✓	1	/	/	1	1	1				
Enclosures for surface mounting	Door-coupling rotary operating mechanisms		1	✓	1	1	1	✓	1	1	1	1	1	1	1	✓	1	✓
Enclosures for flush mounting	Link modules		/	1	✓	1	1	1	/	1	/	/	1	1				
Front plates	Enclosures for surface mounting		/	/	/	/	1	/	/	/	/	/	1	1				
Infeed system	Enclosures for flush mounting		/	1		1	1		/	1		/	1					
Terminal covers for ring terminal $\checkmark^5$ $\checkmark^5$	Front plates		1	/	✓	/	/	/	/	1	/	/	1	/				
lug connections  Sealable scale covers for setting  V  V  V	Infeed system		/						1	1		/	1					
knobs	Terminal covers for ring terminal lug connections	I	<b>√</b> <sup>5)</sup>	<b>√</b> <sup>5)</sup>														
Pages 7/31 7/50	Sealable scale covers for setting knobs	)	1	1	1	1	1	✓				1	1	1				
	Pages		7/31	7/	50													

 $<sup>\</sup>ensuremath{\checkmark}$  Has this function or can use this accessory

<sup>--</sup> Does not have this function or cannot use this accessory

<sup>1)</sup> For symmetrical loading of the three phases.

With molded-plastic enclosure 500 V AC. For DC applications, see "Technical Specifications" — "DC Short-Circuit Breaking Capacity", page 7/16.

<sup>3)</sup> For overload protection of the motors, appropriate overload relays must be used.

 $<sup>^{\</sup>rm 4)}$  According to UL 489 at 480 Y/277 V AC: 65 kA or 50 kA.

<sup>5)</sup> Terminal covers are available for 3RV20 motor starter protectors with ring terminal lug connection to ensure finger-safety.

# **Protection Equipment**Motor Starter Protectors/Circuit Breakers

Introduction













		The second second	THE REAL PROPERTY.	The state of the s	The state of the s	2020	
Туре		3RV10	3RV11	3RV13	3RV16	3RV16	3RV17
SIRIUS 3RV1 motor sta	arte	r protectors/circ	cuit breakers up	to 100 A			
Applications							
System protection		<b>✓</b> <sup>1)</sup>	<b>√</b> 1)				1
<ul> <li>Motor protection</li> </ul>		/					
<ul> <li>Motor protection with overload relay function</li> </ul>			1				
Starter combinations				1			
Transformer protection							/
Fuse monitoring					✓		
<ul> <li>Voltage transformer circuit breakers for distance protection</li> </ul>						1	
Size		S3	S3	S3	S00	S00	S3
Rated current I <sub>n</sub>							
• Size S00	Α				0.2	Up to 3	
• Size S3		Up to 100	Up to 100	Up to 100			Up to 70
Rated operational voltage $U_{\rm e}$ according to IEC	V	690 AC <sup>2)</sup>	690 AC <sup>2)</sup>	690 AC <sup>2)</sup>	690 AC <sup>2)</sup>	400 AC	690 AC
Rated frequency	Hz	50/60	50/60	50/60	50/60	16 <sup>2</sup> / <sub>3</sub> 60	50/60
Trip class		CLASS 10, 20	CLASS 10				
Thermal overload releases	A A	11 16 up to 80 100	11 16 up to 80 100	Without <sup>3)</sup>	0.2	1.4 3	10 70 non-adjustable
Electronic release A multiple of the rated current		13 times	13 times	13 times	6 times	4 7 times	13 times
Short-circuit breaking capacity I <sub>cu</sub> at 400 V AC	kA	50/100	50/100	50/100	100	50	4)
Pages		7/63	7/64	7/65	7/66	7/68	7/67
Accessories							
or sizes		S3	S3	S3	S00	S00	S3
Auxiliary switches		/	1	1	1	✓	<b>√</b> <sup>5)</sup>
Signaling switches		1	1	1			
Jndervoltage releases		1		1			/
Shunt releases		1		1			<b>✓</b>
Busbar adapters		1	✓	1			
Door-coupling rotary operating mechanisms		1	1	✓			✓
Remote motorized operating mechanisms		✓	1	✓			
Link modules		1	1	1			
Front plates		✓	✓	1			
D		7/00 7/77					

✓ Has this function or can use this accessory

Pages

-- Does not have this function or cannot use this accessory

7/69 ... 7/77

- <sup>4)</sup> Acc. to UL 489
  - At 480 Y/277 V AC: 65 kA
  - At 480 V AC: 65 kA (10 A to 30 A)

7/3

<sup>1)</sup> For symmetrical loading of the three phases.

<sup>2)</sup> With molded-plastic enclosure 500 V AC. For DC applications, see "Technical Specifications" → "DC Short-Circuit Breaking Capacity", page 7/58.

<sup>3)</sup> For overload protection of the motors, appropriate overload relays must be used.

<sup>5)</sup> Only lateral auxiliary switches can be fitted.

## **Protection Equipment**

### Motor Starter Protectors/Circuit Breakers

### Introduction





Туре		3RV10			3RV13					
SIRIUS 3RV1 molded ca	ase	motor star	ter protecto	rs up to 800	) A					
Applications										
<ul> <li>Motor protection</li> </ul>		✓								
<ul> <li>Starter combinations</li> </ul>					✓					
Switching capacity		Standard sw	itching capaci	ty	Standard swit	tching capacit	у		Increased sy capacity	vitching
Size		3RV1063	3RV1073	3RV1083	3RV1353	3RV1363	3RV1373	3RV1383	3RV1364	3RV1374
Rated current I <sub>n</sub>	Α	100 200	400	630	1 32	100 250	400, 630	630, 800	100 250	400
Rated operational voltage $U_{\rm e}$ according to IEC	٧	690 AC			690 AC					
Rated frequency	Hz	50/60			50/60					
Trip class		CLASS 10A,	10, 20, 30		1)					
Thermal overload releases	A A	40 100 up 252 630	to		Without <sup>1)</sup>					
Electronic release A multiple of the rated current		Adjustable, 6	5 13 times		Non-adjustable 1 12.5 A: 13 times; Adjustable 20 A, 32 A: 6 12 times	1 10 times	3			
Short-circuit breaking capacity I <sub>cu</sub> at 400 V AC	kA	120	120	100	85	120	120	100	200	200
Trip unit (release)		TU 4			TU 1: 1 12.5 A; TU 2: 20 A, 32 A	TU 3				
Pages		7/83			7/84					
Accessories										
For molded case motor starter protectors	ī	3RV1063	3RV1073	3RV1083	3RV1353	3RV1363	3RV1373	3RV1383	3RV1364	3RV1374
Auxiliary switches		1	1	1	1	1	1	1	1	1
Undervoltage releases		1	/	1	1	1	1	1	1	1
Shunt releases		/	1	1	1	1	1	1	1	1
Rotary operating mechanisms		1	✓	✓	1	✓	1	✓	✓	1
Connection methods • Extended terminals on the front • Cable terminals on the front		✓ ✓	✓ ✓	 •	✓ ✓	✓ ✓	✓ ✓	 •	✓ ✓	✓ ✓

<sup>✓</sup> Has this function or can use this accessory

7/85, 7/86

Rear terminals

Pages

<sup>--</sup> Does not have this function or cannot use this accessory

<sup>1)</sup> For overload protection of the motors, appropriate overload relays must be used.

### **Protection Equipment** Overload Relays

Introduction







			199	~									
Type		3RU2	1		3RB3	0		3RB	31				
SIRIUS overload relays up to 8	0 A												
Applications													
System protection		<b>√</b> 1)			<b>✓</b> 1)			<b>✓</b> <sup>1)</sup>					
Motor protection		✓			✓			✓					
Alternating current, three-phase		✓			✓			✓					
Alternating current, single-phase		✓											
Direct current		✓											
Size contactor		S00, S	80, S2		S00, S	80, S2		S00,	S0, S2				
Rated operational current I <sub>e</sub>													
• Size S00	Α	Up to	16		Up to	16		Up to	16				
• Size S0	Α	Up to	Up to 40			40		Up to	Up to 40				
• Size S2	Α	Up to	Up to 80			80		Up to	Up to 80				
Rated operational voltage $U_{\rm e}$	V	690 A	690 AC			.C		690	690 AC				
Rated frequency	Hz	50/60	50/60					50/60	50/60				
Trip class		CLAS	S 10, 10	)A	CLAS	S 10E, 2	20E	CLA: (adju	CLASS 5E, 10E, 20E, 30E (adjustable)				
Thermal overload releases	A A	0.11 . 70	0.16 u 80	p to									
Electronic overload releases	A A				0.1 20	0.4 up <sup>1</sup> 80	to	0.1 20	0.4 up 1 . 80	0			
Pages		7/100	7/102	2	7/119	, 7/120		7/12	1				
Accessories													
For sizes		S00	S0	S2	S00	S0	S2	S00	S0	S2			
Terminal supports for stand-alone installation		1	✓	✓	1	1	1	✓	1	✓			
Mechanical RESET		/	/	✓	/	1	✓	1	1	✓			
Cable releases for RESET		✓	✓	1	✓	✓	✓	1	1	✓			
Electrical remote RESET		/	✓	/				Integ	grated in	the unit			
Terminal covers													
Ring terminal lug connections		<b>√</b> 2)	<b>√</b> <sup>2)</sup>										
For box terminals				✓			✓			1			
Sealable covers for setting knobs		✓	✓	✓	/	✓	✓	1	1	✓			

7/122, 7/123

✓ Has this function or can use this accessory

**Pages** 

-- Does not have this function or cannot use this accessory

7/103 ... 7/105

The units are responsible in the main circuit for overload protection of the assigned electrical loads (e.g. motors), feeder cable, and other switching and protection devices in the respective load feeder.

7/122, 7/123

2) Terminal covers for ensuring finger-safe touch protection are available for 3RU21 overload relays with ring terminal lug connections for mounting onto contactors.

7/5

### Protection Equipment Overload Relays

### Introduction











										-	7			-
Туре		3RU11	3RE	320		3R	B21		3RB	22, 3F	B23		3R	B24
SIRIUS overload relays up to 63	0 A													
Applications														
System protection		<b>✓</b> <sup>1)</sup>	<b>✓</b> 1)			<b>✓</b> 1	)		<b>√</b> 1)					
Motor protection		✓	/			1			/					
Alternating current, three-phase		✓	/			1			/					
Alternating current, single-phase		✓							/					
Direct current		✓												
Size contactor		S3	S3 .	S1	2	S3	S	12	S00 .	S12				
Rated operational current I <sub>e</sub>														
• Sizes S00 and S0	Α								with	currer	it mea	mm w suring 3RB29	mod	
Size S2	Α											5 mm		
Size S3	Α	Up to 100	Up	to 10	00	Up	to 10	00		currer 2906-2		suring	, mod	ule
• Size S6	Α		Up	to 20	00	Up	to 20	00	with	currer	it mea	20 mm suring 3RB29	, mod	ules
• Size S10/S12	Α		Up	to 63	30	Up	to 6	30	with		it mea	45 mm suring		
• Size 14 (3TF68/3TF69)	Α		Up	to 63	30	Up	to 6	30	with 3RB2	2906-2	BG1	suring and 1868-3	,	
Rated operational voltage <i>U</i> <sub>e</sub>	V	690/1 000 AC	690	/1 00	00 AC	690	0/1 0	00 AC	690/	1 000	AC <sup>2)</sup>			
Rated frequency	Hz	50/60	50/6	60		50/	60		50/60	)				
Trip class		CLASS 10	CLA	ASS	10, 20		ASS justa	5, 10, 20, 30 ble		SS 5, stable		, 30		
Thermal overload releases	A A	18 25 up to 80 100												
Electronic overload releases	A A			5 5 1 6	50 up to 30		5 6 0 6	50 up to 630	0.3 63	. 3 up 630	to			
Pages		7/111	7/13	30, 7	/131	7/1	32		7/14	1, 7/14	12, 7/1	52	7/1	49, 7/152
Accessories														
For sizes		S3	S3	S6	S10/S12	S3	S6	S10/S12	S00	S0	S2	S3	S6	S10/S12
Terminal supports for stand-alone nstallation		✓	3)	3)	3)	3)	3)	3)	3)	3)	3)	3)	3)	3)
Mechanical RESET		/	/	1	/	/	/	/						
Cable releases for RESET		✓	/	1	/	1	1	/						
Electrical remote RESET		/				Inte	egrat	ed in the unit	Inte	grated	in the	e unit		
Terminal covers		✓	/	1	1	1	1	<b>✓</b>				1	1	/
Sealable covers for setting knobs		Integrated in the unit	/	/	/	/	/	/	/	/	/	/	/	/
Operator panel for 3RB24 evaluation module									1	1	✓	1	1	1
Pages		7/112, 7/113	7/13	33, 7	/134	7/1	33, 7	7/134	7/15	2 7	/154			

- ✓ Has this function or can use this accessory
- -- Does not have this function or cannot use this accessory
- 1) The units are responsible in the main circuit for overload protection of the assigned electrical loads (e.g. motors), feeder cable, and other switching and protection devices in the respective load feeder.
- $^{2)}\,$  With reference to the 3RB29.6 current measuring modules.
- $^{\rm 3)}$  Stand-alone installation without accessories is possible.


### SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A

General data

### Overview

The following illustration shows our 3RV2 motor starter protector/circuit breaker with the accessories which can be mounted for the sizes S00 to S2, see also "Introduction" → "Overview", page 7/2.

Accessories, see page 7/31 onwards.



Mountable accessories for SIRIUS 3RV2 motor starter protectors/circuit breakers



SIRIUS motor starter protector with spring-type terminals, size S0 (left) and SIRIUS motor starter protector with screw terminals, size S00 (right)

The new SIRIUS 3RV2 motor starter protectors/circuit breakers are compact, current limiting motor starter protectors/circuit breakers which are optimized for load feeders. The motor starter protectors/circuit breakers are used for switching and protecting three-phase motors of up to 37 kW at 400 V AC and for other loads with rated currents of up to 80 A.

For 3RV1 motor starter protectors/circuit breakers in size S3 up to 100 A, see page 7/63 onwards.

The new 3RV2 motor starter protectors/circuit breakers are usually approved according to IEC and UL/CSA. According to UL 508/UL 60947-4-1, the 3RV2 motor starter protectors in sizes S00 to S2 are approved as:

- "Manual Motor Controllers"
- "Manual Motor Controllers" for "Group Installations"
- "Manual Motor Controllers Suitable for Tab Conductor Protection in Group Installations"
- "Self-Protected Combination Motor Controllers (Type E)"
   Please note that for this approval the 3RV20 motor starter
   protectors must be equipped with additional infeed terminals
   or phase barriers. More information, see "Accessories" on
   page 7/38.

Corresponding short-circuit values, see pages 7/10 to 7/15.

The 3RV27 and 3RV28 circuit breakers are approved as circuit breakers according to UL 489; they are a special version of the 3RV2 motor starter protectors.

### SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A

#### **General data**

#### Type of construction

The 3RV2 motor starter protectors are available in three sizes:

- Size S00 width 45 mm, max. rated current 16 A, at 400 V AC suitable for three-phase motors up to 7.5 kW
- Size S0 width 45 mm, max. rated current 40 A, at 400 V AC suitable for three-phase motors up to 18.5 kW
- Size S2 width 55 mm, max. rated current 80 A, at 400 V AC suitable for three-phase motors up to 37 kW

Size S3 of the 3RV1 motor starter protectors up to 100 A, see page 7/63 onwards.

#### Circuit breakers acc. to UL 489

The 3RV27 and 3RV28 circuit breakers are available in two sizes:

- Size S00 width 45 mm, max. rated current 15 A, for 480 Y/277 V AC
- For size S0 width 45 mm, max. rated current 22 A, at 480 Y/277 V AC

For size S3 of the 3RV1742 circuit breakers up to 70 A, see page 7/67.

#### Connection methods

backgrounds.

The 3RV2 motor starter protectors/circuit breakers can be supplied with screw terminals, spring-type terminals and ring cable lug connections.

	9
<b>(1)</b>	Screw terminals
$\stackrel{\circ}{\square}$	Spring-type terminals
	Ring terminal lug connections
	The terminals are indicated in the corresponding tables by the symbols shown on orange

## "Increased safety" type of protection EEx e according to ATEX directive 94/9/EC

3RV20 motor starter protectors are suitable for overload protection of explosion-proof motors with "increased safety" type of protection EEx e.

EC type test certificate for Category (2)  $\mbox{G/D}$  has been submitted. More details on request.

Comprehensive technical information, see manuals/operating instructions, http://support.automation.siemens.com/WW/view/en/20357458/133300.

#### Article No. scheme

Digit of the Article No.	1st - 3rd	4th	5th	6th	7th		8th	9th	10th	11th	12th		13th	14th	15th	16th
						-						-				
Motor starter protectors/ circuit breakers	3 R V															
SIRIUS 2nd generation		2														
Type of motor starter protector/ circuit breaker																
Size																
Breaking capacity																
Setting range for overload release																
Trip class (CLASS)																
Connection methods																
With or without auxiliary switch																
Special versions																
Example	3 R V	2	0	1	1	-	1	Α	Α	1	0					

#### Note:

The Article No. scheme is presented here merely for information purposes and for better understanding of the logic behind the article numbers.


For your orders, please use the article numbers quoted in the catalog in the Selection and ordering data.

### SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A

General data

#### Benefits

### Advantages through energy efficiency



Overview of the energy management process

We offer you a unique portfolio for industrial energy management, using an energy management system that helps to optimally define your energy needs. We split up our industrial energy management into three phases – identify, evaluate and realize – and we support you with the appropriate hardware and software solutions in every process phase.

The innovative products of the SIRIUS industrial controls portfolio can also make a substantial contribution to a plant's energy efficiency (see www.siemens.com/sirius/energysaving).

3RV2 motor starter protectors/circuit breaker contribute to energy efficiency throughout the plant as follows:

- Minimization of energy losses through optimization of the bimetal trip units
- Reduction of inherent power loss
- · Less heating of the control cabinet
- · Smaller control cabinet air conditioners can be used

#### Application

#### Operating conditions

3RV2 motor starter protectors/circuit breakers are suitable for use in any climate. They are intended for use in enclosed rooms in which no severe operating conditions (such as dust, caustic vapors, hazardous gases) prevail. When installed in dusty and damp areas, suitable enclosures must be provided.

3RV2 motor starter protectors/circuit breakers can optionally be fed from the top or from below.

The permissible ambient temperatures, the maximum switching capacities, the tripping currents and other boundary conditions can be found in the technical specifications and tripping characteristics, see the manual

"SIRIUS Innovations – SIRIUS 3RV2 Motor Starter Protectors", http://support.automation.siemens.com/WW/view/en/60279172.

3RV2 motor starter protectors/circuit breakers are suitable for operation in IT systems (IT networks). In this case, the different short-circuit breaking capacity in the IT system must be taken into account, see page 7/11.

Since operational currents, starting currents and current peaks are different even for motors with identical power ratings due to the inrush current, the motor ratings in the selection tables are only guide values. The specific rated and startup data of the motor to be protected is always paramount to the choice of the most suitable motor starter protector/circuit breaker. This also applies to motor starter protectors for transformer protection.

#### Note:

For the use of 3RV2 motor starter protectors in conjunction with highly energy-efficient IE3 motors, please observe the information on dimensioning and configuring, see

"Configuration Manual for SIRIUS Controls with IE3 Motors", http://support.automation.siemens.com/WW/view/en/94770820.

More information, see 1/3.

#### Possible uses

The 3RV2 motor starter protectors can be used:

- For short-circuit protection
- For motor protection (also with overload relay function)
- For system protection
- For short-circuit protection for starter combinations
- For transformer protection
- As main and EMERGENCY-STOP switches
- For operation in IT systems (IT networks)
- For switching of DC currents
- In areas subject to explosion hazard (ATEX)
- Approved as circuit breakers according to UL 489 (3RV27 and 3RV28)

#### For more information, see

- System manual "SIRIUS Innovations System Overview", http://support.automation.siemens.com/WW/view/en/60311318
- Manual "SIRIUS Innovations SIRIUS 3RV2 Motor Starter Protectors"

http://support.automation.siemens.com/WW/view/en/60279172

### SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A

#### **General data**

### Technical specifications

### Short-circuit breaking capacity $I_{cu}$ , $I_{cs}$ according to IEC 60947-2

This table shows the rated ultimate short-circuit breaking capacity  $I_{\rm Cu}$  and the rated service short-circuit breaking capacity  $I_{\rm CS}$  of the 3RV2 motor starter protectors/circuit breakers with different operating voltages dependent on the rated current  $I_{\rm n}$  of the motor starter protectors/circuit breakers.

Power can be supplied to the motor starter protectors/circuit breakers via the terminals at the top or at the bottom without restricting the rated data. If the short-circuit current at the place of installation exceeds the rated short-circuit breaking capacity of the motor starter protector/circuit breaker as specified in the table, a back-up fuse is required. It is also possible to install an upstream motor starter protector/circuit breaker with a limiter function.

The maximum rated current of this back-up fuse is indicated in the tables. The rated ultimate short-circuit breaking capacity then applies as specified on the fuse.

#### Fuseless design

Motor starter protector/contactor assemblies for short-circuit currents up to 150 kA can be ordered as fuseless load feeders, see Chapter 8 "Load Feeders and Motor Starters for Use in the Control Cabinet".

Motor starter protectors/	Rated current I <sub>n</sub>	Up to	240 \	/ AC <sup>1)</sup>		400 \ / AC <sup>2)</sup>	/ AC <sup>1)</sup> /	Up to 460 \	440 \ / AC <sup>2)</sup>	/ AC <sup>1)</sup> /	Up to 525 V		/ AC <sup>1)</sup> /	Up to	690 \	/ AC <sup>1)</sup>
circuit breakers		$I_{ m CU}$	$I_{ t CS}$	Max. fuse (gG)	$I_{ extsf{CU}}$	$I_{ t CS}$	Max. fuse (gG) <sup>3)</sup>	$I_{ m CU}$	$I_{ t CS}$	Max. fuse (gG) <sup>3)</sup>	$I_{ m CU}$	$I_{ t CS}$	Max. fuse (gG) <sup>3)</sup>	$I_{ t CU}$	$I_{ t CS}$	Max. fuse (gG) <sup>3)4)</sup>
Туре	Α	kA	kA	А	kA	kA	А	kA	kA	Α	kA	kA	Α	kA	kA	Α
Size S00																
3RV2.11	0.16 1.6 2; 2.5 3.2	100 100 100	100 100 100	0 0	100 100 100	100 100 100	o o	100 100 100	100 100 100	0	100 100 100	100 100 100	0	100 10 10	100 10 10	。 25 32
	4; 5 6.3 8	100 100 100	100 100 100	0	100 100 100	100 100 100	0	100 100 50	100 100 50	。 63	100 100 42	100 100 42	。 63	6 6 6	4 4 4	32 50 50
	10 12.5 16	100 100 100	100 100 100	0	100 100 55	100 100 30	。 100	50 50 50	50 50 10	80 80 80	42 42 10	42 42 5	63 80 80	6 6 4	4 4 4	50 63 63
Size S0																
3RV2.21	0.16 1.6 2; 2.5 3.2	100 100 100	100 100 100	0 0	100 100 100	100 100 100	0	100 100 100	100 100 100	0	100 100 100	100 100 100	0	100 10 10	100 10 10	° 25 32
	4; 5 6.3 8	100 100 100	100 100 100	0	100 100 100	100 100 100	0	100 100 50	100 100 50	。 63	100 100 42	100 100 42	。 63	6 6 6	4 4 4	32 50 50
	10 12.5 16	100 100 100	100 100 100	0 0	100 100 55	100 100 25	。 100	50 50 50	50 50 10	80 80 80	42 42 10	42 42 5	63 80 80	6 6 4	4 4 2	50 63 63
	20 22; 25 28; 32 36; 40	100 100 100 100	100 100 100 100	o o o	55 55 55 20	25 25 25 10	125 125 125 125	50 50 30 12	10 10 10 8	80 100 125 125	10 10 10 6	5 5 5 3	80 80 100 100	4 4 4 3	2 2 2 2	63 100 100
Size S2																
3RV2.31	14; 17 20 25	100 100 100	100 100 100	0 0	65 65 65	30 30 30	100 100 100	50 50 50	25 25 15	100 100 100	12 12 12	6 6 6	63 80 80	5 5 5	3 3 3	63 80 80
	32; 36 40; 45 52	100 100 100	100 100 100	0 0	65 65 65	30 30 30	125 160 160	50 50 50	15 15 15	125 125 125	10 10 10	5 5 5	100 100 125	4 4 4	2 2 2	100 100 125
	59 80	Value	s on re	equest												
Size S2, with in switching capa																
3RV2.32	14; 17 20; 25 32 45 52 59 80	100 100 100 100	100 100 100 100	。 。 equest	100 100 100 100	50 50 50 50	0 0 0	65 65 65 65	30 30 30 30	100 100 125 125	18 18 15 15	10 10 8 8	63 80 100 125	8 8 6 6	5 5 4 4	63 80 100 125

<sup>°</sup> No back-up fuse required, since short-circuit resistant up to 100 kA

<sup>1) 10 %</sup> overvoltage.

<sup>&</sup>lt;sup>2)</sup> 5 % overvoltage.

 $<sup>^{\</sup>rm 3)}$  Back-up fuse only required if short-circuit current at the place of installation >  $I_{\rm cu}.$ 

<sup>4)</sup> Alternatively, fuseless limiter combinations for 690 V AC can also be used.

### SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A

General data

### Short-circuit breaking capacity $I_{\text{culT}}$ in the IT system (IT network) according to IEC 60947-2

3RV2 motor starter protectors/circuit breakers are suitable for use in IT systems. The values of  $I_{\rm CU}$  and  $I_{\rm CS}$  apply for the three-pole short circuit. In case of a double ground fault in different phases at the input and output side of a motor starter protector, the special short-circuit breaking capacity  $I_{\rm CUIT}$  applies. The specifications in the table below apply to 3RV2 motor starter protectors/circuit breakers.

If the short-circuit current at the place of installation exceeds the motor starter protector/circuit breaker's specified rated short-circuit breaking capacity, you will need to use a back-up fuse. The maximum rated current of this back-up fuse is indicated in the tables. The rated short-circuit breaking capacity then applies as specified on the fuse.

Motor starter	Rated	Up to 240 V	<b>AC</b> <sup>1)</sup>	Up to 400 V A	AC <sup>1)</sup> /415 V AC <sup>2)</sup>	Up to 500 V A	C1)/525 V AC2)	Up to 690 V	AC <sup>1)5)</sup>
protectors	current I <sub>n</sub>	$I_{CUIT}$	Max. fuse (gG) <sup>3)</sup>	$I_{CulT}$	Max. fuse (gG) <sup>3)4)</sup>	$I_{culT}$	Max. fuse (gG) <sup>3)</sup>	$I_{culT}$	Max. fuse (gG) <sup>3)</sup>
Туре	Α	kA	А	kA	А	kA	А	kA	Α
Size S00									
3RV2.11	0.16 0.4 0.5 0.63; 0.8	100 100 100	0	100 100 100	0	100 100 100	o o o	100 0.5 0.5	° 4 6
	1 1.25 1.6	100 100 100	0 0	100 100 100	0	8 8 8	10 16 20	2 2 2	10 16 16
	2; 2.5 3.2 4; 5	100 100 100	0 0	8 8 4	25 32 32	8 8 2	25 32 32	2 2 2	20 25 25
	6.3; 8 10 12.5 16	100 100 100 55	。 。 80	4 4 4 4	50 50 63 63	2 2 2 2	40 40 50 50	1.5 1.5 1.5 1.5	35 40 40 40
Size S0						_			
3RV2.21	0.16 0.4 0.5 0.63; 0.8	100 100 100	0 0	100 100 100	o o	100 100 100	o o	100 0.5 0.5	° 4
	1 1.25 1.6	100 100 100	o o	100 100 100	o o	8 8 8	10 16 20	2 2 2	10 16 16
	2; 2.5 3.2 4; 5	100 100 100	0	8 8 4	25 32 32	8 8 2	25 32 32	2 2 2	20 25 25
	6.3; 8 10 12.5	100 100 100	0	4 4 4	50 50 63	2 2 2	40 40 50	1.5 1.5 1.5	35 40 40
	16 20 25 28; 32 36; 40	55 55 55 20	80 80 80 80	4 4 2 2	63 63 63	2 2 2 2	50 50 63 63	1.5 1.5 1.5 1.5	40 50 63 63
Size S2									
3RV2.31	14 25 32 45 52	100 100 100	0	8 6 4	100 125 160	6 4 3	80 100 125	4 3 2	63 80 100
	59 80	Values on red	quest						
Size S2, with in switching capa									
3RV2.32	14 25 32 45 52	100 100 100	o o	8 6 6	100 125 160	6 6 6	80 100 125	4 4 4	63 80 100
	59 80	Values on red	quest						

<sup>°</sup> No back-up fuse required, since short-circuit resistant up to 100 kA

<sup>1) 10 %</sup> overvoltage.

<sup>2) 5 %</sup> overvoltage.

 $<sup>^{\</sup>rm 3)}$  Back-up fuse only required if short-circuit current at the place of installation >  $I_{\rm culT}$ 

<sup>&</sup>lt;sup>4)</sup> Alternatively, fuseless limiter combinations for 690 V AC can also be used.

<sup>5)</sup> Overvoltage category II applies for applications in IT systems > 600 V.

### SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A

#### **General data**

### Limiter function with standard devices for 500 V AC and 690 V AC according to IEC 60947-2

The table shows the rated ultimate short-circuit breaking capacity  $I_{\rm CU}$  and the rated service short-circuit breaking capacity  $I_{\rm CS}$  with an upstream standard motor starter protector/circuit breaker that fulfills the limiter function at voltages 500 V AC and 690 V AC.

The short-circuit breaking capacity can be increased significantly with an upstream standard motor starter protector/ circuit breaker with limiter function. The motor starter protector/ circuit breaker which is connected downstream must be set to the rated current of the load. With motor starter protector/circuit breaker assemblies, note the clearance to grounded parts and between the motor starter protectors/circuit breaker. Short-circuit proof wiring between the motor starter protectors/circuit breaker must be ensured. The motor starter protectors/circuit breakers can be mounted side by side in a modular arrangement.

Standard motor starter p	rotectors/circuit breakers	Rated current I <sub>n</sub>	Up to 500 V AC1)/52	25 V AC <sup>2)</sup>	Up to 690 V AC <sup>1)</sup>	
	With limiter rated current $I_n$		$I_{ m CU}$	$I_{ t CS}$	$I_{CU}$	$I_{ extsf{CS}}$
Type	Туре	A	kA	kA	kA	kA
Size S00						
3RV2011	<b>Size S0:</b> $I_{\cap} = 32 \text{ A}$	2 6.3 8 10 16	 100 100	 50 50	50 20 20 <sup>3)</sup>	25 10 10 <sup>3)</sup>
	Size S2: 3RV1331-4HC10	10 16			50	25
	$I_{\rm n}$ = 50 A					
Size S0						
3RV2021	<b>Size S0:</b> $I_{n} = 32 \text{ A}$	16 32	100	50	20 <sup>3)</sup>	10 <sup>3)</sup>
	Size S2: 3RV1331-4HC10	16 32			50	20
	$I_{\cap} = 50 \text{ A}$					
Size S2			_	•		
3RV2031		14 80	Values on request			
Size S2, with increase	ed switching capacity					
3RV2032		14 80	Values on request			

<sup>--</sup> No limiter required

<sup>1) 10 %</sup> overvoltage.

<sup>&</sup>lt;sup>2)</sup> 5 % overvoltage.

<sup>3)</sup> Infeed to the limiter is always on the side 1L1/3L2/5L3.

### SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A

**General data** 

### Permissible rated data of approved devices for North America (UL/CSA)

Motor starter protectors of the 3RV2 series are approved for UL/CSA, and according to UL508/UL 60947-4-1 and CSA C22.2 No. 14/CSA C22.2 No. 60947-4-1 they can be used on their own or as load feeders in combination with a contactor.

These motor starter protectors/circuit breakers can be used as "Manual Motor Controllers" for "Group Installations", as "Manual Motor Controllers Suitable for Tap Conductor Protection in Group Installations" and as "Self-Protected Combination Motor Controllers" (Type E).

#### 3RV2 motor starter protectors as "Manual Motor Controllers"

If used as a "Manual Motor Controller", the motor starter protector is always operated in combination with an upstream short-circuit protection device. Approved fuses or a circuit breaker according to UL 489/CSA C22.2 No. 5 can be used. These devices must be dimensioned according to the National Electrical Code (UL) or Canadian Electrical Code (CSA).

The file numbers for the approval of the 3RV2 as a Manual Motor Controller are as follows:

- UL File No. 47705, CCN: NLRV
- CSA Master Contract 165071, Product Class: 3211 05

Motor starter		hp rating	g <sup>1)</sup> for FLA <sup>2)</sup>	Rated	240 V AC		480 V AC		600 V AC	
protectors		max.		current I <sub>n</sub>	UL I <sub>bc</sub> <sup>3)</sup>	CSA I <sub>bc</sub> <sup>3)</sup>	UL I <sub>bc</sub> <sup>3)</sup>	CSA I <sub>bc</sub> <sup>3)</sup>	UL I <sub>bc</sub> <sup>3)</sup>	CSA $I_{\rm bc}^{(3)}$
Type	V	Single- phase	Three- phase	А	kA	kA	kA	kA	kA	kA
Size S00										
3RV2011, 3RV2111	1, 3RV2311, 3R\	<b>V2411</b>		0.16 12.5 16	65 65	65 65	65 65	65 65	30	30
FLA <sup>2)</sup> max.	115	1	2							
16 A, 480 V; 12.5 A, 600 V	200 230 460 575/600	2 2 	2 3 5 10 10							
Size S0										
3RV2021, 3RV2121	1, 3RV2321, 3R\	/2421		0.16 12.5 16 25	65 65	65 65	65 65	65 65	30 /(30) <sup>4)</sup>	30 /(30) <sup>4)</sup>
FLA <sup>2)</sup> max.	115	3	5	28, 32	65	65	50	50		
40 A, 480 V	200 230 460 575/600	5 7 1/2 	10 10 30 	36, 40	65	65	12	12		
Size S2										
3RV2031, 3RV2032	2. 3RV2131.				Values on	request				

<sup>3</sup>RV2331, 3RV2332, 3RV2431
-- No approval

<sup>1)</sup> hp rating = Power rating in horse power (maximum motor rating).

<sup>2)</sup> FLA = Full Load Amps/motor full load current.

<sup>3)</sup> Corresponds to "short-circuit breaking capacity" according to UL/CSA.

<sup>4)</sup> The values in brackets only apply to 3RV2.23 motor starter protectors.

### SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A

#### **General data**

3RV20 motor starter protectors (up to 80 A) as "Manual Motor Controller Suitable for Tap Conductor Protection in Group Installations"

The application as "Manual Motor Controllers Suitable for Tap Conductor Protection in Group Installations" is only available for UL. CSA does not recognize this approval! When the motor starter protector is used as a "Manual Motor Controller Suitable for Tap Conductor Protection in Group Installations", it must always be combined with upstream short-circuit protection. Approved fuses or a circuit breaker according to UL 489 can be used. These devices must be dimensioned according to the National Electrical Code.

The 3RV20 motor starter protectors are approved as "Manual Motor Controllers Suitable for Tap Conductor Protection in Group Installations" under the following file number:

• UL File No. 47705, CCN: NLRV

Motor starter protectors		hp rating <sup>1)</sup> max.	for FLA <sup>2)</sup>	Rated current $I_{\rm n}$	<b>240 V AC</b> UL <i>I</i> <sub>bc</sub> <sup>3)</sup>	Up to 480 Y/277 V AC UL $I_{\rm bc}{}^{3)}$	Up to 600 Y/347 V AC UL $I_{\rm bc}{}^{3)}$
Туре	V	Single- phase	Three- phase	А	kA	kA	kA
Size S00							
3RV2011				0.16 12.5 16	65 65	65 65	30
FLA <sup>2)</sup> max.	115	1	2	.0			
16 A, 480 V; 12.5 A, 600 V	200 230 460 575/600	2 2  	3 5 10 10				
Size S0							
3RV2021				0.16 12.5 16 25	65 65	65 65	30
FLA <sup>2)</sup> max. 32 A, 480 V	115 200 230 460 575/600	2 3 5 	5 7 1/2 10 20 	28; 32	50	50	
Size S2							
3RV2031, 3RV2032					Values on request		

<sup>--</sup> No approval

<sup>1)</sup> hp rating = Power rating in horse power (maximum motor rating).

<sup>2)</sup> FLA = Full Load Amps/motor full load current.

<sup>3)</sup> Corresponds to "short-circuit breaking capacity" according to UL.

### SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A

**General data** 

### 3RV20 motor starter protectors (up to 80 A) as "Self-Protected Combination Motor Controller (Type E)"

UL 508/UL 60947-4-1 approval demands 1-inch clearance and 2-inch creepage distance at line side for "Self-Protected Combination Motor Controller Type E".

Therefore, 3RV20 motor starter protectors of sizes S00 to S2 are approved according to UL 508/UL 60947-4-1 in combination with the terminal blocks listed below.

CSA does not require these extended clearances and creepage distances. According to CSA, these terminal blocks can be omitted when the device is used as a "Self-Protected Combination Motor Controller".

The 3RV20 motor starter protectors are approved as "Self-Protected Combination Motor Controllers" under the following file numbers:

- UL File No. E156943, CCN: NKJH
- CSA Master Contract 165071, Product Class: 3211 08

Motor starter		hp rating <sup>1)</sup> for FLA <sup>2)</sup>		Rated	Up to 240 V AC		Up to 48	Up to 480 Y/277 V AC		Up to 600 Y/347 V AC	
protectors		max.		current I <sub>n</sub>	UL I <sub>bc</sub> <sup>3)</sup>	CSA $I_{ m bc}^{3)}$	UL I <sub>bc</sub> <sup>3)</sup>	CSA $I_{ m bc}^{3)}$	$I_{bc}^{(3)}$	CSA $I_{\rm bc}^{(3)}$	
Туре	V	Single- phase	Three- phase	А	kA	kA	kA	kA	kA	kA	
Size S00											
3RV2011 + 3RV2	928-1H <sup>4)5)</sup>			0.16 12.5 16	65 65			65 65	30	30 	
FLA <sup>2)</sup> max. 16 A, 480 V; 12.5 A, 600 V	115 200 230 460 575/600	1 2 2 	2 3 5 10 10								
Size S0											
3RV2021 + 3RV2	928-1H <sup>4)5)</sup>			0.16 12.5 16 25	65 65	65 65	65 65	65 65	30	30 	
FLA <sup>2)</sup> max. 32 A, 480 V	115 200 230 460 575/600	2 3 5 	5 7 1/2 10 20	28; 32	50	50	50	50			

### 3RV2031/3RV2032 + 3RV2938-1K<sup>4)</sup>

- -- No approval
- 1) hp rating = Power rating in horse power (maximum motor rating).
- 2) FLA = Full Load Amps/motor full load current.

### Values on request

- 3) Corresponds to "short-circuit breaking capacity" according to UL/CSA.
- 4) Not required for CSA.
- 5) Alternatively, the 3RV2928-1K phase barrier can also be used.

### 3RV27 and 3RV28 motor starter protectors as "circuit breakers"

These motor starter protectors are approved as circuit breakers according to UL 489 and CSA 22.2 No. 5. They can be used therefore as upstream short-circuit protective devices for "Manual Motor Controllers" and "Manual Motor Controllers Suitable for Tap Conductor Protection in Group Installations".

3RV27 and 3RV28 motor starter protectors are approved as "circuit breakers" under the following file numbers:

- UL File No. E235044, CCN: DIVQ
- CSA Master Contract 165071, Product Class: 1432 01

Circuit breakers	Rated current I <sub>n</sub>	240 V A	240 V AC		480 Y/277 V AC		600 Y/347 V AC	
		UL	CSA	UL	CSA	UL	CSA	
		$I_{bc}^{1)}$	$I_{\rm bc}^{-1)}$					
Туре	Α	kA	kA	kA	kA	kA	kA	
Size S00								
3RV2711	0.16 12.5 15	65 65	65 65	65 65	65 65	10	10 	
3RV2811	0.16 12.5 15	65 65	65 65	65 65	65 65	10	10 	
Size S0								
3RV2721	20; 22	50	50	50	50			
3RV2821	20; 22	50	50	50	50			

<sup>--</sup> No approval

<sup>1)</sup> Corresponds to "short-circuit breaking capacity" according to UL.

### SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A

General data						
<b>Type</b> Size			<b>3RV2.1.</b> S00	<b>3RV2.2.</b> S0	<b>3RV2.3.</b> S2	<b>3RV27, 3RV28</b> S00, S0
Dimensions (W x H x D)			000	00	02	000, 00
Screw terminals     Spring-type terminals	W	mm mm	45 x 97 x 91 45 x 106 x 91	45 x 97 x 91 45 x 119 x 91	55 x 140 x 149 	45 x 144 x 92 
Standards						
• IEC 60947-1, EN 60947-1 (VDE 0660 Par			Yes			
● IEC 60947-2, EN 60947-2 (VDE 0660 Par ● IEC 60947-4-1, EN 60947-4-1 (VDE 0660			Yes Yes	Yes	Yes	
• UL 508/UL 60947-4-1, CSA C22.2 No. 14			Yes	Yes	Yes	
• UL 489, CSA C22.2 No. 5						Yes
Number of poles			3			
Max. rated current I <sub>n max</sub>		А	16	40	80	22
(= max. rated operational current I <sub>e</sub> )						
Permissible ambient temperature		00	FO00			
<ul><li>Storage/transport</li><li>Operation</li></ul>	<i>I</i> <sub>n</sub> : 0.16 32 A	°C	-50 +80 -20 +70			
oporation.	-n. 0. 10 02 /1	J	(current reduction	n above +60 °C)		
	<i>I</i> <sub>n</sub> : 36 40 A	°C		–20 +40 <sup>*</sup>		
				(the devices must		
				not be mounted side-by-side and		
				they must not be		
				assembled with		
				link modules with		
				contactors.		
				A lateral clear- ance of 9 mm is		
				required.)		
	<i>I</i> <sub>n</sub> : 14 80 A	°C		roquirou.)	-20 +70	
					(current reduction	
					above +60 °C)	
Permissible rated current at inside temp	erature of control cabinet	0/	100			
• +60 °C • +70 °C		% %	100 87			
Permissible rated current at ambient ten	noroture of analogura	/0	01			
(applies for motor starter protector/circu		e < 32 A)				
• +35 °C		%	100		On	100
• +60 °C		%	87		request	87
Rated operational voltage <i>U</i> e						
• Acc. to IEC		V AC		ded-plastic enclosur	e is used only 500 \	/)
• Acc. to UL/CSA		V AC	600			
Rated frequency		Hz	50/60			
Rated insulation voltage <i>U</i> i		V	690			
Rated impulse withstand voltage $U_{ m imp}$		kV	6			
Utilization category						
IEC 60947-2 (motor starter protector/circles)	uit breaker)		A			
• IEC 60947-4-1 (motor starter)			AC-3			
Trip class CLASS	Acc. to IEC 60947-4-1		10		10/20	
DC short-circuit breaking capacity (time	constant $t = 5 \text{ ms}$ )		40			40
<ul> <li>1 conducting path 150 V DC</li> <li>2 conducting paths in series 300 V DC</li> </ul>		kA kA	10 10		On	10 10
• 3 conducting paths in series 300 V DC		kA	10		request	10
Power loss P <sub>v</sub> for each motor starter	<i>I</i> <sub>n</sub> : 0.16 0.63 A	W	5			5
protector/circuit breaker	I <sub>n</sub> : 0.8 6.3 A	W	6			6
Dependent on	<i>I</i> <sub>n</sub> : 8 16 A	W	7			7
the rated current In	I <sub>n</sub> : 16 A	W		7	10	7
(upper setting range)						
_ P	<i>I</i> <sub>n</sub> : 17 25 A <i>I</i> <sub>n</sub> : 28 32 A	W W		8 11	12 14	8
$R_{\text{per conducting path}} = \frac{P}{I^2 \times 3}$	I <sub>n</sub> : 36 40 A	W		14	15	
	<i>I</i> <sub>n</sub> : 45 52 A	W			17	
	<i>I</i> n: 80 A	W			On request	
	Acc. to IEC 60068-2-27	g/ms	25/11 (square and	d sine pulse)		
Shock resistance	ACC. 10 ILC 00000-2-21		IP20			
	Acc. to IEC 60529					
Degree of protection				ertical contact from t	he front	
Degree of protection Touch protection	Acc. to IEC 60529 Acc. to EN 50274	°C	Finger-safe for ve	ertical contact from t	he front	
Degree of protection Touch protection Temperature compensation	Acc. to IEC 60529 Acc. to EN 50274 Acc. to IEC 60947-4-1	°C	Finger-safe for ve			No
Degree of protection Touch protection Temperature compensation Phase failure sensitivity	Acc. to IEC 60529 Acc. to EN 50274 Acc. to IEC 60947-4-1 Acc. to IEC 60947-4-1	°C	Finger-safe for ver-20 +60 Yes (only for 3RV)	23 motor starter pro	tectors)	No
Shock resistance  Degree of protection  Touch protection  Temperature compensation  Phase failure sensitivity  Explosion protection – Safe operation of	Acc. to IEC 60529 Acc. to EN 50274 Acc. to IEC 60947-4-1 Acc. to IEC 60947-4-1	°C	Finger-safe for ver-20 +60 Yes (only for 3RV)		tectors)	No
Degree of protection Touch protection Temperature compensation Phase failure sensitivity	Acc. to IEC 60529 Acc. to EN 50274 Acc. to IEC 60947-4-1 Acc. to IEC 60947-4-1 f motors with	°C	Finger-safe for ver-20 +60 Yes (only for 3RV)	23 motor starter pro 20 motor starter pro	tectors)	No No

### SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A

General data (continued)						
Type Size Dimensions (W x H x D) • Screw terminals • Spring-type terminals Isolating function Main and EMERGENCY-STOP switch characteristics	Acc. to IEC 60947-2 Acc. to DIN EN 60204-1	mm mm	3RV2.1. S00 45 × 97 × 91 45 × 106 × 91 Yes Yes	<b>3RV2.2.</b> S0 45 × 97 × 91 45 × 119 × 91	<b>3RV2.3.</b> S2 55 x 140 x 149	<b>3RV27, 3RV28</b> S00, S0 45 x 144 x 92
(with corresponding accessories)  Protective separation between main and auxiliary circuits, required for PELV applications  • Up to 400 V +10 %  • Up to 415 V +5 % (higher voltages on reference)	Acc. to IEC 60947-1		Yes Yes			
Permissible mounting position			Any, acc. to IEC 6	0447 start commar	nd "I" right-hand side	e or top
Mechanical endurance	Operati	ing cycles	100 000		52 A: 50 000, 80 A: On request	100 000
Electrical endurance	Operati	ing cycles	100 000		52 A: 50 000, 80 A: On request	100 000
Max. switching frequency per hour (mo	tor starts)	1/h	15		_	

Rated data of the auxiliary switches and signaling switches	5				
		Lateral auxiliary switch with	Signaling switches	Transverse auxiliary switch with	
		1 NO + 1 NC, 2 NO, 2 NC, 2 NO + 2 NC		1 CO	1 NO + 1 NC, 2 NO
Max. rated voltage					
• Acc. to NEMA (UL)	V AC	600			250
• Acc. to NEMA (CSA)	V AC	600			250
Uninterrupted current	Α	10		5	2.5
Switching capacity		1 NO + 1 NC, 2 NO, 2 NC: A600, Q300; 2 NO + 2 NC: A300, Q300	A600, Q300	B600, R300	C300, R300

Front transverse auxiliary switches			
		Switching capacity for	or different voltages
		1 CO	1 NO + 1 NC, 2 NO
Rated operational current I <sub>e</sub>			
<ul> <li>At AC-15, alternating voltage</li> <li>24 V</li> <li>230 V</li> </ul>	A A	4 3	2 0.5
<ul> <li>At AC-12 = I<sub>th</sub>, alternating voltage</li> <li>24 V</li> <li>230 V</li> </ul>	A A	10 10	2.5 2.5
<ul> <li>At DC-13, direct voltage L/R 200 ms</li> <li>24 V</li> <li>48 V</li> <li>60 V</li> <li>110 V</li> <li>220 V</li> </ul>	A A A A	1  0.22 0.1	1 0.3 0.15 
Minimum load capacity	V mA	17 1	

Front transverse solid-state com	patible auxiliary switches		
			Switching capacity for different voltages
			1 00
Rated operational voltage U <sub>e</sub>	Alternating voltage	V	125
Rated operational current I <sub>e</sub> /AC-14	at $U_{\rm e}$ = 125 V	Α	0.1
Rated operational voltage U <sub>e</sub>	Direct voltage L/R 200 ms	V	60
Rated operational current I <sub>e</sub> /DC-13	at $U_{e} = 60 \text{ V}$	Α	0.3
Minimum load capacity		V	5
		mΑ	1

SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A

Lateral auxiliary switches with signaling switch		
		Switching capacity for different voltages: Lateral auxiliary switch with 1 NO + 1 NC, 2 NO, 2 NC, 2 NO + 2 NC Signaling switch
Rated operational current I <sub>e</sub>		
<ul> <li>At AC-15, alternating voltage</li> <li>24 V</li> <li>230 V</li> <li>400 V</li> <li>690 V</li> </ul>	A A A	6 4 3 1
<ul> <li>At AC-12 = I<sub>th</sub>, alternating voltage</li> <li>24 V</li> <li>230 V</li> <li>400 V</li> <li>690 V</li> </ul>	A A A	10 10 10 10
<ul> <li>At DC-13, direct voltage L/R 200 ms</li> <li>24 V</li> <li>110 V</li> <li>220 V</li> <li>440 V</li> </ul>	A A A	2 0.5 0.25 0.1
Minimum load capacity	V mA	17 1

Auxiliary releases			
		Undervoltage releases	Shunt releases
Power consumption			
<ul><li>During pick-up</li><li>AC voltages</li><li>DC voltages</li></ul>	VA/W W	20.2/13 20	20.2/13 13 80
<ul><li>During uninterrupted duty</li><li>AC voltages</li><li>DC voltages</li></ul>	VA/W W	7.2/2.4 2.1	 
Response voltage			
• Tripping	V	0.35 0.7 x <i>U</i> <sub>s</sub>	0.7 1.1 x U <sub>s</sub>
• Pick-up	V	0.85 1.1 x <i>U</i> <sub>s</sub>	
Opening time maximum	ms	20	

Short-circuit protection for auxiliary and control circuits		
Melting fuses operational class gG	А	10
Miniature circuit breakers C characteristic	Α	6 (prospective short-circuit current < 0.4 kA)

SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A

						General ua
Conductor cross-sections of main circuit						
Туре		3RV2.11	3RV2.21	3RV2.31-4B1., 3RV2.31-4D.1., 3RV2.31-4E.1., 3RV2.31-4P.1., 3RV2.31-4S.1., 3RV2.31-4T.1., 3RV2.31-4U.1., 3RV2.31-4V.1.	3RV2.31-4J.1., 3RV2.31-4K.1., 3RV2.31-4R.1., 3RV2.31-4W.1., 3RV2.31-4X.1., 3RV2.31-4X.1, 3RV2.32	3RV27, 3RV28
Size		S00	S0	S2		S00, S0
Connection type		Screw term	inals			
Terminal screw		M3, Pozidriv size 2	M4, Pozidriv size 2	M6, Pozidriv size 2		M4, Pozidriv size 2
Operating devices	mm	Ø 5 6	Ø 5 6	Ø 5 6		Ø 5 6
Prescribed tightening torque	Nm	0.8 1.2	2 2.5	3.0 4.5		2.5 3
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected						
Solid or stranded	mm <sup>2</sup>	2 x (0.75 2.5) <sup>1)</sup> , 2 x 4	2 x (1 2.5) <sup>1)</sup> , 2 x (2.5 10) <sup>1)</sup>	2 x (1 25) <sup>1)</sup> , 1 x (1 35) <sup>1)</sup>	2 x (1 35) <sup>1)</sup> , 1 x (1 50) <sup>1)</sup>	2 x (1 10) <sup>1)</sup> , max. 1 x 25
• Finely stranded with end sleeve (DIN 46228-1)	mm <sup>2</sup>	2 x (0.5 1.5) <sup>1)</sup> 2 x (0.75 2.5) <sup>1)</sup>	2 x (1 2.5) <sup>1)</sup> , 2 x (2.5 6) <sup>1)</sup> , 1 x 10	2 x (1 16) <sup>1)</sup> , 1 x (1 25) <sup>1)</sup>	2 x (1 25) <sup>1)</sup> , 1 x (1 35) <sup>1)</sup>	1 x (1 16), max. 6 + 16
AWG cables, solid or stranded	AWG	2 x (20 16) <sup>1)</sup> , 2 x (18 12) <sup>1)</sup>	2 x (16 12) <sup>1)</sup> , 2 x (14 8) <sup>1)</sup>	2 x (18 3) <sup>1)</sup> , 1 x (18 2) <sup>1)</sup>	2 x (18 2) <sup>1)</sup> , 1 x (18 1) <sup>1)</sup>	2 x (14 10)
Connection type	Spring-type	terminals				
Operating devices	mm	3.0 x 0.5 and 3.5 x	0.5			
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected						
Solid or stranded	mm <sup>2</sup>	2 x (0.5 4)	2 x (1 10)			
Finely stranded without end sleeve	mm <sup>2</sup>	2 x (0.5 2.5)	2 x (1 6)			
<ul> <li>Finely stranded with end sleeve (DIN 46228-11)</li> </ul>	mm <sup>2</sup>	2 x (0.5 2.5)	2 x (1 6)			
<ul> <li>AWG cables, solid or stranded</li> </ul>	AWG	2 x (20 12)	2 x (18 8)			
Max. external diameter of the conductor insulation	mm	3.6	3.6			
Connection type		Ring termin	al lug connection	ıs		
Terminal screw		M3, Pozidriv size 2	M4, Pozidriv size 2			
Operating devices	mm	Ø 5 6	Ø 5 6			
Prescribed tightening torque	Nm	0.8 1.2	2 2.5			
Usable ring terminal lugs   → d <sub>3</sub> →	mm	$d_2 = min. 3.2,$	$d_2 = min. 4.3,$			
DIN 46234 without insulation sleeve		$d_3 = \text{max. } 7.5$	$d_3 = \text{max. } 12.2$			
DIN 46225 without insulation sleeve						
DIN 46237 with insulation sleeve						
• JIS C2805 Type R without insulation sleeve						
JIS C2805 Type RAV with insulation sleeve						
<ul> <li>JIS C2805 Type RAP with insulation sleeve</li> </ul>						

<sup>1)</sup> If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.

### SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A

### General data

Туре		3RV2.11	3RV2.21	3RV2.31, 3RV2.32	3RV27, 3RV28	
Size		S00	S0	S2	S00, S0	
Connection type		Screw 1	erminals			
Terminal screw		M3, Pozidriv s	size 2			
Operating devices	mm	Ø 5 6				
Prescribed tightening torque	Nm	0.8 1.2				
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected						
Solid or stranded	$mm^2$	2 x (0.5 1.5	) <sup>1)</sup> , 2 x (0.75 2.	5) <sup>1)</sup>		
• Finely stranded with end sleeve (DIN 46228-1)	$\text{mm}^2$	2 x (0.5 1.5	) <sup>1)</sup> , 2 x (0.75 2.	5) <sup>1)</sup>		
AWG cables, solid or stranded	AWG	2 x (18 14)	<sup>1)</sup> , 2 x (20 16) <sup>1)</sup>			
Connection type		Spring-	type terminals			
Operating devices	mm	3.0 x 0.5 and	3.5 x 0.5			
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected						
Solid or stranded	mm <sup>2</sup>	2 x (0.5 2.5	)			
Finely stranded without end sleeve	mm <sup>2</sup>	2 x (0.5 2.5)				
<ul> <li>Finely stranded with end sleeve (DIN 46228-1)</li> </ul>	mm <sup>2</sup>	2 x (0.5 1.5)				
AWG cables, solid or stranded	AWG	2 x (20 14)				
Max. external diameter of the conductor insulation	mm	3.6				
Connection type		Ring te	rminal lug conne	ections		
Terminal screw		M3, Pozidriv s	size 2			
Operating devices	mm	Ø 5 6				
Tightening torque	Nm	0.8 1.2				
Usable ring terminal lugs  • DIN 46234 without insulation sleeve  • DIN 46225 without insulation sleeve  • DIN 46237 with insulation sleeve  • DIN 20805 Type R without insulation sleeve  • JIS C2805 Type RAV with insulation sleeve  • JIS C2805 Type RAP with insulation sleeve	mm	d <sub>2</sub> = min. 3.2,	d <sub>3</sub> = max. 7.5			

## Terminals for "Self-Protected Combination Motor Controllers (Type E) according to UL 508/UL 60947-4-1"

according	to or 300/or 0034/-4-1		
Туре			3RV2928-1H
Prescribed t	ightening torque	Nm	2.5 3
Conductor c	cross-sections		
• Front clamp	oing point connected - Solid - Finely stranded with end sleeve - Stranded - AWG cables, solid or stranded - Terminal screw	mm² mm² mm² AWG	1 10 1 16 2.5 25 14 3 M4
Rear clamp	ping point connected	_	
NSB0_00480	<ul> <li>Solid</li> <li>Finely stranded with end sleeve</li> <li>Stranded</li> <li>AWG cables, solid or stranded</li> <li>Terminal screw</li> </ul>	mm² mm² mm² AWG	1 10 1 16 1.5 25 14 6
<ul> <li>Both clamp</li> </ul>	ing points connected		
NSB0_00481	<ul> <li>Front clamping point:         Solid         Finely stranded with end sleeve         Stranded         AWG cables, solid or stranded         Terminal screw     </li> </ul>	mm² mm² mm² AWG	1 10 1 10 <sup>1</sup> ), 1 6 <sup>1</sup> ) 2.5 10 14 6 M4
	<ul> <li>Rear clamping point:         Solid         Finely stranded with end sleeve         Stranded         AWG cables, solid or stranded         Terminal screw     </li> </ul>	mm² mm² mm² AWG	1 10 1 10 <sup>1)</sup> , 1 16 <sup>1)</sup> 2.5 10 16 3 M4

- 1) The following can be connected when both clamping points are connected:
  - Front 1 ... 10  $\text{mm}^2$  and rear 1 ... 10  $\text{mm}^2$
  - Front 1 ... 6 mm² and rear 1 ... 16 mm²


### **Motor Starter Protectors/Circuit Breakers** SIRIUS 3RV2 Motor Starter Protectors up to 80 A

For motor protection

### Selection and ordering data

### CLASS 10, without auxiliary switches<sup>1)</sup>

PU (UNIT, SET, M) = 1 PS\* PG = 1 unit = 41E











3RV2011-0/	4A10
------------	------

3RV2011-0EA20

3RV2021-4AA10

3RV2021-4AA20

Rated current	Suitable for three-phase motors <sup>2)</sup> with <i>P</i>	Setting range for thermal overload release	Instantaneous overcurrent release	Short-circuit breaking capacity at 400 V AC		Screw terminals	<b>+</b>	DT	Spring-type terminals	
$I_{n}$		日	[ >	$I_{\mathrm{CU}}$		Article No.	Price		Article No.	Price
Α	kW	A	A	kA			per PU			per PU
Size S0										
0.16	0.04	0.11 0.16	2.1	100	<b>&gt;</b>	3RV2011-0AA10		•	3RV2011-0AA20	
0.2	0.06	0.14 0.2	2.6	100	<b>&gt;</b>	3RV2011-0BA10		<b></b>	3RV2011-0BA20	
0.25	0.06	0.18 0.25	3.3	100	<b>&gt;</b>	3RV2011-0CA10		<b></b>	3RV2011-0CA20	
0.32	0.09	0.22 0.32	4.2	100	<b>&gt;</b>	3RV2011-0DA10		<b></b>	3RV2011-0DA20	
0.4	0.09	0.28 0.4	5.2	100		3RV2011-0EA10			3RV2011-0EA20	
0.5 0.63	0.12 0.18	0.35 0.5 0.45 0.63	6.5 8.2	100 100	<b>&gt;</b>	3RV2011-0FA10 3RV2011-0GA10		<b>&gt;</b>	3RV2011-0FA20 3RV2011-0GA20	
0.8	0.18	0.55 0.8	10	100		3RV2011-0GA10			3RV2011-0GA20 3RV2011-0HA20	
1	0.25	0.7 1	13	100	•	3RV2011-0JA10		<b></b>	3RV2011-0JA20	
1.25	0.37	0.9 1.25	16	100	<b>&gt;</b>	3RV2011-0KA10		<b>&gt;</b>	3RV2011-0KA20	
1.6	0.55	1.1 1.6	21	100	▶	3RV2011-1AA10		<b></b>	3RV2011-1AA20	
2	0.75	1.4 2	26	100	<b>&gt;</b>	3RV2011-1BA10		<b></b>	3RV2011-1BA20	
2.5	0.75	1.8 2.5	33	100	<b>&gt;</b>	3RV2011-1CA10		<b></b>	3RV2011-1CA20	
3.2 4	1.1 1.5	2.2 3.2 2.8 4	42 52	100 100	<b>&gt;</b>	3RV2011-1DA10 3RV2011-1EA10		<b>&gt;</b>	3RV2011-1DA20 3RV2011-1EA20	
5	1.5	2.6 4 3.5 5	65	100		3RV2011-1EA10			3RV2011-1EA20 3RV2011-1FA20	
6.3	2.2	4.5 6.3	82	100	•	3RV2011-1GA10		<u> </u>	3RV2011-1GA20	
8	3	5.5 8	104	100		3RV2011-1GA10		<b>•</b>	3RV2011-10A20	
10	4	7 10	130	100	▶	3RV2011-1JA10		<b></b>	3RV2011-1JA20	
12.5	5.5	9 12.5	163	100	<b>&gt;</b>	3RV2011-1KA10		<b></b>	3RV2011-1KA20	
16	7.5	10 <sup>3)</sup> 16	208	55	<b>&gt;</b>	3RV2011-4AA10		<b></b>	3RV2011-4AA20	
Size S0										
0.63	0.18	0.45 0.63	8.2		<i>EW</i> B	3RV2021-0GA10		В	3RV2021-0GA20	
0.8	0.18	0.55 0.8	10		EW B	3RV2021-0HA10		В	3RV2021-0HA20	
1	0.25	0.7 1	13		EW B	3RV2021-0JA10		В	3RV2021-0JA20	
1.25 1.6	0.37 0.55	0.9 1.25	16 21		EW B EW B	3RV2021-0KA10 3RV2021-1AA10		B B	3RV2021-0KA20 3RV2021-1AA20	
2	0.75	1.1 1.6 1.4 2	26		EW B	3RV2021-1AA10		В	3RV2021-1AA20 3RV2021-1BA20	
2.5	0.75	1.8 2.5	33		EW B	3RV2021-1CA10		В	3RV2021-1CA20	
3.2	1.1	2.2 3.2	42		EW B	3RV2021-1DA10		В	3RV2021-1DA20	
4	1.5	2.8 4	52	100 N	<i>EW</i> B	3RV2021-1EA10		В	3RV2021-1EA20	
5	1.5	3.5 5	65	100 N	EW B	3RV2021-1FA10		В	3RV2021-1FA20	
6.3	2.2	4.5 6.3	82		<i>EW</i> B	3RV2021-1GA10		В	3RV2021-1GA20	
8	3	5.5 8	104		EW B	3RV2021-1HA10		В	3RV2021-1HA20	
10 12.5	4 5.5	7 10 9 12.5	130 163		EW B EW B	3RV2021-1JA10 3RV2021-1KA10		B B	3RV2021-1JA20 3RV2021-1KA20	
16			208	55				<b>D</b>	3RV2021-1RA20	
20	7.5 7.5	13 <sup>3)</sup> 20	260	55		3RV2021-4AA10 3RV2021-4BA10			3RV2021-4AA20 3RV2021-4BA20	
22	11	10.7 66	286	55		3RV2021-4CA10		•	3RV2021-4DA20	
25	11	18 <sup>3)</sup> 25	325	55	<b>&gt;</b>	3RV2021-4DA10		<b>&gt;</b>	3RV2021-4DA20	
28 32 <sup>4)</sup>	15 15	23 28 27 32	364 400	55 55	<b>&gt;</b>	3RV2021-4NA10 3RV2021-4EA10		<b>&gt;</b>	3RV2021-4NA20 3RV2021-4EA20	
36 <sup>5)</sup>	18.5	30 36	432	20	<b>&gt;</b>	3RV2021-4PA10				
40 <sup>5)</sup>	18.5	34 40	480	20	•	3RV2021-4FA10				

<sup>1)</sup> The 3RV20.1-..A.0 motor starter protectors up to 32 A are also available with ring terminal lug connection. The Article No. must be changed in the 11th digit to "4": e.g. 3RV2011-0AA40.

Auxiliary switches and other accessories can be ordered separately (see "Accessories" page 7/32 onwards).

<sup>2)</sup> Guide value for 4-pole standard motors at 50 Hz 400 V AC. The actual starting and rated data of the motor to be protected must be considered when selecting the units.

 $<sup>^{3)}</sup>$  The setting range of the thermal overload releases has been extended.


<sup>4)</sup> Suitable for use with IE3 motors up to a starting current of 256 A. For higher starting currents we recommend using 3RV2 motor starter protectors size S2.

<sup>5)</sup> The devices must not be mounted side-by-side and they must not be assembled with link modules with contactors. A lateral clearance of 9 mm is required. For use with IE3 motors we recommend using 3RV2 motor starter protectors size S2.

SIRIUS 3RV2 Motor Starter Protectors up to 80 A

### For motor protection

### CLASS 10, without auxiliary switches







3RV2031-4.A10

3RV2032-4.A10

Rated current	Suitable for three-phase motors 1) with P	Setting range for thermal overload release	Instantaneous overcurrent release	Short-circuit breaking cap at 400 V AC		DT	Screw terminals	<b>+</b>	PU (UNIT, SET, M)	PS*	PG
I <sub>n</sub>	kW	G A	[ <i>I</i> >	$I_{ m cu}$ kA			Article No.	Price per PU			
Size S2	2										
14 17 20 25	5.5 7.5 7.5 11	9.5 14 12 17 14 20 18 25	208 260 260 325	65 65 65 65	NEW NEW NEW	A A	3RV2031-4SA10 3RV2031-4TA10 3RV2031-4BA10 3RV2031-4DA10		1 1 1 1	1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E
32 36 40 45	15 18.5 18.5 22	22 32 28 36 32 40 35 45	416 520 585 650	65 65 65 65	NEW NEW NEW	A A	3RV2031-4EA10 3RV2031-4PA10 3RV2031-4UA10 3RV2031-4VA10		1 1 1 1	1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E
52 59 <sup>2)</sup> 65 <sup>2)</sup> 73 <sup>2)</sup> 80 <sup>2)3)</sup>	22 30 30 37 37	42 52 49 59 54 65 62 73 70 80	741 845 845 949 1 040	65 65 65 65 65	NEW NEW NEW NEW	X X X	3RV2031-4WA10 3RV2031-4XA10 3RV2031-4JA10 3RV2031-4KA10 3RV2031-4RA10		1 1 1 1	1 unit 1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E 41E
Size S2	2, with increase	d switching capaci	ty								
14 17 20 25	5.5 7.5 7.5 11	9.5 14 12 17 14 20 18 25	208 260 260 325	100 100 100 100	NEW NEW NEW NEW	A A	3RV2032-4SA10 3RV2032-4TA10 3RV2032-4BA10 3RV2032-4DA10		1 1 1 1	1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E
32 36 40 45	15 18.5 18.5 22	22 32 28 36 32 40 35 45	416 520 585 650	100 100 100 100	NEW NEW NEW	A A	3RV2032-4EA10 3RV2032-4PA10 3RV2032-4UA10 3RV2032-4VA10		1 1 1 1	1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E
52 59 <sup>2)</sup> 65 <sup>2)</sup> 73 <sup>2)</sup> 80 <sup>2)3)</sup>	22 30 30 37 37	42 52 49 59 54 65 62 73 70 80	741 845 845 949 1 040	100 100 100 100 100	NEW NEW NEW NEW	X X X	3RV2032-4WA10 3RV2032-4XA10 3RV2032-4JA10 3RV2032-4KA10 3RV2032-4RA10		1 1 1 1	1 unit 1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E 41E

<sup>1)</sup> Guide value for 4-pole standard motors at 50 Hz 400 V AC. The actual starting and rated data of the motor to be protected must be considered when selecting the units.

Auxiliary switches and other accessories can be ordered separately (see "Accessories" page 7/32 onwards).

<sup>2)</sup> Start of delivery on request.

<sup>3)</sup> Suitable for use with IE3 motors up to a starting current of 720 A. For higher starting currents we recommend using 3RV1 motor starter protectors size S3




### Motor Starter Protectors/Circuit Breakers SIRIUS 3RV2 Motor Starter Protectors up to 80 A

For motor protection

### CLASS 10, with transverse auxiliary switch (1 NO + 1 NC)

 $\begin{array}{ll} PU \text{ (UNIT, SET, M)} &= 1 \\ PS^* &= 1 \text{ unit} \\ PG &= 41E \end{array}$ 





3RV2011-4AA15 with integrated transverse auxiliary switch



3RV2011-0EA25 with integrated transverse auxiliary switch



3RV2021-4AA15 with integrated transverse auxiliary switch



3RV2021-4AA25 with integrated transverse auxiliary switch

		auxiliar y Switch		addition 5 witch		auxilial y Switch			auxiliary Switch	
Rated current	Suitable for three-phase motors <sup>1)</sup> with <i>P</i>	Setting range for thermal overload release	Instantaneous overcurrent release	Short-circuit breaking capacity at 400 V AC	DT	Screw terminals	<b>+</b>	DT	Spring-type terminals	
I <sub>n</sub>	kW	G A	[	$I_{ m CU}$ kA		Article No.	Price per PU		Article No.	Price per PU
Size S0		A	A	KA						
0.16 0.2 0.25 0.32	0.04 0.06 0.06 0.09	0.11 0.16 0.14 0.2 0.18 0.25 0.22 0.32	2.1 2.6 3.3 4.2	100 100 100 100	<b>* * * *</b>	3RV2011-0AA15 3RV2011-0BA15 3RV2011-0CA15 3RV2011-0DA15		<b>&gt;</b>	3RV2011-0AA25 3RV2011-0BA25 3RV2011-0CA25 3RV2011-0DA25	
0.4 0.5 0.63 0.8	0.09 0.12 0.18 0.18	0.28 0.4 0.35 0.5 0.45 0.63 0.55 0.8	5.2 6.5 8.2 10	100 100 100 100	<b>* * *</b>	3RV2011-0EA15 3RV2011-0FA15 3RV2011-0GA15 3RV2011-0HA15		<b>A A A</b>	3RV2011-0EA25 3RV2011-0FA25 3RV2011-0GA25 3RV2011-0HA25	
1 1.25 1.6 2	0.25 0.37 0.55 0.75	0.7 1 0.9 1.25 1.1 1.6 1.4 2	13 16 21 26	100 100 100 100	<b>* * *</b>	3RV2011-0JA15 3RV2011-0KA15 3RV2011-1AA15 3RV2011-1BA15		<b>A A A</b>	3RV2011-0JA25 3RV2011-0KA25 3RV2011-1AA25 3RV2011-1BA25	
2.5 3.2 4 5	0.75 1.1 1.5 1.5	1.8 2.5 2.2 3.2 2.8 4 3.5 5	33 42 52 65	100 100 100 100	<b>* * *</b>	3RV2011-1CA15 3RV2011-1DA15 3RV2011-1EA15 3RV2011-1FA15		<b>A A A</b>	3RV2011-1CA25 3RV2011-1DA25 3RV2011-1EA25 3RV2011-1FA25	
6.3 8 10 12.5 16	2.2 3 4 5.5 7.5	4.5 6.3 5.5 8 7 10 9 12.5 10 <sup>2)</sup> 16	82 104 130 163 208	100 100 100 100 55	<b>* * * *</b>	3RV2011-1GA15 3RV2011-1HA15 3RV2011-1JA15 3RV2011-1KA15 3RV2011-4AA15		<b>A A A A</b>	3RV2011-1GA25 3RV2011-1HA25 3RV2011-1JA25 3RV2011-1KA25 3RV2011-4AA25	
Size S0										
16 20 22 25 28 32 <sup>3)</sup>	7.5 7.5 11 11	10 <sup>2</sup> ) 16 13 <sup>2</sup> ) 20 16 <sup>2</sup> ) 22 18 <sup>2</sup> ) 25 23 28	208 260 286 325 364	55 55 55 55 55	<b>* * * *</b>	3RV2021-4AA15 3RV2021-4BA15 3RV2021-4CA15 3RV2021-4DA15 3RV2021-4NA15		<b>A A A A</b>	3RV2021-4AA25 3RV2021-4BA25 3RV2021-4CA25 3RV2021-4DA25 3RV2021-4NA25	
32 <sup>3)</sup> 36 <sup>4)</sup> 40 <sup>4)</sup>	15 18.5 18.5	27 32 30 36 34 40	400 432 480	55 20 20	<b>* *</b>	3RV2021-4EA15 3RV2021-4PA15 3RV2021-4FA15		•	3RV2021-4EA25  	

<sup>1)</sup> Guide value for 4-pole standard motors at 50 Hz 400 V AC. The actual starting and rated data of the motor to be protected must be considered when selecting the units.

Auxiliary switches and other accessories can be ordered separately (see "Accessories" page 7/32 onwards).

<sup>&</sup>lt;sup>2)</sup> The setting range of the thermal overload releases has been extended.


<sup>3)</sup> Suitable for use with IE3 motors up to a starting current of 256 A. For higher starting currents we recommend using 3RV2 motor starter protectors size S2.

<sup>4)</sup> The devices must not be mounted side-by-side and they must not be assembled with link modules with contactors. A lateral clearance of 9 mm is required. For use with IE3 motors we recommend using 3RV2 motor starter protectors size S2.

SIRIUS 3RV2 Motor Starter Protectors up to 80 A

### For motor protection

### CLASS 20, without auxiliary switches







3RV2031-4.B10

3RV2031-4WB10

Rated current	Suitable for three-phase motors <sup>1)</sup> with <i>P</i>	Setting range for thermal overload release	Instantaneous overcurrent release	Short-circuit breaking cap at 400 V AC	acity D	Т	Screw terminals	<b>(1)</b>	PU (UNIT, SET, M)	PS*	PG
$I_{n}$		日	<i>I</i> >	$I_{\mathrm{CU}}$			Article No.	Price			
Α	kW	A	A	kA				per PU			
Size S2											
14	5.5	9.5 14	208		<i>NEW</i> A		3RV2031-4SB10		1	1 unit	41E
17	7.5	12 17	260		<i>NEW</i> A		3RV2031-4TB10		1	1 unit	41E
20	7.5	14 20	260	65	NEW A		3RV2031-4BB10		1	1 unit	41E
25	11	18 25	325	65	<i>NEW</i> A		3RV2031-4DB10		1	1 unit	41E
32	15	22 32	416	65	<i>NEW</i> A		3RV2031-4EB10		1	1 unit	41E
36	18.5	28 36	520	65	<i>NEW</i> A		3RV2031-4PB10		1	1 unit	41E
40	18.5	32 40	585	65	NEW A		3RV2031-4UB10		1	1 unit	41E
45	22	35 45	650	65	<i>NEW</i> A		3RV2031-4VB10		1	1 unit	41E
52	22	42 52	741	65	<i>NEW</i> A		3RV2031-4WB10		1	1 unit	41E
59 <sup>2)</sup>	30	49 59	845	65	NEW X		3RV2031-4XB10		1	1 unit	41E
65 <sup>2)</sup>	30	54 65	845	65	NEW X		3RV2031-4JB10		1	1 unit	41E

<sup>1)</sup> Guide value for 4-pole standard motors at 50 Hz 400 V AC. The actual starting and rated data of the motor to be protected must be considered when selecting the units.

Auxiliary switches and other accessories can be ordered separately (see "Accessories" page 7/32 onwards).

<sup>&</sup>lt;sup>2)</sup> Start of delivery on request.

### Motor Starter Protectors/Circuit Breakers SIRIUS 3RV2 Motor Starter Protectors up to 80 A

For motor protection with overload relay function

### Selection and ordering data

### CLASS 10, with overload relay function (automatic RESET), without auxiliary switches



<sup>1)</sup> Guide value for 4-pole standard motors at 50 Hz 400 V AC. The actual starting and rated data of the motor to be protected must be considered when selecting the units.

Auxiliary switches and other accessories can be ordered separately (see "Accessories" page 7/32 onwards).

Accessories for mounting on the right and 3RV2915 three-phase busbars cannot be used

 $<sup>^{3)}</sup>$  The setting range of the thermal overload releases has been extended.

<sup>4)</sup> Suitable for use with IE3 motors up to a starting current of 256 A. For higher starting currents we recommend using 3RV2 motor starter protectors size S2.

<sup>5)</sup> Start of delivery on request.

<sup>6)</sup> Suitable for use with IE3 motors up to a starting current of 720 A. For higher starting currents we recommend using 3RV1 motor starter protectors size S3.


### SIRIUS 3RV2 Motor Starter Protectors up to 80 A

### For starter combinations

### Selection and ordering data

### Without auxiliary switches

 $\begin{array}{ll} PU \text{ (UNIT, SET, M)} &= 1 \\ PS^* &= 1 \text{ unit} \\ PG &= 41E \end{array}$ 











3RV2311-4AC10

3RV2311-0JC20

3RV2321-4AC10

3RV2321-4AC20

Rated current	Suitable for three-phase motors <sup>1)</sup> with <i>P</i>	Thermal overload release <sup>2)</sup>	Instantaneous overcurrent release	Short-circuit breaking capacity at 400 V AC	DT	Screw terminals	<b>+</b>	DT	Spring-type terminals	
$I_{D}$		G	<i>I</i> >	$I_{\mathrm{CU}}$		Article No.	Price per PU		Article No.	Price per PU
Α	kW	A	A	kA			perro			perro
Size S0	0									
0.16	0.04	Without	2.1	100	В	3RV2311-0AC10		В	3RV2311-0AC20	
0.2	0.06	Without	2.6	100	В	3RV2311-0BC10		В	3RV2311-0BC20	
0.25 0.32	0.06 0.09	Without Without	3.3 4.2	100 100	B B	3RV2311-0CC10 3RV2311-0DC10		B B	3RV2311-0CC20 3RV2311-0DC20	
0.4 0.5	0.09 0.12	Without Without	5.2 6.5	100 100	B B	3RV2311-0EC10 3RV2311-0FC10		B B	3RV2311-0EC20 3RV2311-0FC20	
0.63	0.12	Without	8.2	100	В	3RV2311-0FC10		В	3RV2311-0GC20	
0.8	0.18	Without	10	100	В	3RV2311-0HC10		В	3RV2311-0HC20	
1	0.25	Without	13	100	В	3RV2311-0JC10		В	3RV2311-0JC20	
1.25	0.37	Without	16	100	В	3RV2311-0KC10		В	3RV2311-0KC20	
1.6	0.55	Without	21	100	В	3RV2311-1AC10		В	3RV2311-1AC20	
2	0.75	Without	26	100	В	3RV2311-1BC10		В	3RV2311-1BC20	
2.5	0.75	Without	33	100	В	3RV2311-1CC10		В	3RV2311-1CC20	
3.2	1.1	Without	42	100	В	3RV2311-1DC10		В	3RV2311-1DC20	
4	1.5	Without	52 65	100	B B	3RV2311-1EC10		B B	3RV2311-1EC20	
5	1.5	Without		100		3RV2311-1FC10			3RV2311-1FC20	
6.3	2.2	Without	82	100	В	3RV2311-1GC10		B B	3RV2311-1GC20	
8 10	3 4	Without Without	104 130	100 100	B B	3RV2311-1HC10 3RV2311-1JC10		В	3RV2311-1HC20 3RV2311-1JC20	
12.5	5.5	Without	163	100	В	3RV2311-13C10		В	3RV2311-13C20 3RV2311-1KC20	
16	7.5	Without	208	55	В	3RV2311-4AC10		В	3RV2311-4AC20	
Size S0										
1.6	0.55	Without	21	100 NEV		3RV2321-1AC10		В	3RV2321-1AC20	
2	0.75	Without	26	100 <b>NEV</b>	<b>⊿</b> B	3RV2321-1BC10		В	3RV2321-1BC20	
2.5	0.75	Without	33	100 NEV		3RV2321-1CC10		В	3RV2321-1CC20	
3.2	1.1	Without	42	100 <b>NEV</b>	¼ B	3RV2321-1DC10		В	3RV2321-1DC20	
4	1.5	Without	52	100 NEV		3RV2321-1EC10		В	3RV2321-1EC20	
5	1.5	Without	65	100 NEV		3RV2321-1FC10		В	3RV2321-1FC20	
6.3	2.2	Without	82	100 NEV		3RV2321-1GC10		В	3RV2321-1GC20	
8 10	3 4	Without Without	104 130	100 NEW		3RV2321-1HC10 3RV2321-1JC10		B B	3RV2321-1HC20 3RV2321-1JC20	
12.5	5.5	Without	163	100 NEW		3RV2321-13C10		В	3RV2321-13C20 3RV2321-1KC20	
16	7.5	Without	208	55	В	3RV2321-4AC10		В	3RV2321-4AC20	
20	7.5 7.5	Without	260	55	В	3RV2321-4AC10 3RV2321-4BC10		В	3RV2321-4AC20 3RV2321-4BC20	
22	11	Without	286	55	В	3RV2321-4DC10		В	3RV2321-4CC20	
25	11	Without	325	55	В	3RV2321-4DC10		В	3RV2321-4DC20	
28	15	Without	364	55	В	3RV2321-4NC10		В	3RV2321-4NC20	
32 <sup>3)</sup>	15	Without	400	55	В	3RV2321-4EC10		В	3RV2321-4EC20	
36 <sup>4)</sup>	18.5	Without	432	20	В	3RV2321-4PC10				
40 <sup>4)</sup>	18.5	Without	480	20	В	3RV2321-4FC10				

<sup>1)</sup> Guide value for 4-pole standard motors at 50 Hz 400 V AC. The actual starting and rated data of the motor to be protected must be considered when selecting the units.

Size S2, see page 7/27.

Auxiliary switches and other accessories can be ordered separately (see "Accessories" page 7/32 onwards).

<sup>2)</sup> For overload protection of the motors, appropriate overload relays must be used.


<sup>3)</sup> Suitable for use with IE3 motors up to a starting current of 256 A. For higher starting currents we recommend using 3RV2 motor starter protectors size S2.

<sup>4)</sup> The devices must not be mounted side-by-side and they must not be assembled with link modules with contactors. A lateral clearance of 9 mm is required. For use with IE3 motors we recommend using 3RV2 motor starter protectors size S2.

### **Motor Starter Protectors/Circuit Breakers** SIRIUS 3RV2 Motor Starter Protectors up to 80 A

For starter combinations

### Without auxiliary switches (continued)











331-4.C10	3RV2331-4WC10	3RV2332-4.C1

3B\/2	332-4	MC

Rated current	Suitable for three-phase motors <sup>1)</sup> with <i>P</i>	Thermal overload release <sup>2)</sup>	Instantaneous overcurrent release	Short-circuit breaking cap at 400 V AC	pacity	DT	Screw terminals	1	PU (UNIT, SET, M)	PS*	PG
$I_{n}$			<i>I</i> >	$I_{\mathrm{CU}}$			Article No.	Price per PU			
Α	kW	A	A	kA				perro			
Size S2											
14 17 20 25	5.5 7.5 7.5 11	Without Without Without Without	208 260 260 325	65 65 65 65	NEW NEW NEW	A A	3RV2331-4SC10 3RV2331-4TC10 3RV2331-4BC10 3RV2331-4DC10		1 1 1 1	1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E
32 36 40 45	15 18.5 18.5 22	Without Without Without Without	416 520 585 650	65 65 65 65	NEW NEW NEW	A A	3RV2331-4EC10 3RV2331-4PC10 3RV2331-4UC10 3RV2331-4VC10		1 1 1	1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E
52 59 <sup>3)</sup> 65 <sup>3)</sup> 73 <sup>3)</sup> 80 <sup>3)4)</sup>	22 30 30 37 37	Without Without Without Without Without	741 845 845 949 1 040	65 65 65 65 65	NEW NEW NEW NEW NEW	X X X	3RV2331-4WC10 3RV2331-4XC10 3RV2331-4JC10 3RV2331-4KC10 3RV2331-4RC10		1 1 1 1	1 unit 1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E 41E
Size S2, v	vith increased s	witching capacit	у								
14 17 20 25	5.5 7.5 7.5 11	Without Without Without Without	208 260 260 325	100 100 100 100	NEW NEW NEW	A A	3RV2332-4SC10 3RV2332-4TC10 3RV2332-4BC10 3RV2332-4DC10		1 1 1 1	1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E
32 36 40 45	15 18.5 18.5 22	Without Without Without Without	416 520 585 650	100 100 100 100	NEW NEW NEW	A A	3RV2332-4EC10 3RV2332-4PC10 3RV2332-4UC10 3RV2332-4VC10		1 1 1 1	1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E
52 59 <sup>3)</sup> 65 <sup>3)</sup> 73 <sup>3)</sup> 80 <sup>3)4)</sup>	22 30 30 37 37	Without Without Without Without Without	741 845 845 949 1 040	100 100 100 100 100	NEW NEW NEW NEW	X X X	3RV2332-4WC10 3RV2332-4XC10 3RV2332-4JC10 3RV2332-4KC10 3RV2332-4RC10		1 1 1 1	1 unit 1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E 41E

<sup>1)</sup> Guide value for 4-pole standard motors at 50 Hz 400 V AC. The actual starting and rated data of the motor to be protected must be considered when selecting the units.

Auxiliary switches and other accessories can be ordered separately (see "Accessories" page 7/32 onwards).

 $<sup>^{2)}\,</sup>$  For overload protection of the motors, appropriate overload relays must be

<sup>3)</sup> Start of delivery on request.

<sup>4)</sup> Suitable for use with IE3 motors up to a starting current of 720 A. For higher starting currents we recommend using 3RV1 motor starter protectors size S3.

SIRIUS 3RV2 Motor Starter Protectors up to 80 A


#### For transformer protection

### Selection and ordering data

### CLASS 10, without auxiliary switches

Motor starter protectors for the protection of transformers with high inrush current

 $\begin{array}{ll} PU \text{ (UNIT, SET, M)} &= 1 \\ PS^* &= 1 \text{ unit} \\ PG &= 41E \end{array}$ 



<sup>1)</sup> The setting range of the thermal overload releases has been extended.

Auxiliary switches and other accessories can be ordered separately (see "Accessories" page 7/32 onwards).

<sup>2)</sup> Start of delivery on request.


### Motor Starter Protectors/Circuit Breakers SIRIUS 3RV2 Circuit Breakers up to 80 A

For system protection according to UL 489/CSA C22.2 No. 5

### Selection and ordering data

### Without auxiliary switches

Circuit breakers for system protection and non-motor loads according to UL/CSA





3RV2711-0AD10

Rated current <sup>1)</sup>	Thermal overload releases (non-adjustable)	Instantaneous overcurrent release	Short-circuit breaking capacity at 480 Y/277 V AC <sup>2)</sup>	DT	Screw terminals	<b>(1)</b>	PU (UNIT, SET, M)	PS*	PG
$I_n^{(1)}$	G	[ >	$I_{ extsf{bc}}$		Article No.	Price			
Α	A	A	kA			per PU			
Size S00									
0.16 0.2 0.25 0.32	0.16 0.2 0.25 0.32	2.1 2.6 3.3 4.2	65 65 65 65	В В В	3RV2711-0AD10 3RV2711-0BD10 3RV2711-0CD10 3RV2711-0DD10		1 1 1 1	1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E
0.4 0.5 0.63 0.8	0.4 0.5 0.63 0.8	5.2 6.5 8.2 10	65 65 65 65	B B B	3RV2711-0ED10 3RV2711-0FD10 3RV2711-0GD10 3RV2711-0HD10		1 1 1 1	1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E
1 1.25 1.6 2	1 1.25 1.6 2	13 16 21 26	65 65 65 65	B B B	3RV2711-0JD10 3RV2711-0KD10 3RV2711-1AD10 3RV2711-1BD10		1 1 1 1	1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E
2.5 3.2 4 5	2.5 3.2 4 5	33 42 52 65	65 65 65 65	В В В В	3RV2711-1CD10 3RV2711-1DD10 3RV2711-1ED10 3RV2711-1FD10		1 1 1 1	1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E
6.3 8 10 12.5 15	6.3 8 10 12.5 15	82 104 130 163 208	65 65 65 65 65	B B B B	3RV2711-1GD10 3RV2711-1HD10 3RV2711-1JD10 3RV2711-1KD10 3RV2711-4AD10		1 1 1 1 1	1 unit 1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E 41E
Size S0 20 22	20 22	260 286		NEW B	3RV2721-4BD10 3RV2721-4CD10		1	1 unit 1 unit	41E 41E

 $<sup>^{1)}</sup>$  Rated value 100 % according to UL 489 and IEC 60947-2 ("100 % rated breaker").

Lateral and transverse auxiliary switches can be ordered separately (see "Accessories" from page 7/32 onwards).

 $<sup>^{2)}</sup>$  Values for 600 Y/347 V AC, see page 7/15.


SIRIUS 3RV2 Circuit Breakers up to 80 A

For transformer protection according to UL 489/CSA C22.2 No.5

### Selection and ordering data

### Without auxiliary switches

Circuit breakers for system and transformer protection according to UL/CSA, specially designed for transformers with high inrush current





3RV2811-0AD10

Rated current <sup>1)</sup>	Thermal overload releases (non-adjustable)	Instantaneous overcurrent release	Short-circuit breaking capacity at 480 Y/277 V AC <sup>2)</sup>	DT	Screw terminals	<b></b>	PU (UNIT, SET, M)	PS*	PG
$I_n^{(1)}$	4	<i>I</i> >	$I_{ m bc}$		Article No.	Price per PU			
Α	Α	Α	kA						
Size S00									
0.16 0.2 0.25 0.32	0.16 0.2 0.25 0.32	3.3 4.2 5.2 6.5	65 65 65 65	B B B	3RV2811-0AD10 3RV2811-0BD10 3RV2811-0CD10 3RV2811-0DD10		1 1 1 1	1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E
0.4 0.5 0.63 0.8	0.4 0.5 0.63 0.8	8.2 10 13 16	65 65 65 65	B B B	3RV2811-0ED10 3RV2811-0FD10 3RV2811-0GD10 3RV2811-0HD10		1 1 1 1	1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E
1 1.25 1.6 2	1 1.25 1.6 2	21 26 33 42	65 65 65 65	B B B	3RV2811-0JD10 3RV2811-0KD10 3RV2811-1AD10 3RV2811-1BD10		1 1 1 1	1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E
2.5 3.2 4 5	2.5 3.2 4 5	52 65 82 104	65 65 65 65	B B B	3RV2811-1CD10 3RV2811-1DD10 3RV2811-1ED10 3RV2811-1FD10		1 1 1 1	1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E
6.3 8 10 12.5 15	6.3 8 10 12.5 15	130 163 208 260 286	65 65 65 65 65	B B B B	3RV2811-1GD10 3RV2811-1HD10 3RV2811-1JD10 3RV2811-1KD10 3RV2811-4AD10		1 1 1 1 1	1 unit 1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E 41E
Size S0 20 22	20 22	325 364		VEW B	3RV2821-4BD10 3RV2821-4CD10		1	1 unit 1 unit	41E 41E

<sup>1)</sup> Rated value 100 % according to UL 489 and IEC 60947-2 ("100 % rated breaker").

Lateral and transverse auxiliary switches can be ordered separately (see "Accessories" from page 7/32 onwards).

<sup>&</sup>lt;sup>2)</sup> Values for 600 Y/347 V AC, see page 7/15.

Tel. +375 44 592 00 86 https://www.abn.by Tel. +375 33 366 51 85

info@abn.by otectors/Circuit Breakers

### SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A Accessories

Mountable accessories

### Overview

#### Mounting location and function

The 3RV2 motor starter protectors/circuit breakers have three

These components are easily fitted to the switches without the

main contact elements. In order to achie auxiliary switches, signaling switches, a isolator modules can be supplied separ	uxiliary releases and	use of any tools according to requirements.  Overview graphic, see page 7/7.						
	,							
Front side     Note:     A maximum of four auxiliary contacts with auxiliary switches can be mounted on each motor starter protector/circuit breaker.	Transverse auxiliary switches, solid-state compatible transverse auxiliary switches 1 NO + 1 NC or 2 NO or 1 CO	An auxiliary switch block can be inserted transversely on the front. The overall width of the motor starter protectors/circuit breakers remains unchanged.						
Left-hand side     Notes:     A maximum of four auxiliary contacts with auxiliary switches can be mounted on each motor starter protector/circuit breaker.     Lateral auxiliary switches (two contacts) and signaling switches can be mounted	Lateral auxiliary switches (2 contacts) 1 NO + 1 NC or 2 NO or 2 NC	One of the three lateral auxiliary switches can be mounted on the left side per motor starter protector/circuit breaker. The contacts of the auxiliary switch close and open together with the main contacts of the motor starter protector/circuit breaker.  The width of the lateral auxiliary switch with two contacts is 9 mm.						
separately or together.  The signaling switch cannot be used for the 3RV27 and 3RV28 circuit breakers.	Lateral auxiliary switches (4 contacts) 2 NO + 2 NC	One lateral auxiliary switch with four contacts can be mounted on the left side per motor starter protector/circuit breaker. The contacts of the auxiliary switch close and open together with the main contacts of the motor starter protector/circuit breaker.						
		The width of the lateral auxiliary switch with four contacts is 18 mm.						
	Signaling switches Tripping 1 NO + 1 NC	One signaling switch can be mounted on the left side of each motor starter protector.						
	Short circuit 1 NO + 1 NC	The signaling switch has two contact systems.						
		One contact system always signals <u>tripping</u> irrespective of whether this was caused by a short circuit, an overload or an auxiliary release. The other contact system only switches in the event of a short circuit. There is no signaling as a result of <u>switching off</u> with the actuator.						
		In order to be able to switch on the motor starter protector again after a short circuit, the signaling switch must be reset manually after the error cause has been eliminated.						
		The overall width of the signaling switch is 18 mm.						

Right-hand side  Notes: One auxiliary release can be mounted per motor starter protector/circuit breaker.  Shunt releases For remote-controlled tripping of the motor starter protector/circuit breaker. The release coil should only be energized for short periods (see circuit diagrams).			The everal main of the eighaning evitor is to mini
<ul> <li>One auxiliary release can be mounted per motor starter protector/circuit breaker.</li> <li>The release coil should only be energized for short periods (see circuit diagrams).</li> </ul>	Right-hand side	Auxiliary releases	
	<ul> <li>One auxiliary release can be mounted per</li> </ul>	Shunt releases	The release coil should only be energized for short periods (see circuit

Accessories cannot be mounted at the right-hand side of the 3RV21 motor starter protectors for motor protection with overload relay function

Undervoltage releases	Trips the motor starter protector/circuit breaker when the voltage is inter- rupted and prevents the motor from being restarted accidentally when the voltage is restored. Used for remote-controlled tripping of the motor starter protector/circuit breaker.
	Particularly suitable for EMERGENCY-STOP disconnection by way of corresponding EMERGENCY-STOP pushbuttons according to DIN EN 60204-1.

Undervoltage releases with leading auxiliary contacts 2 NO

Function and use as for the undervoltage release without leading auxiliary contacts, but with the following additional function: the auxiliary contacts will open in switch position OFF to deenergize the coil of the undervoltage release, thus interrupting energy consumption. In the "tripped" position, these auxiliary contacts are not guaranteed to open. The leading contacts permit the motor starter protector/circuit breaker to reclose.

The overall width of the auxiliary release is 18 mm

### Тор

#### Notes:

- The isolator module cannot be used for the 3RV27 and 3RV28 circuit breakers.
- The isolator module for size S2
- can only be used with 3RV2 motor starter protectors/circuit breakers up to max. 65 A
- cannot be used with the transverse auxiliary switch
- The isolator module covers the terminal screws of the transverse auxiliary switch. If the isolator module is used, we therefore recommend that either the lateral auxiliary switches be fitted or that the isolator module not be mounted until

#### Isolator modules

Isolator modules can be mounted to the upper connection side of the motor starter protectors

The supply cable is connected to the motor starter protector through the isolator módule.

The plug can only be unplugged when the motor starter protector is open and isolates all 3 poles of the motor starter protector from the network. The shock-protected isolation point is clearly visible and secured with a padlock to prevent reinsertion of the plug.

the auxiliary switch has been wired.

For a complete overview of which accessories can be used for the various motor starter protectors/circuit breakers, see page 7/2.

# SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A Accessories

### Mountable accessories

### Selection and ordering data

PU (UNIT, SET, M) = 1

PS\* = 1 unit (unless otherwise specified)

PG = 41E

PG	= 41E								
		Version	For motor starter protectors/ circuit breakers	DT	Screw terminals	<b>+</b>	DT	Spring-type terminals	
			Size		Article No.	Price per PU		Article No.	Price per PU
Auxiliary sw	vitches <sup>1)</sup>								
		Transverse auxiliary switcher For front mounting	es						
3RV2901-1E		1 CO 1 NO + 1 NC <sup>2)</sup>	S00 S2	<b>&gt;</b>	3RV2901-1D 3RV2901-1E		<b>&gt;</b>	 3RV2901-2E	
3RV2901-1E		2 NO		<b></b>	3RV2901-1F		<b>&gt;</b>	3RV2901-2F	
2000 000	1	Electronic compatible transverse auxiliary switches							
3RV2901-2E		Mountable on the front, for operation in dusty							
6 6 6		atmosphere and in electronic circuits with low operating currents							
3RV2901-1G		1 CO	S00 S2	Α	3RV2901-1G				
	<b>*</b>	Covers for transverse auxiliary switches (PKG* = 10 units)	S00 S2	•	3RV2901-0H				
3RV2901-0H									
4	-	Lateral auxiliary switches Mountable on the left							
		1 NO + 1 NC <sup>2)</sup> 2 NO 2 NO 2 NC 2 NO + 2 NC	S00 S2	A	3RV2901-1A 3RV2901-1B 3RV2901-1C 3RV2901-1J		<b>A A</b>	3RV2901-2A 3RV2901-2B 3RV2901-2C 	
3RV2901-1A	3RV2901-2A								
Signaling sv	witches <sup>3)</sup>								
		Signaling switches <sup>2)</sup> One signaling switch can be mounted on the left per motor starter protector. Separate tripped and short-circuit alarms, 1 NO + 1 NC each	S00 S2	•	3RV2921-1M		•	3RV2921-2M	
3RV2921-1M	3RV2921-2M								
Isolator mod	aures"	Isolator modules <sup>4)</sup>	200 20		3D\/2028.4A			_	
		Visible isolating distance for isolating individual motor starter protectors from the network, lockable in disconnected position	\$00, \$0 \$2 <sup>4</sup> ) <b>N</b> E	<b>№</b> A	3RV2928-1A 3RV2938-1A			_	
3RV2928-1A	3RV2938-1A								

- 1) Each motor starter protector/circuit breaker can be fitted with one transverse and one lateral auxiliary switch. The lateral auxiliary switch with 2 NO + 2 NC is used without a transverse auxiliary switch.
- 2) The 3RV29 auxiliary and signaling switches with 1 NO + 1 NC are also available with ring terminal lug connection. The Article No. must be changed in the 8th digit to "4": e.g. 3RV2901-4E.
- 3) This accessory cannot be used for the 3RV27 and 3RV28 circuit breakers.
- 4) The isolator module for size S2 can be used only with 3RV2 motor starter protectors/circuit breakers up to max. 65 A. Similarly, it cannot be used with the transverse auxiliary switch.

### otectors/Circuit Breakers

### SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A Accessories

Mountable accessories

PU (UNIT, SET, M) = 1 PS\* = 1 unit PG = 41E









3RV2902-1AV0

3RV2902-2AV0

3RV2922-1CP0

3RV2902-2DB0

0111200	_ 17.40		01172302 27170		OHVZ	022 1	01 0	01112	202 2		
Rated co AC 50 Hz	AC 60 Hz	oly voltage $U_{\rm S}$ AC 50/60 Hz 100 % ON period 1	AC/DC 50/60 Hz, DC 5 s ON period <sup>2)</sup>	DC	For motor starter protectors/ circuit breakers	DT	Screw terminals	<b>+</b>	DT	Spring-type terminals	
V	V	V	V	V	Size		Article No.	Price per PU		Article No.	Price per PU
Auxilia	ry releas	ses <sup>3)</sup>									
Undervo	oltage rele	eases									
 24 110	 120 208	  	  	24  	S00 S2 S00 S2 S00 S2 S00 S2	A A A	3RV2902-1AB4 3RV2902-1AB0 3RV2902-1AF0 3RV2902-1AM1			  	
230 400 415 500	240 440 480 600	  	  	  	S00 S2 4) S00 S2 4) S00 S2 S00 S2		3RV2902-1AP0 3RV2902-1AV0 3RV2902-1AV1 3RV2902-1AS0		<b>&gt;</b>	3RV2902-2AP0 3RV2902-2AV0 	
	oltage rele y contacts	eases with leading s 2 NO									
24 230 400 415	24 240 440 480	  	  	  	S00 S2 S00 S2 S00 S2 S00 S2 4)	B A A	3RV2922-1CB0 3RV2922-1CP0 3RV2922-1CV0 3RV2922-1CV1		A A A	3RV2922-2CP0 3RV2922-2CV0 3RV2922-2CV1	
Shunt re	eleases										
  	   	20 24 90 110 210 240 350 415 500	20 70 70 190 190 330 330 500 500	   	\$00 \$2 \$00 \$2 4) \$00 \$2 4) \$00 \$2 \$00 \$2	A A A	3RV2902-1DB0 3RV2902-1DF0 3RV2902-1DP0 3RV2902-1DV0 3RV2902-1DS0		A	3RV2902-2DB0 3RV2902-2DF0 3RV2902-2DP0 	

<sup>1)</sup> The voltage range is valid for 100 % (infinite) ON period. The response voltage lies at 0.9 of the lower limit of the voltage range.

<sup>2)</sup> The voltage range is valid for 5 s ON period at AC 50/60Hz and DC. The response voltage lies at 0.85 of the lower limit of the voltage range.

<sup>&</sup>lt;sup>3)</sup> One auxiliary release can be mounted on the right per motor starter protector/circuit breaker (does not apply to 3RV21 motor starter protectors with overload relay function).

<sup>4)</sup> The 3RV29 auxiliary releases are also available with ring terminal lug connection. The Article No. must be changed in the 8th digit to "4": e.g. 3RV2902-4AP0.

SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A Accessories

**Busbar accessories** 

#### Overview


### Insulated three-phase busbar system

Three-phase busbar systems provide an easy, time-saving and clearly arranged means of feeding 3RV2 motor starter protector/circuit breakers with screw terminals. Different versions are available for sizes S00 to S2 and can be used for the various different types of motor starter protectors/circuit breakers (size S0 up to 32 A).


The 3RV1915 and 3RV1935 three-phase busbar systems are generally unsuitable for the 3RV21 motor starter protectors for motor protection with overload relay function and 3RV27 and 3RV28 circuit breakers according to UL 489/CSA C22.2 No. 5.

The busbars are suitable for between two and five motor starter protectors/circuit breakers. However, any kind of extension is possible by clamping the tags of an additional busbar (rotated by 180°) underneath the terminals of the respective last motor starter protector/circuit breaker.

A combination of motor starter protectors/circuit breakers of size S00 and S0 is possible. The motor starter protectors/circuit breakers are supplied by appropriate infeed terminals.



SIRIUS three-phase busbar system size S00/S0



SIRIUS three-phase busbar system size S2

The three-phase busbar systems are finger-safe. They are designed for any short-circuit stress which can occur at the output side of connected motor starter protectors/circuit breakers.

The three-phase busbar systems can also be used to construct "Type E Starters" according to UL/CSA. Special infeed terminals must be used for this purpose, however (see "Selection and Ordering Data", page 7/35).


#### 8US busbar adapters for 60 mm systems

The motor starter protectors/circuit breakers are mounted directly with the aid of busbar adapters on busbar systems with 60 mm center-to-center clearance in order to save space and to reduce infeed times and costs.

The busbar adapters for busbar systems with 60 mm center-tocenter clearance are suitable for copper busbars with a width of 12 mm to 30 mm. The busbars can be 5 mm or 10 mm thick.

The motor starter protectors/circuit breakers are snapped onto the adapter and connected on the line side. This prepared unit is then plugged directly onto the busbar system, and is thus connected both mechanically and electrically at the same time.

For further busbar adapters for snap-mounting direct-on-line starters and reversing starters as well as additional accessories such as line terminals and outgoing terminals, flat copper profile, etc., see Catalog LV 10 "Low-Voltage Power Distribution and Electrical Installation Technology".



SIRIUS load feeders with busbar adapters snapped onto busbars



Tel.:+375 17 310 44 44 Tel. +375 33 366 51 85 info@abn.by

ЭйБиЭн

### otectors/Circuit Breakers

### SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A Accessories

**Busbar accessories** 

### Selection and ordering data

	Modular spacing		of motor starte can be conne		Rated current In		DT	Article No.	Price per PU	PU (UNIT,	PS*	PG
		Without lateral accessories	With lateral auxiliary switch	With auxiliary release	at 690 V	protectors				SET, M)		
	mm				Α	Size						
Three-phase bu	sbars <sup>1)</sup>											
ANA ANA	mounted		motor starter de on standai n									
3RV1915-1AB	45 <sup>3)</sup>	2			63	S00, S0 <sup>2)</sup>	<b>&gt;</b>	3RV1915-1AB		1	1 unit	41E
NO.		3 4 5			63 63	S00, S0 <sup>2)</sup> S00, S0 <sup>2)</sup>	<b>&gt;</b>	3RV1915-1BB 3RV1915-1CB		1	1 unit 1 unit	41E 41E
000 HO4E 400	55 <sup>4)</sup>				63	S00, S0 <sup>2)</sup>	<b>&gt;</b>	3RV1915-1DB			1 unit	41E
3RV1915-1BB	55.7		2		63 63	S00, S0 <sup>2)</sup> S00, S0 <sup>2)</sup>	<b>&gt;</b>	3RV1915-2AB 3RV1915-2BB		1	1 unit 1 unit	41E 41E
AAAA REE			4 5		63 63	S00, S0 <sup>2)</sup> S00, S0 <sup>2)</sup>	<b>&gt;</b>	3RV1915-2CB 3RV1915-2DB		i 1	1 unit 1 unit	41E 41E
3RV1915-1CB	1	2			108 108	S2 S2	<b>&gt;</b>	3RV1935-1A 3RV1935-1B		1 1	1 unit 1 unit	41E 41E
Charles and the		4			108	S2	<b></b>	3RV1935-1C		1	1 unit	41E
AMARARA BARARA BARARA	63 <sup>5)</sup>			2	63 63	S00, S0 <sup>2)</sup> S00, S0 <sup>2)</sup>	<b>&gt;</b>	3RV1915-3AB 3RV1915-3CB		1 1	1 unit 1 unit	41E 41E
3RV1915-1DB	75 <sup>5)</sup>		2	2	108	S2	<b></b>	3RV1935-3A		1	1 unit	41E
			3	3	108	S2	<b>&gt;</b>	3RV1935-3B		1	1 unit	41E
			4	4	108	S2	<b>&gt;</b>	3RV1935-3C		1	1 unit	41E

- Not suitable for 3RV21 motor starter protectors for motor protection with overload relay function and for 3RV27 and 3RV28 circuit breakers according to UL 489/CSA C22.2 No. 5.
- <sup>2)</sup> Approved for motor starter protectors size S0 with  $I_{\rm n} \leq$  32 A.
- 3) For 3RV2 motor starter protectors without accessories mounted on the side.
- 4) For 3RV2 motor starter protectors with auxiliary switches with 1 NO + 1 NC, 2 NO and 2 NC mounted on the left (9 mm wide).
- 5) For 3RV2 motor starter protectors with mounted accessories (18 mm wide). Auxiliary switches with 2 NO + 2 NC or signaling switch (mounted on the left) or with auxiliary release (mounted on the right).

	Conductor o	ross-section		Tightening	For motor	DT	Article No.	Price	PU	PS*	PG
	Solid or stranded	Finely stranded with end sleeve	AWG cables, solid or stranded	torque	starter protectors/ circuit breakers			per PU	(UNIT, SET, M)		
	mm²	mm²	AWG	Nm	Size						
Three-phase infee	d terminals										
889	Connection	from top									
000	2.5 25	2.5 16	10 4	3 4	S00, S0	<b>&gt;</b>	3RV2925-5AB		1	1 unit	41E
HINE	2 x	2 x (2.5 35) <sup>1)</sup> ,	2 x	4 6	S2 NEW	Α	3RV2935-5A		1	1 unit	41E
3RV2925-5AB	1 x	1 x	1 x								
to division	(2.5 70) <sup>1)</sup>	(2.5 50) <sup>1)</sup>	(10 2/0) <sup>1)</sup>								
A STATE OF THE STA											
900											
3RV2935-5A											
		from below									
		l is connected rement into ac	in place of a s count.	witch, please	e take the						
	2.5 25	2.5 16	10 4	Input: 4,	S00, S0	<b>&gt;</b>	3RV2915-5B		1	1 unit	41E
A				Output: 2 2.5							
3RV2915-5B											
Three-phase infee	d terminals	for constru	cting "Type	E Starters'	"						
	Connection	from top									
A STATE OF THE PARTY OF THE PAR	2.5 25	2.5 16	10 4	3 4	S00, S0	Α	3RV2925-5EB		1	1 unit	41E
المامام	2 x	2 x (2.5 35) <sup>1)</sup> ,	2 x	4 6	S2 <b>NEW</b>	Α	3RV2935-5E		1	1 unit	41E
יי ה ה	1 x	1 x	1 x								
3RV2925-5EB	(2.5 70) <sup>1)</sup>	(2.5 50) <sup>1)</sup>	(10 2/0) <sup>1)</sup>								

<sup>3</sup>RV2935-5E

<sup>1)</sup> If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.

<sup>\*</sup> You can order this quantity or a multiple thereof. Illustrations are approximate

# SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A Accessories

### **Busbar accessories**

	Version	For motor starter protectors/ circuit breakers	DT	Article No.	Price er PU	PU (UNIT, SET, M)	PS*	PG
		Size						
Covers for connec	tion tags							
State of the last	Touch protection for empty positions	S00, S0	<b>&gt;</b>	3RV1915-6AB		1	10 units	41E
3RV1915-6AB		S2	<b>&gt;</b>	3RV1935-6A		1	5 units	41E

#### Busbar adapters









8US1251-5DS10

8US1251-5DT11

8US1250-5AS10

8US1250-5AT10

For motor starter protectors/ circuit breakers	Rated current	Connecting cable	Adapter length	Adapter width	Rated volta	age	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
Size	А	AWG	mm	mm	V							
Busbar adapters f	or 60 mm sy	stems										
For flat copper profiles Width: 12 mm and 30 Thickness: 5 mm and also for T and double-	mm 10 mm											
For motor starter pro	tectors/circuit b	oreakers with	screw term	inals				Screw terminals	<b>+</b>			
S00, S0	25	12	200	45	690		<b></b>	8US1251-5DS10		1	1 unit	140
S0	32	10	260	45	690		<b></b>	8US1251-5NT10		1	1 unit	140
S2	80	4	200	55	690	VEW.	Α	8US1261-5MS13		1	1 unit	140
S2	80	4	260	55	690	VEW	Α	8US1261-6MT10		1	1 unit	140
S2 <sup>1)</sup>	80	4	260	118	690 <b>N</b>	VEW	Α	8US1211-6MT10		1	1 unit	140
For motor starter pro	tectors/circuit b	oreakers with	spring-type	terminals				Spring-type terminals				
S00, S0	25	12	200	45	690		<b></b>	8US1251-5DS11		1	1 unit	140
S00, S0	25	12	260	45	690		<b></b>	8US1251-5DT11		1	1 unit	140
S0	32	10	260	45	690		<b></b>	8US1251-5NT11		1	1 unit	140
Accessories												
Device holders			200	45			<b></b>	8US1250-5AS10		1	1 unit	140
For lateral mounting to busbar adapters			260	45			<b></b>	8US1250-5AT10		1	1 unit	140
Side modules For widening of busbar adapters			200	9			A	8US1998-2BJ10		1	10 units	140
Spacers For fixing the load feeder onto the busbar adapter							<b>&gt;</b>	8US1998-1BA10		1	50 units	140
Vibration and shock kits For high vibration and shock loads												
S00/S0							<b></b>	8US1998-1CA10		1	2 units	140
S2					1	VEW	Α	8US1998-1DA10	20.40	1	1 unit	140

<sup>1)</sup> For the assembly of feeders for reversing starters comprising a motor starter protector and two contactors.

For additional busbar adapters, see Catalog LV 10 "Low-Voltage Power Distribution and Electrical Installation Technology".

## otectors/Circuit Breakers


## SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A Accessories

Rotary operating mechanisms

#### Overview

#### Door-coupling rotary operating mechanisms

Motor starter protectors/circuit breakers with a rotary operating mechanism can be mounted in a control cabinet and operated externally by means of a door-coupling rotary operating mechanism. When the cabinet door with motor starter protector/circuit breaker is closed, the operating mechanism is coupled. When the motor starter protector/circuit breaker closes, the coupling is locked which prevents the door from being opened unintentionally. This interlock can be defeated by the maintenance personnel. In the OPEN position, the rotary operating mechanism can be secured against reclosing with up to three padlocks. Inadvertent opening of the door is not possible in this case either.



NEW ICON CONCORD days and line states and basiness favor

SIRIUS 3RV2926-2B door-coupling rotary operating mechanisms for arduous conditions

SIRIUS 3RV2926-0K door-coupling rotary operating mechanism

#### Selection and ordering data

Version	Color of handle	Version of extension shaft	For motor starter protectors/ circuit breakers	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
		mm	Size						

## Door-coupling rotary operating mechanisms



Ťł

The door-coupling rotary operating mechanisms consist of a knob, a coupling driver and a 130/330 mm long extension shaft (6 mm x 6 mm).

The door-coupling rotary operating mechanisms are designed to degree of protection IP64. The door locking device prevents accidental opening of the control cabinet door in the ON position of the motor starter protector/circuit breaker. The OFF position can be locked with up to three padlocks.

Door-coupling rotary operating mechanisms	Black	130 330	\$00 \$2 \$00 \$2	•	3RV2926-0B 3RV2926-0K	1 1	1 unit 1 unit	–
EMERGENCY-STOP door-coupling rotary operating mechanisms	Red/yellow	130 330	S00 S2 S00 S2	•	3RV2926-0C 3RV2926-0L	1 1	1 unit 1 unit	–

#### Door-coupling rotary operating mechanisms for arduous conditions



The door-coupling rotary operating mechanisms consist of a knob, a coupling driver, an extension shaft of 300 mm in length (8 mm x 8 mm), a spacer and two metal brackets, into which the motor starter protector/circuit breaker is inserted.

The door-coupling rotary operating mechanisms are designed to degree of protection IP65. The door interlocking reliably prevents opening of the control cabinet door in the ON position of the motor starter protector/circuit breaker. The OFF position can be locked with up to three padlocks.

Laterally mountable auxiliary releases and two-pole auxiliary switches can be used.

The door-coupling rotary operating mechanisms thus meet the requirements for isolating functions according to IEC 60947-2.

2926-2B	Door-coupling rotary operating mechanisms	Gray	300	S00, S0 S2	NEW	<b>&gt;</b>	3RV2926-2B 3RV2936-2B	1 1	1 unit 1 unit	
	EMERGENCY STOP door-coupling rotary operating mechanisms	Red/yellow	300	S00, S0 S2	NEW	<b>&gt;</b>	3RV2926-2C 3RV2936-2C	1		



3RV29

SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A Accessories


#### **Mounting accessories**

#### Overview


#### Accessories for "Self-Protected Combination Motor Controllers (Type E)" according to UL 508/UL 60947-4-1

The 3RV20 motor starter protectors with screw terminals are approved according to UL 508/UL 60947-4-1 as "Self-Protected Combination Motor Controllers (Type E)".

This requires increased clearance and creepage distances (1 inch and 2 inches respectively) at the input side of the device, which are achieved by mounting a terminal block or a phase barrier.



SIRIUS 3RV2928-1H terminal block



SIRIUS 3RV2938-1K phase barrier

Motor starter protectors/ circuit breakers	Size	Essential accessories for "Self-Protected Combination Motor Controllers (Type E)" according to UL 508/UL 60947-4-1
3RV201., 3RV202.	S00/S0	3RV2928-1H terminal block or 3RV2928-1K phase barrier
3RV2031-4B1., 3RV2031-4D.1., 3RV2031-4E1., 3RV2031-4P.1., 3RV2031-4S.1., 3RV2031-4T.1., 3RV2031-4U.1., 3RV2031-4V.1.	\$2	_
3RV2031-4J.1., 3RV2031-4K.1., 3RV2031-4R.1., 3RV2031-4W.1., 3RV2031-4X.1., 3RV2032	S2	3RV2938-1K phase barrier

-- No accessories needed

Special three-phase infeed terminals are required for constructing "Type E Starters" with an insulated three-phase busbar system (see "Busbar Accessories", page 7/35).

The 3RV29 infeed system also enables the assembly of "Type E Starters", see page 7/46 onwards.

#### Note:

According to CSA, these terminal blocks and the phase barriers can be omitted when the device is used as a "Self-Protected Combination Motor Controller (Type E)".

#### Link modules

Feeders can be easily assembled from single devices with the help of the link modules. The following table shows the different combination options for devices with screw or spring-type terminals.

Combination devices	3RV2 motor starter protec- tors/ circuit breakers Size	3RT2 contactors; 3RW30, 3RW40 soft starters; 3RF34 solid-state contactors	Link modules Screw terminals	Spring-type terminals
Link modules	00	cting switching dev	vices to 3DV2 n	notor startor
protectors/circ	cuit breake	ers <sup>1)</sup>	vices to sitve ii	notor starter
3RT2 contactors with AC or	S00	S00	3RA1921- 1DA00	3RA2911- 2AA00
DC coil	S0	S00		
	S2	S2	3RA2931- 1AA00	
3RT2 contactors with	S0	S0	3RA2921- 1AA00	3RA2921- 2AA00
AC coil	S00	S0	_	
3RT2 contactors with	S0	S0	3RA2921- 1BA00	3RA2921- 2AA00
DC coil	S00	1BA00 2AA00 S0 S00 3RA2921- 3RA29		
3RW30 soft starters	S00	S00	3RA2921- 1BA00	3RA2911- 2GA00
	S0	S00	_	
3RW30/ 3RW40	S0	S0	3RA2921- 1BA00	3RA2921- 2GA00
soft starters	S00	S0	_	
	S2 <sup>2)</sup>	S2 <sup>2)</sup>	3RA2931- 1AA00	
3RF34 solid- state contac- tors	S00/S0	S00	3RA2921- 1BA00	
	RV2 motor	connecting contact starter protectors.		
3RT2 contactors with AC or	S00	S00	3RA2911- 2FA00	
DC coil	S0	S0	3RA2921- 2FA00	

- -- Version not possible
- The link modules cannot be used for the 3RV2.21-4PA1., 3RV2.21-4FA1., 3RV2.31-4K.1., 3RV2.31-4R.1., 3RV2.32-4K.1., 3RV2.32-4R.1., 3RV27 and 3RV28 motor starter protectors/circuit breakers.
- 2) To assemble the feeder between a motor starter protector and a soft starter in size S2, the 3RA2932-1AC00 standard mounting rail adapter must be used
- 3) The motor starter protector to contactor hybrid link modules cannot be used for the 3RV2.21-4PA1., 3RV2.21-4FA1., 3RV27 and 3RV28 motor starter protectors/circuit breakers. They are only suitable for constructing direct-on-line starters.

#### Note:

- Link modules can be used in
  - Sizes S00 and S0: up to max. 32 A
  - Size S2: up to max. 65 A
- Hybrid link modules can be used in
  - Sizes S00 and S0: up to max. 32 A

## info@abn.by

## SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A Accessories

Mounting accessories

## Selection and ordering data

#### Accessories

	Version	For motor sta protectors/ circuit breake		DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
		Size							
Covers									
3RV2908-0P	Scale covers Sealable, for covering the set current scale	3RV20, 3RV2 3RV24: S00 S2	21,	<b>&gt;</b>	3RV2908-0P		100	10 units	41E
	Covers for devices with screw terminals (box terminals) Additional touch protection for fastening to the box terminals (2 units required per device)				Screw terminals	1			
3RT2936-4EA2	Main current level	S2	NEW	В	3RT2936-4EA2		1	1 unit	41B
	Covers for devices with ring terminal lug connection (ensure finger-safety)				Ring terminal lug connections	<b>(</b>			
Name of Street, or other Designation of the least of the	Main current level	3RV20:		В	3RV2928-4AA00		1	1 unit	41E
3RV2928-4AA00	<ul> <li>For transverse auxiliary switches</li> </ul>	S00, S0		В	3RV2908-4AA10		1	1 unit	41E
0000	•								
3RV2908-4AA10									
Fixing accessories	S								
	Push-in lugs For screwing the motor starter protector/ circuit breakers onto mounting plates For each motor starter protector/circuit	S00, S0		Α	3RV2928-0B		100	10 units	41E
3RV2928-0B	breakers, two units are required.								
Tools for opening	spring-type terminals								
	Screwdrivers For all SIRIUS devices with spring-type te	rminals			Spring-type terminals				
3RA2908-1A	Length approx. 200 mm, 3.0 mm x 0.5 mm, titanium gray/black, partially insulated	S00 S2		Α	3RA2908-1A		1	1 unit	41B

# Terminal blocks and phase barriers for "Self-Protected Combination Motor Controllers (Type E)" according to UL 508/UL 60947-4-1



UL 508/UL 60947-4-1 approval demands 1-inch clearance and 2-inch creepage distance for "Self-Protected Combination Motor Controllers (Type E)". The following terminal blocks or phase barriers must be used for the 3RV20 motor starter protectors with screw terminals. The construction of 3RV20 motor starter protectors with spring-type terminals with the 3RV29 infeed system is also approved as "Self-Protected Combination Motor Controllers (Type E)" according to UL 508/UL 60947-4-1.

The terminal block or phase barriers cannot be used in combination with the 3RV19.5 three-phase busbars.

For construction with three-phase busbars, see "Busbar Accessories" page 7/34 onwards.





Tor conditaction with three phace backar	0,000 2000	a. / 1000000110	o pago 170 i onimarao.			
Terminal blocks type E For extended clearance and creepage distances (1 and 2 inch)	S00, S0	•	3RV2928-1H	1	1 unit	41E
Phase barriers For extended clearance and creepage distances (1 and 2 inch)	S00, S0 S2	NEW A	3RV2928-1K 3RV2938-1K	1	1 unit 1 unit	41E 41E

## SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A Accessories

For mechanical and electrical connection between motor

S00/S0 S00/S0

S00/S0

S00/S0

S00/S0

S00/S0

S2

S2

starter protector and contactor with screw terminals

S0 S2

Multi-unit packaging

AC/DC

AC/DC

AC DC AC/DC

#### **Mounting accessories**

#### Link modules

Actuating voltage of contactor	Size		DT	Article No.	Price per PU	PU (UNIT.	PS*	PG
Contactor	3RT2 contactors	3RV2 motor starter protectors/ circuit breakers			per FO	SET, M)		

 $\triangleright$ 

Α

Α

Α

NEW A

**NEW** A

Screw terminals

3RA1921-1DA00

3RA2921-1AA00 3RA2921-1BA00

3RA2931-1AA00

3RA1921-1D

3RA2921-1A

3RA2921-1B

3RA2931-1A

(<del>1</del>)

1 unit

1 unit

1 unit

1 unit

10 units

10 units

10 units

5 units

41B

41B

41B

41B

41B

41B

41B

41B

Link modules for me	otor starter prot	tector to contac	ctor <sup>1)</sup>
14-14		and electrical con r and contactor wit	
	Single-unit pad	kaging	
	AC/DC	S00	S
and the second second	AC	S0	S
111	DC	S0	S

3RA2921-1AA00



3RA2931-1AA00





3RA2911-1CA00

#### Note:

Link modules can be used in

- Sizes S00 and S0 up to max. 32 A
- Size S2 up to max. 65 A

For mechanical and el starter protector and c				Spring-type terminals	$\stackrel{\infty}{\mathbb{L}}$			
Single-unit packaging	g							
AC/DC AC <sup>2)</sup> DC	\$00 \$0 \$0	S00 S0 S0	<b>&gt; &gt;</b>	3RA2911-2AA00 3RA2921-2AA00 3RA2921-2AA00		1 1 1	1 unit 1 unit 1 unit	41B 41B 41B
Multi-unit packaging								
AC/DC AC <sup>2)</sup> DC	S00 S0 S0	S00 S0 S0	<b>&gt; &gt;</b>	3RA2911-2A 3RA2921-2A 3RA2921-2A		1 1 1	10 units 10 units 10 units	41B 41B 41B
Spacers <sup>2)</sup>								
For compensating the	height on AC	contactors						
Single-unit packaging Multi-unit packaging	S0 S0	S0 S0	A A	3RA2911-1CA00 3RA2911-1C		1	1 unit 5 units	41B 41B

The link modules from motor starter protector to contactor cannot be used for the 3RV2.21-4PA1., 3RV2.21-4FA1., 3RV2.31-4K.1., 3RV2.31-4R.1., 3RV2.32-4K.1., 3RV2.32-4R.1., 3RV27 and 3RV28 motor starter protectors/ circuit breakers.

 $<sup>^{2)}\,</sup>$  A spacer for height compensation on AC contactors size S0 is optionally

## otectors/Circuit Breakers

## SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A Accessories

info@abn.by

#### **Mounting accessories**

	Size 3RW30, 3RW40 soft starters;	3RV2 motor starter	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
	3RF34 solid-state contactors	protectors/circuit breakers				02.,,		
		1)						
	motor starter protector to so tector to solid-state contactor							
Madel	Connection between motor starte solid-state contactor with screw t			Screw terminals	<b>(1)</b>			
	Single-unit packaging							
THE REAL PROPERTY AND ADDRESS OF THE PARTY AND	\$00	S00/S0	Α	3RA2921-1BA00		1	1 unit	41B
A STATE OF THE PARTY OF THE PAR	S0 S2 <sup>2)</sup>	\$00/\$0 \$2 <b>NEV</b>	Α Δ	3RA2921-1BA00 3RA2931-1AA00		1	1 unit 1 unit	41B 41B
3RA2921-1BA00	Multi-unit packaging	02	, ,	01012001 170100		· ·	T GITTE	115
-60 0	S00	S00/S0	Α	3RA2921-1B		1	10 units	41B
	SO	S00/S0	Α	3RA2921-1B		1	10 units	41B
4	S2 <sup>2)</sup>	S2 NEV	<b>7</b> A	3RA2931-1A		1	5 units	41B
Michigan								
3RA2931-1AA00								
	Connection between motor starte spring-type terminals	r protector and soft starter		Spring-type terminals	<u> </u>			
	Single-unit packaging							
	S00	S00	<b>&gt;</b>	3RA2911-2GA00		1	1 unit	41B
Dick.	S0	S0		3RA2921-2GA00		1	1 unit	41B
on the PA	Multi-unit packaging							
3RA2921-2GA00	S00 S0	S00 S0		3RA2911-2G 3RA2921-2G		1	10 units 10 units	41B 41B
	30	30		JINA2321-20		,	io uillo	410

#### Note:

Link modules can be used in

- Sizes S00 and S0 up to max. 32 A
- Size S2 up to max. 65 A

- 1) The link modules from motor starter protector to soft starter and from motor starter protector to solid-state contactor cannot be used for the 3RV2.21-4PA1., 3RV2.21-4FA1., 3RV2.31-4K.1., 3RV2.31-4R.1., 3RV2.32-4K.1., 3RV2.32-4R.1., 3RV2.32-4R.1. protectors/circuit breakers.
- $^{2)}\,$  To assemble the feeder between a motor starter protector and a soft starter in size S2, the 3RA2932-1AC00 standard mounting rail adapter must be

# SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A Accessories

#### **Mounting accessories**

	Actuating voltage of contactor	Size 3RT2 contactors	3RV2 motor starter protectors	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
Hybrid link modul	es for motor starter prote	ctor to con	tactor <sup>1)</sup>						
	Mechanical and electrical cor protector with screw terminals terminals								
	Single-unit packaging								
HAP	AC/DC AC <sup>2)</sup> /DC	S00 S0	S00 S0	<b>&gt;</b>	3RA2911-2FA00 3RA2921-2FA00		1 1	1 unit 1 unit	41B 41B
3RA2911-2FA00	Multi-unit packaging								
NV V	AC/DC AC <sup>2</sup> /DC	S00 S0	\$00 \$0	* *	3RA2911-2F 3RA2921-2F		1 1	10 units 10 units	41B 41B
3RA2921-2FA00									
ST 17 100	Spacers <sup>2)</sup> For compensating the height	on AC contac	ctors						
6 T	Single-unit packaging Multi-unit packaging	S0 S0	S0 S0	A A	3RA2911-1CA00 3RA2911-1C		1 1	1 unit 5 units	41B 41B
3RA2911-1CA00									
			4)						

#### Note:

Hybrid link modules in sizes S00 and S0 up to max. 32 A can be used.

## More information

#### Manuals

- System Manual "SIRIUS Innovations System Overview" http://support.automation.siemens.com/WW/view/en/60311318
- Manual "SIRIUS Innovations SIRIUS 3RV2 Motor Starter Protectors"
- http://support.automation.siemens.com/WW/view/en/60279172

The hybrid link modules for motor starter protector to contactor cannot be used for the 3RV2.21-4PA1., 3RV2.21-4FA1., 3RV27 and 3RV28 motor starter protectors/circuit breakers. They are only suitable for constructing direct-on-line starters.

<sup>2)</sup> A spacer for height compensation on AC contactors size S0 is optionally available.

## otectors/Circuit Breakers

## SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A Accessories

Enclosures and front plates


## Overview

#### **Enclosures**


For stand-alone installation of 3RV20 to 3RV24 motor starter protectors size S00 ( $I_{\rm n\,max}$  = 16 A), S0 ( $I_{\rm n\,max}$  = 32 A) and S2 ( $I_{\rm n\,max}$  = 65 A), cast aluminum enclosures for surface mounting and molded-plastic enclosures for flush mounting are available in various dimensions.

When installed in a molded-plastic enclosure the motor starter protectors have a rated operational voltage  $U_{\rm e}$  of 500 V.

The enclosures for surface mounting have the degree of protection IP55; the enclosures for flush mounting also comply with the degree of protection IP55 at the front (the flush-mounted section complies with IP20).



Enclosures for surface mounting



Enclosures (only for sizes S00 and S0)

All enclosures are equipped with N and PE terminals. There are two knock-out cable entries for cable glands at the top and two at the bottom; also on the rear corresponding cable entries are scored. There is a knockout on the top of the enclosure for indicator lights that are available as accessories.

The narrow enclosure can accommodate a motor starter protector without accessories, with transverse auxiliary switch and with lateral auxiliary switch. There is no provision for installing a motor starter protector with a signaling switch.

With size S00 to S2 circuit breakers the molded-plastic enclosures are equipped with a rotary operating mechanism.


The enclosures can be supplied with either a black rotary operating mechanism or with an EMERGENCY-STOP rotary operating mechanism with a red/yellow knob.

In the OFF setting, all rotary operating mechanisms can be locked with up to three padlocks.

#### Front plates

Motor starter protectors are frequently required to be actuated in any enclosure. Front plates equipped with a rotary operating mechanism for 3RV20 to 3RV24 motor starter protectors sizes S00 to S2 are available for this purpose.

A holder for the motor starter protectors size S00 and S0, into which the motor starter protectors can be snapped, is available for the front plates.



Front plate (including holder) for sizes S00 and S0

## SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A Accessories

## **Enclosures and front plates**

Selection and	ordering da	ata									
	Version	Degree of pro- tection	Inte- grated terminals	Width	For 3RV20 to 3RV24 motor starter protectors	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
				mm	Size						
Molded-plastic	enclosures	for sur	rface moι	ınting <sup>1)</sup>							
	With rotary operating mechanism, lockable in	IP55	N and PE/ ground	54 (for motor starter protector + lateral auxiliary switch)	S00, S0	•	3RV1923-1CA00		1	1 unit	41E
3RV1933-1DA00	0 position			72 (for motor starter protector + lateral auxiliary switch <sup>2)</sup> + auxiliary release)	S00, S0	•	3RV1923-1DA00		1	1 unit	41E
				82 (for motor starter protector + lateral auxiliary switch <sup>2)</sup> + auxiliary release)	S2	Α	3RV1933-1DA00		1	1 unit	41E
	With EMER- GENCY- STOP rotary	IP55	N and PE/ ground	54 (for motor starter protector + lateral auxiliary switch)	S00, S0	•	3RV1923-1FA00		1	1 unit	41E
3RV1923-1FA00, 3RV1933-1GA00	operating mechanism, lockable in 0 position			72 (for motor starter protector + lateral auxiliary switch <sup>2)</sup> + auxiliary release)	S00, S0	•	3RV1923-1GA00		1	1 unit	41E
				82 (for motor starter protector + lateral auxiliary switch <sup>2)</sup> + auxiliary release)	S2	Α	3RV1933-1GA00		1	1 unit	41E
Cast aluminun	n enclosures	s for su	rface mo	unting <sup>1)</sup>							
	With rotary operating mechanism, lockable in 0 position	IP65	PE <sup>3)</sup>	72 (for motor starter protector + lateral auxiliary switch <sup>2)</sup> + auxiliary release)	S00, S0	•	3RV1923-1DA01		1	1 unit	41E
3RV1923-1DA01	With EMER- GENCY- STOP rotary operating mechanism, lockable in 0 position	IP65	PE <sup>3)</sup>	72 (for motor starter protector + lateral auxiliary switch <sup>2</sup> ) + auxiliary release)	S00, S0	•	3RV1923-1GA01		1	1 unit	41E
Molded-plastic	enclosures	for flus	sh mount	ing <sup>4)</sup>							
	With rotary operating mechanism, lockable in 0 position	(front side)	N and PE/ ground	72 (for motor starter protector + lateral auxiliary switch <sup>2)</sup> + auxiliary release)	S00, S0	A	3RV1923-2DA00		1	1 unit	41E
3RV1923-2DA00	With EMER- GENCY- STOP rotary operating mechanism, lockable in 0 position	IP55 (front side)	N and PE/ ground	72 (for motor starter protector + lateral auxiliary switch <sup>2</sup> ) + auxiliary release)	S00, S0	Α	3RV1923-2GA00		1	1 unit	41E

<sup>1)</sup> The rear cable glands cannot be used on 3RV2.11-...2. and 3RV2.21-...2. devices with spring-type terminals.

 $<sup>^{2)}\,</sup>$  Only valid for lateral auxiliary switches with two auxiliary contacts.

<sup>3)</sup> If required, an additional N terminal can be mounted (e.g. 8WA1011-1BG11).

<sup>4)</sup> Not suitable for 3RV2.11-...2. and 3RV2.21-...2. devices with spring-type terminals.

## otectors/Circuit Breakers

## SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A Accessories

## **Enclosures and front plates**

	Version	Degree of protection	For 3RV20 to 3RV24 motor starter protectors	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
			Size						
Front plates									
	Molded-plastic front plates with rooperating mechanism, lockable in 0 position	otary IP55 (front side)	S00 S2	•	3RV1923-4B		1	1 unit	41E
	For actuation of 3RV2 motor starter protectors in any enclosure								
3RV1923-4B +	Molded-plastic front plates with EMERGENCY-STOP rotary operat mechanism, red/yellow, lockable in 0 position	ing (front side)	S00 S2	Α	3RV1923-4E		1	1 unit	41E
3RV1923-4G	EMERGENCY-STOP actuation of 3RV2 motor starter protectors in any enclosure	1							
	Holders for front plates		S00, S0	<b>&gt;</b>	3RV1923-4G		1	1 unit	41E
	Holder is mounted on front plate, mo starter protector with and without accessories is snapped in.	otor							
	Version	Rated control supply voltage $U_{\rm S}$	For 3RV20 to 3RV24 motor starter protectors	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
		V	Size						
Indicator lights									
3RV1903-5B	Indicator lights For all enclosures and front plates  • With LED lamp for versions 110 120 V, with glow lamp for versions 220 500 V  • With colored lenses red, green, yellow, orange and clear	110 120 220 240 380 415 480 500	S00 S2	0000	3RV1903-5B 3RV1903-5C 3RV1903-5E 3RV1903-5G		1 1 1	1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E
	, , ,								

#### SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A

#### 3RV29 infeed system

#### Overview

The 3RV29 infeed system is a convenient means of energy supply and distribution for a group of several motor starter protectors or complete load feeders with a screw or spring-type connection in sizes S00 and S0 (exception: this system cannot be used for the 3RV21, 3RV27 and 3RV28 motor starter protectors/circuit breakers).


The system is based on a basic module complete with a lateral incoming unit (three-phase busbar with infeed). This infeed with spring-type terminals is mounted on the right or left depending on the version and can be supplied with a maximum conductor cross-section of 25 mm² (with end sleeve). A basic module has two sockets onto each of which a motor starter protector can be snapped.

Expansion modules are available for extending the system (three-phase busbars for system expansion). The individual modules are connected through an expansion plug.

The electrical connection between the three-phase busbars and the motor starter protectors is implemented through plug-in connectors. The complete system can be mounted on a TH 35 standard mounting rail to IEC 60715 and can be expanded as required up to a maximum current carrying capacity of 63 A.

The system is mounted extremely quickly and easily thanks to the simple plug-in technique. Thanks to the lateral infeed, the system also saves space in the control cabinet. The additional overall height required for the infeed unit is only 30 mm. The alternative infeed possibilities on each side offer a high degree of flexibility for configuring the control cabinet: Infeed on left-hand or right-hand side as well as infeed on one side and outfeed on the other side to supply further loads are all possible. A terminal block with spring-type connections in combination with a standard mounting rail enables the integration of not only SIRIUS motor starter protectors but also single-phase, 2-phase and 3-phase components such as 5SY miniature circuit breakers or SIRIUS relay components.

The 3RV29 infeed system is approved in accordance with IEC to 500 V. It is also UL-approved and authorized for "Self-Protected Combination Motor Controller" (Type E starter) as well as for Type F starter (Type E starter + contactor).



SIRIUS 3RV29 infeed systems

# Motor Starter Protectors/Circuit Breakers SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A

3RV29 infeed system

#### 1 Three-phase busbars with infeed

A three-phase busbar with infeed unit is required for connecting the incoming supply. These modules comprise one infeed module and two sockets which each accept one motor starter protector. A choice of two versions with infeed on the left or right is available. The infeed is connected to spring-type terminals. They permit an infeed with conductor cross-sections of up to 25 mm² with end sleeves. An end cover is supplied with each module.

## (2) Three-phase busbars for system expansion

The three-phase busbars for system expansion support expansion of the system. There is a choice of modules with two or three sockets. The system can be expanded as required up to a maximum current carrying capacity of 63 A. An expansion plug is supplied with each module.

#### (3)a Expansion plug

The expansion plug is used for electrical connection of adjacent three-phase busbars. The current carrying capacity of this plug equals 63 A. One expansion plug is supplied with each three-phase busbar for system expansion. Additional expansion plugs are therefore only required as spare parts.

#### (3)b Extra-wide expansion plug

The wide expansion plug makes the electrical connection between two three-phase busbars, thus performing the same function as the 3RV2917-5BA00 expansion plug; the electrical characteristics (e.g. a current carrying capacity of 63 A) are identical.

The 3RV2917-5E expansion plug is 10 mm wider than the 3RV2917-5BA00 expansion plug, hence in the plugged state there is a distance of 10 mm between the connected three-phase busbars. This distance can be used to lay the auxiliary current and control current wiring ("wiring duct"). The motor starter protector and contactor can be wired from underneath, which means that the complete cable duct above the system can be omitted.

#### (4) End cover

The end cover is used to cover the three-phase busbar at the open end of the system. This cover is therefore only required once for each system. An end cover is supplied with each three-phase busbar system with infeed. Further end covers are therefore only required as spare parts.

#### 5 Plug-in connector

The plug-in connector is used for the electrical connection between the three-phase busbar and the 3RV2 motor starter protector. These plug-in connectors are available for screw or spring-type terminals.

#### 6 Contactor base

Load feeders can be assembled in the system using the S00 and S0 contactor base. The contactor bases are suitable for contactors sizes S00 and S0 with spring-type and screw terminals and are simply snapped onto the three-phase busbars. Direct-on-line starters and reversing starters are possible. One contactor base is required for direct-on-line starters and two are required for reversing starters.

To assemble load feeders for reversing starters, the contactor bases can be arranged alongside each other (90 mm overall width). In this case the mechanical interlocking of the contactors is possible. The S0 contactor bases are also suitable for soft starters size S00 and S0 with screw terminal.

The infeed system is designed for mounting onto a TH 35 standard mounting rail with 7.5 mm overall depth. This standard mounting rail gives the contactor base a stable mounting surface to sit on. If standard mounting rails with a depth of 15 mm are used, the spacer connected to the bottom of the contactor base must be knocked out and plugged into the mating piece that is also on the underside. Then the contactor base also has a stable mounting surface. When standard mounting rails with a depth of 7.5 mm are used, the spacer has no function and can be removed.

The link modules are used for direct start load feeders, in which case the use of a contactor base is not absolutely necessary. Motor starter protector and contactor assemblies can then be directly snapped onto the sockets of the three-phase busbars. For feeders of sizes S00 and S0, the corresponding 3RA1921-1...., 3RA2911-2...., 3RA2921-1.... or 3RA2921-2.... link modules should generally be used.

#### (7) Terminal block

The 3RV2917-5D terminal block enables the integration of not only SIRIUS motor starter protectors but also single-phase, 2-phase and 3-phase components. The three phases can be fed out of the system using the terminal block; which means that single-phase loads can also be integrated in the system. The terminal block is plugged into the slot of the expansion plug and thus enables outfeeding from the middle or end of the infeed system. The terminal block can be rotated through 180° and be locked to the support modules of the infeed system. In addition, the 45 mm wide TH 35 3RV1917-7B standard mounting rail option for screwing onto the support plate facilitates plugging the single-phase, two-phase and three-phase components onto the infeed system.

SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A

## 3RV29 infeed system

Technical spe	cifications
---------------	-------------

General data					
Туре					3RV29.7
Size					S00, S0
Standards					
• IEC 60947-2					Yes
• IEC 60947-4-1					Yes
• UL 508/UL 609	947-4-1				Yes
Rated current I <sub>r</sub>	1			Α	63
Permissible rate	ed current at i	nside temperature	of control cabinet		
Motor starter protectors	Size	Rated current	Inside tempera- ture of control cabinet		
• 3RV2.11	S00	14 A	60 °C	%	100
		>14 16 A	40 °C 60 °C	% %	100 87
• 3RV2.21	S0	16 A	60 °C	%	100
		> 16 25 A	40 °C 60 °C	%	100 87
		> 25 32 A	40 °C	%	87
Permissible am	bient tempera	ture			
<ul> <li>Storage/transp</li> </ul>	ort			°C	-50 <b>+</b> 80
<ul> <li>Operation</li> </ul>				°C	-20 +60
Rated operation	nal voltage <i>U</i> e				
<ul> <li>Acc. to IEC</li> </ul>		10 % overvolta	ge	V AC	500
		5% overvoltage	Э	V AC	525
Acc. to UL/CS/	4			V AC	600
Rated frequency				Hz	50/60
Rated impulse v		age <i>U<sub>imp</sub></i>		kV	6
Short-circuit str					Corresponds to the mounted motor starter protector or load feeder
Degree of prote	ction acc. to IE	EC 60529			IP20 (In the terminal compartment of the infeed without connected IP00 conductor)
Touch protectio	n acc. to DIN \	/DE 0106, Part 100			Finger-safe

Condi	ictor	cross.	sections
Colle	u o to i	01000	300010113

Туре		Three-phase busbar with infeed 3RV2917-1A, 3RV2917-1E	Terminal block 3RV2917-5D
Conductor cross-sections (min./max.)			
Solid or stranded	$mm^2$	4 25	1.5 6
Finely stranded with end sleeve	$mm^2$	4 25	1.5 4
Finely stranded without end sleeve	$\text{mm}^2$	6 25	1.5 6
AWG cables	AWG	10 3	15 10

## **Motor Starter Protectors/Circuit Breakers** SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A

3RV29 infeed system

1 unit

1 unit

10 units

10 units

1 unit

1 unit

10 units

10 units

41E

41E

41E

41E

41E

41E

41E

41E

Selection and ordering	ng data								
	Туре	Version	For 3RV20, 3RV23, 3RV24 motor starter protectors Size	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
Three-phase busbars	with infeed		GIZC						
3RV2917-1A	Three-phase busbars with infeed incl. 3RV2917-6A end cover	For 2 motor starter protectors with screw or spring-type terminals  • With infeed on the left  • With infeed on the right	\$00, \$0 \$00, \$0	A A	3RV2917-1A 3RV2917-1E		1	1 unit 1 unit	41E 41E
Three-phase busbars	for system expansion	on							
	Three-phase busbars incl. 3RV2917-5BA00 expansion plug	For motor starter protectors with screw or spring-type terminals  • For 2 motor starter protectors  • For 3 motor starter protectors	S00, S0 S00, S0	A A	3RV2917-4A 3RV2917-4B		1	1 unit 1 unit	41E 41E





3RV2917-4A

to make contact with the motor starter protectors

Plug-in connectors

- For spring-type Spring-type terminals S00<sup>1)</sup> S0<sup>2)</sup> 3RV2917-5AA00 - Single-unit packaging Α 3RV2927-5AA00
- S00<sup>1)</sup> S0<sup>2)</sup> 3RV2917-5A 3RV2927-5A A A - Multi-unit packaging • For screw terminals
- S00<sup>1)</sup> S0<sup>2)</sup> S00<sup>1)</sup> S0<sup>2)</sup> - Multi-unit packaging

- Single-unit packaging

- **Screw terminals (1)** 3RV2917-5CA00 3RV1927-5AA00 A A Α 3RV2917-5C 3RV1927-5A Α
- I > 16 A, please note derating; see Manual "SIRIUS Innovations SIRIUS 3RV2 Motor Starter Protectors", http://support.automation.siemens.com/WW/view/en/60279172.

3RV2917-5CA00
1) I > 14 A, please note derating; see Manual
"SIRIUS Innovations – SIRIUS 3RV2 Motor Starter Protectors",
http://support.automation.siemens.com/WW/view/en/60279172.

	Туре	Version	For contactors	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
			Size						
Contactor bases									
Almeta	Contactor bases	Single-unit packaging	S00	Α	3RV2917-7AA00		1	1 unit	41E
	for mounting direct-on-line or reversing starters		S00, S0	A	3RV2927-7AA00		1	1 unit	41E
3RV2927-7AA00									

## SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A

## 3RV29 infeed system

	Туре	Version	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
Terminal blocks								-
3RV2917-5D	<b>Terminal blocks</b> For integration of single-phase, two-phase and three-phase components	Single-unit packaging	А	3RV2917-5D		1	1 unit	41E
TH 35 standard moun	ting rails, width 45 mm							
ODI/4047 7D	TH 35 standard mounting rails acc. to IEC 60715, width 45 mm For mounting onto three-phase busbars	Single-unit packaging	А	3RV1917-7B		1	1 unit	41E
3RV1917-7B Extra-wide expansion	nluge							
-	Extra-wide expansion plugs As accessory	Single-unit packaging	A	3RV2917-5E		1	1 unit	41E
3RV2917-5E Expansion plugs								
3RV2917-5BA00	<b>Expansion plugs</b> <sup>1)</sup> As spare part	Single-unit packaging	A	3RV2917-5BA00		1	1 unit	41E
End covers	0)							
3RV2917-6A	End covers <sup>2)</sup> As spare part	Multi-unit packaging	А	3RV2917-6A		100	10 units	41E

 $<sup>^{1)}\,</sup>$  The expansion plug is included in the scope of supply of the 3RV2917-4. three-phase busbars for system expansion.

The end cover is included in the scope of supply of the 3RV2917-1. three-phase busbars with infeed system.

#### SIRIUS 3RV1 Motor Starter Protectors/Circuit Breakers up to 100 A

**General data** 

## Overview


The following illustration shows our 3RV1 motor starter protector/ circuit breaker with the accessories which can be mounted for size S3, see also "Introduction" → "Overview", page 7/3.

"Accessories", see page 7/69 onwards.

#### Note:

The 3RV1 devices (sizes S00/S0 to S3) can be found

- in the Catalog Add-On IC 10 AO · 2015 at the Information and Download Center
- in the interactive catalog CA 01
- in the Industry Mall



#### Mountable accessories for size S3

- 1 Transverse auxiliary switch (can not be used with 3RV1742 circuit breakers)
- 2 Lateral auxiliary switch with 2 contacts
- 3 Lateral auxiliary switch with 4 contacts
- 4 Shunt release (can not be used with 3RV11 motor starter protectors)
- 5 Undervoltage release (can not be used with 3RV11 motor starter protectors)
- (6) Undervoltage release with leading auxiliary contacts (can not be used with 3RV11 motor starter protectors)
- (7) Alarm switch (can not be used with 3RV1742 circuit breakers)

SIRIUS 3RV1 motor starter protector/circuit breaker size S3 with mountable accessories



SIRIUS motor starter protector/circuit breaker size S3

3RV1 motor starter protectors/circuit breakers are compact, current limiting motor starter protectors/circuit breakers which are optimized for load feeders. The motor starter protectors/circuit breakers are used according to IEC 60947-2 for switching and protecting three-phase motors of up to 45 kW at 400 V AC and for other loads with rated currents of up to 100 A.

3RV2 motor starter protectors/circuit breakers sizes S00 to S2 up to 80 A, see page 7/21 onwards.

3RV1 motor starter protectors/circuit breakers are generally approved according to IEC and UL/CSA.

According to UL 508/UL 60947-4-1, the 3RV1 motor starter protectors in size S3 are approved as:

- "Manual Motor Controllers"
- "Manual Motor Controllers" for "Group Installations"
- "Manual Motor Controllers Suitable for Tab Conductor Protection in Group Installations"
- "Self-Protected Combination Motor Controllers (Type E)" Please note that for this approval the 3RV10 motor starter protectors in size S3 must be equipped with additional infeed terminals.

The 3RV1742 are approved as circuit breakers according to UL 489; they are a special variant of the 3RV1 motor starter protectors.

Corresponding short-circuit values, see pages 7/54 to 7/57.

## SIRIUS 3RV1 Motor Starter Protectors/Circuit Breakers up to 100 A

#### **General data**

#### Type of construction

The 3RV1 motor starter protectors/circuit breakers are available in four sizes:

- Size S00 width 45 mm, max. rated current 12 A,
  - at 400 V AC suitable for three-phase motors up to 5.5 kW
- Size S0 width 45 mm, max. rated current 25 A,
- at 400 V AC suitable for three-phase motors up to 11 kW
- Size S2 width 55 mm, max. rated current 50 A,
- at 400 V AC suitable for three-phase motors up to 22 kW
- Size S3 width 70 mm, max. rated current 100 A, at 400 V AC suitable for three-phase motors up to 45 kW

Sizes S00 to S2 of the 3RV2 motor starter protectors/circuit breakers up to 80 A, see page 7/21 onwards.

#### Circuit breakers acc. to UL 489


The 3RV1742 circuit breakers are available in size S3 (width 70 mm):

- Maximum rated current 70 A at 480 Y/277 V AC
- Maximum rated current 10 A to 30 A at 480 V AC

For sizes S00 and S0 of the 3RV27 and 3RV28 circuit breakers up to 22 A, see pages 7/29 and 7/30.

#### Connection methods

The SIRIUS 3RV1 motor starter protectors/circuit breakers can be supplied with screw terminals and spring-type terminals.



## "Increased safety" type of protection EEx e according to ATEX directive 94/9/EC

3RV10 motor starter protectors are suitable for the overload protection of explosion-proof motors with "increased safety" type of protection EEx e.

#### Article No. scheme

Digit of the Article No.	1st - 3rd	4th	5th	6th	7th		8th	9th	10th	11th	12th		13th	14th	15th	16th	
						-						-					
Motor starter protectors/ circuit breakers	3 R V																
SIRIUS 1st generation		1															
Type of motor starter protector/ circuit breaker																	
Size																	
Breaking capacity																	
Setting range for overload release																	
Trip class (CLASS)																	
Connection methods																	
With or without auxiliary switch																	
Special versions																	
Example	3 R V	1	0	4	1	-	4	F	Α	1	0						

#### Note:

The Article No. scheme is presented here merely for information purposes and for better understanding of the logic behind the article numbers.

For your orders, please use the article numbers quoted in the catalog in the Selection and ordering data.

SIRIUS 3RV1 Motor Starter Protectors/Circuit Breakers up to 100 A

General data

## Application

#### Operating conditions

3RV1 motor starter protectors/circuit breakers are suitable for use in any climate. They are intended for use in enclosed rooms in which no severe operating conditions (such as dust, caustic vapors, hazardous gases) prevail. When installed in dusty and damp areas, suitable enclosures must be provided.

3RV1 motor starter protectors/circuit breakers can optionally be fed from the top or from below.

The permissible ambient temperatures, the maximum switching capacities, the tripping currents and other boundary conditions can be found in the technical specifications and tripping characteristics, see Reference Manual "Protection Equipment – Circuit Breakers · Molded Case Circuit Breakers", http://support.automation.siemens.com/WW/view/en/65032586.

3RV1 motor starter protectors/circuit breakers are suitable for operation in IT systems (IT networks). In this case, the different short-circuit breaking capacity in the IT system must be taken into account, see page 7/55.

Since operational currents, starting currents and current peaks are different even for motors with identical power ratings due to the inrush current, the motor ratings in the selection tables are only guide values. The specific rated and startup data of the motor to be protected is always paramount to the choice of the most suitable motor starter protector/circuit breaker. This also applies to motor starter protectors for transformer protection.

#### Note:

For the use of 3RV1 motor starter protectors in size S3 in conjunction with highly energy-efficient IE3 motors, please observe the information on dimensioning and configuring, see "Configuration Manual for SIRIUS Controls with IE3 Motors", http://support.automation.siemens.com/WW/view/en/94770820.

More information, see page 3.

#### Possible uses

The 3RV1 motor starter protectors/circuit breakers can be used:

- For short-circuit protection
- For motor protection (also with overload relay function)
- For system protection
- For short-circuit protection for starter combinations
- As main and EMERGENCY-STOP switches
- · For fuse monitoring
- For operation in IT systems (IT networks)
- For switching of DC currents
- As voltage transformer circuit breakers
- In areas subject to explosion hazard (ATEX)
- Approved as circuit breakers according to UL 489 (3RV1742)

For more details, see Reference Manual "Protection Equipment – Circuit Breakers · Molded Case Circuit Breakers" http://support.automation.siemens.com/WW/view/en/65032586.

#### SIRIUS 3RV1 Motor Starter Protectors/Circuit Breakers up to 100 A

#### **General data**

## Technical specifications

## Short-circuit breaking capacity $I_{cu}$ , $I_{cs}$ according to IEC 60947-2

This table shows the rated ultimate short-circuit breaking capacity  $I_{\rm Cu}$  and the rated service short-circuit breaking capacity  $I_{\rm CS}$  of the 3RV1 motor starter protectors/circuit breakers with different operating voltages dependent of the rated current  $I_{\rm n}$  of the motor starter protectors/circuit breakers.

Power can be supplied to the motor starter protectors/circuit breakers via the terminals at the top or at the bottom without restricting the rated data. If the short-circuit current at the place of installation exceeds the rated short-circuit breaking capacity of the motor starter protector/circuit breaker as specified in the table, a back-up fuse is required. It is also possible to install an upstream motor starter protector/circuit breaker with a limiter function.

The maximum rated current of this back-up fuse is indicated in the tables. The rated ultimate short-circuit breaking capacity then applies as specified on the fuse.

#### Fuseless design

Motor starter protector/contactor assemblies for short-circuit currents up to 100 kA can be ordered as fuseless load feeders, see Chapter 8 "Load Feeders and Motor Starters for Use in the Control Cabinet".

Motor starter protectors/ circuit breakers	Rated current I <sub>n</sub>	Up to	240 \	/ AC <sup>1)</sup>	Up to	Up to 400 V AC <sup>1)</sup> / 415 V AC <sup>2)</sup>		Up to 440 V AC <sup>1)</sup> / 460 V AC <sup>2)</sup> (these values do not ap			525 \	/ AC <sup>2)</sup>			<b>690 \</b>	/ AC <sup>1)</sup>
		$I_{ m CU}$	$I_{\mathrm{CS}}$	Max. fuse (gG)	$I_{\mathrm{CU}}$	$I_{\mathrm{CS}}$	Max. fuse (gG) <sup>3)</sup>	$I_{\text{CU}}$	$I_{\text{CS}}$	Max. fuse (gG) <sup>3)</sup>		$I_{\text{CS}}$	Max. fuse (gG) <sup>3)</sup>		$I_{ extsf{CS}}$	Max. fuse (gG) <sup>3)4)</sup>
Туре	А	kA	kA	Α	kA	kA	А	kA	kA	А	kA	kA	А	kA	kA	А
Size S00																
3RV1611-0BD10	0.2	100	100	0	100	100	0	100	100	0	100	100	0	100	100	0
Size S3																
3RV1.41	40 50 63	100 100 100	100 100 100	0 0	50 50 50	25 25 25	125 125 160	50 50 50	20 20 20	125 125 160	12 12 12	6 6 6	100 100 100	6 6 6	3 3 3	63 80 80
	75 90; 100	100 100	100 100	0	50 50	25 25	160 160	50 50	20 20	160 160	8	4	125 125	5 5	3	100 125
Size S3, with inc switching capaci																
3RV1.42/3RV1742 <sup>5)</sup>	16 / 10 20 / 15 25 / 20	100 100 100	100 100 100	0 0	100 100 100	50 50 50	0	100 100 100	50 50 50	0	30 30 30	15 15 15	80 80 80	12 12 12	7 7 7	63 63 63
	32 / 25 40 / 30 50 / 35 40	100 100 100	100 100 100	0	100 100 100	50 50 50	o o	100 100 100	50 50 50	o o	22 18 15	11 9 7.5	100 160 160	12 12 10	7 6 5	63 80 100
	63 / 45 50 75 / 60 90 / 70 100 /	100 100 100 100	100 100 100 100	0 0 0	100 100 100 100	50 50 50 50	o o o	70 70 70 70	50 50 50 50	200 200 200 200	15 10 10 10	7.5 5 5 5	160 160 160 160	7.5 6 6 6	4 3 3 3	100 125 160 160

<sup>°</sup> No back-up fuse required, since short-circuit resistant up to 100 kA

<sup>1) 10 %</sup> overvoltage.

<sup>&</sup>lt;sup>2)</sup> 5 % overvoltage.

 $<sup>^{\</sup>rm 3)}$  Back-up fuse only required if short-circuit current at the place of installation >  $I_{\rm CU}$ 

<sup>4)</sup> Alternatively, fuseless limiter combinations for 690 V AC can also be used.

<sup>5)</sup> The values for the 3RV1742 circuit breakers have been tested only up to 400 V/415 V AC; values > 440 V AC on request.

#### SIRIUS 3RV1 Motor Starter Protectors/Circuit Breakers up to 100 A

**General data** 

#### Short-circuit breaking capacity I<sub>CulT</sub> in the IT system (IT network) according to IEC 60947-2

3RV1 motor starter protectors/circuit breakers are suitable for operation in IT systems. The values of  $I_{\rm Cu}$  and  $I_{\rm CS}$  apply for the three-pole short circuit. In case of a double ground fault in different phases at the input and output side of a motor starter protector/circuit breaker, the special short-circuit breaking capacity  $I_{\rm culT}$  applies. The specifications in the table apply to 3RV1 motor starter protectors/circuit breakers.

If the short-circuit current at the place of installation exceeds the motor starter protector/circuit breaker's specified rated short-circuit breaking capacity, you will need to use a back-up fuse. The maximum rated current of this back-up fuse is indicated in the tables. The rated short-circuit breaking capacity then applies as specified on the fuse.

Motor starter	Rated	Up to 240 V	AC1)	Up to 400 V A	C <sup>1)</sup> /415 V AC <sup>2)</sup>	Up to 500 V A	C <sup>1)</sup> /525 V AC <sup>2)</sup>	Up to 690 V A	<b>C</b> <sup>1)5)</sup>
protectors/ circuit breakers	current I <sub>n</sub>	$I_{CulT}$	Max. fuse (gG) <sup>3)</sup>	$I_{culT}$	Max. fuse (gG) <sup>3)4)</sup>	$I_{CUIT}$	Max. fuse (gG) <sup>3)</sup>	$I_{culT}$	Max. fuse (gG) <sup>3)</sup>
Туре	Α	kA	Α	kA	Α	kA	Α	kA	Α
Size S00									
3RV1611-0BD10	0.2	100	0	100	0	100	0	100	0
Size S3									
3RV1.41	40 50 63 75 90; 100	50 50 50 50 50	125 125 160 160 160	10 8 6 5	63 80 80 100 125	5 3 3 2 2	50 63 63 80 100	5 3 3 2 2	50 63 63 80 100
Size S3, with ine									
3RV1.42	16 32 40 50 63 75 90; 100	100 100 100 100 100 100	0 0 0 0 0 0	12 12 10 7.5 6	63 80 100 100 125 160	6 6 4 4 3 3	50 63 80 80 100 125	6 6 4 4 3 3	50 63 80 80 100 125

 $<sup>^{\</sup>circ}$   $\,$  No back-up fuse required, since short-circuit resistant up to 100 kA  $\,$ 

#### Limiter function with standard devices for 500 V AC and 690 V AC according to IEC 60947-2

The table shows the rated ultimate short-circuit breaking capacity  $I_{\rm CU}$  and the rated service short-circuit breaking capacity  $I_{\rm CS}$  with an upstream standard motor starter protector that fulfills the limiter function at voltages 500 V AC and 690 V AC.

The short-circuit breaking capacity can be increased significantly with an upstream standard motor starter protector with limiter function. The motor starter protector which is connected downstream must be set to the rated current of the load. With motor starter protector assemblies, note the clearance to grounded parts and between the motor starter protectors. Short-circuit proof wiring between the motor starter protectors must be ensured. The motor starter protectors can be mounted side by side in a modular arrangement.

Standard motor starter	protectors	Rated current In	Up to 500 V AC <sup>1)</sup> /5	Up to 500 V AC <sup>1)</sup> /525 V AC <sup>2)</sup>		
	With limiter rated current $I_n$		$I_{ t CU}$	$I_{ t CS}$	$I_{ m CU}$	$I_{ exttt{CS}}$
Type	Туре	Α	kA	kA	kA	kA
Size S3						
3RV1041/3RV10 42	3RV1341-4HC10	32 50	100	50	50	25
	$I_{\rm n} = 50  \text{A}$					
	3RV1341-4MC10	50 100	100	50	50	25
	$I_{\rm n} = 100  {\rm A}$					

<sup>1) 10 %</sup> overvoltage.

<sup>1) 10 %</sup> overvoltage.

<sup>&</sup>lt;sup>2)</sup> 5 % overvoltage.

 $<sup>^{\</sup>rm 3)}$  Back-up fuse only required if short-circuit current at the place of installation >  $I_{\rm culT}$ 

<sup>4)</sup> Alternatively, fuseless limiter combinations for 690 V AC can also be used.

<sup>5)</sup> Overvoltage category II applies for applications in IT systems > 600 V.

<sup>&</sup>lt;sup>2)</sup> 5 % overvoltage.

#### SIRIUS 3RV1 Motor Starter Protectors/Circuit Breakers up to 100 A

#### **General data**

#### Permissible rated data of approved devices for North America (UL/CSA)

Motor starter protectors/circuit breakers of the 3RV1 series are approved for UL/CSA, and according to UL508/UL 60947-4-1 and CSA C22.2 No. 14/CSA 60947-4-1 they can be used on their own or as load feeders in combination with a contactor.

These motor starter protectors/circuit breakers can be used as "Manual Motor Controllers" for "Group Installations", as "Manual Motor Controllers Suitable for Tap Conductor Protection in Group Installations" and as "Self-Protected Combination Motor Controllers" (Type E).

#### 3RV1 motor starter protectors/circuit breakers as "Manual Motor Controllers"

If used as a "Manual Motor Controller", the motor starter protector/circuit breaker is always operated in combination with an upstream short-circuit protection device. Approved fuses or a circuit breaker according to UL 489/CSA C22.2 No. 5 can be used. These devices must be dimensioned according to the National Electrical Code (UL) or Canadian Electrical Code (CSA).

The file numbers for the approval of the 3RV1 as a Manual Motor Controller are as follows:

- UL File No. 47705, CCN: NLRV
- CSA Master Contract 165071, Product Class: 3211 05

Motor starter		hp rating <sup>1)</sup>	for FLA <sup>2)</sup>	Rated	240 V AC		480 V AC		600 V AC	
protectors		max.		current I <sub>n</sub>	$I_{bc}^{(3)}$	CSA $I_{\rm bc}^{(3)}$	$I_{bc}^{(3)}$	CSA $I_{bc}^{(3)}$	$I_{bc}^{(3)}$	CSA $I_{bc}^{(3)}$
Туре	V	Single- phase	3-phase	A	kA	kA	kA	kA	kA	kA
Size S00										
3RV1611-0BD10				0.2	65	65	65	65	10	10
Size S3										
3RV1041/3RV1042, 3	RV1142, 3RV	/1341/3RV13	342	16 75 90; 100	65 65	65 65	65 65	65 65	30 10	30 10
FLA <sup>2)</sup> max. 100 A, 600 V NEMA size 3	115 200 230 460 575/600	7 1/2 20 20  	 30 40 75 100							

<sup>1)</sup> hp rating = Power rating in horse power (maximum motor rating).

#### 3RV10 motor starter protectors as "Manual Motor Controllers Suitable for Tap Conductor Protection in Group Installations"

The application as "Manual Motor Controllers Suitable for Tap Conductor Protection in Group Installations" is only available for UL. CSA does not recognize this approval! When the motor starter protector is used as a "Manual Motor Controller Suitable for Tap Conductor Protection in Group Installations", it must always be combined with upstream short-circuit protection. Approved fuses or a circuit breaker according to UL 489 can be used. These devices must be dimensioned according to the National Electrical Code.

The 3RV10 motor starter protectors are approved as "Manual Motor Controllers Suitable for Tap Conductor Protection in Group Installations" under the following file number:

• UL File No. 47705, CCN: NLRV

Motor starter protectors		hp rating <sup>1)</sup> max.	for FLA <sup>2)</sup>	Rated current I <sub>n</sub>	<b>240 V AC</b> UL <i>I</i> <sub>bc</sub> <sup>3)</sup>		Up to 600 Y/347 V AC UL $I_{\rm bc}^{(3)}$
Туре	V	Single- phase	3-phase	Α	kA		kA
Size S3							
3RV104.				16 75 90: 100	65 65	65 65	30
FLA <sup>2)</sup> max. 100 A, 480 V 75 A, 600 V NEMA size 3	115 200 230 460 575/600	7 1/2 20 20 	 30 40 75 75	36, 166			

<sup>--</sup> No approval

<sup>2)</sup> FLA = Full Load Amps/motor full load current.

<sup>3)</sup> Corresponds to "short-circuit breaking capacity" according to UL/CSA.

<sup>1)</sup> hp rating = Power rating in horse power (maximum motor rating)

<sup>2)</sup> FLA = Full Load Amps/motor full load current.

<sup>3)</sup> Corresponds to "short-circuit breaking capacity" according to UL.

## SIRIUS 3RV1 Motor Starter Protectors/Circuit Breakers up to 100 A

General data

#### 3RV10 motor starter protectors as "Self-Protected Combination Motor Controllers (Type E)"

UL 508/UL 60947-4-1 approval demands 1-inch clearance and 2-inch creepage distance at line side for "Self-Protected Combination Motor Controller Type E".

Therefore, 3RV10 motor starter protectors in size S3 are approved according to UL 508/UL 60947-4-1 in combination with the 3RT1946-4GA07 terminal block listed below.

CSA does not require these extended clearances and creepage distances. According to CSA, these terminal blocks can be omitted when the device is used as a "Self-Protected Combination Motor Controller".

The 3RV10 motor starter protectors are approved as "Self-Protected Combination Motor Controllers" under the following file numbers:

- UL File No. E156943, CCN: NKJH
- CSA Master Contract 165071, Product Class: 3211 08

Motor starter		hp rating <sup>1</sup>	for FLA <sup>2)</sup>	Rated	Up to 240 V	AC	Up to 480 Y	//277 V AC	Up to 600 Y	/347 V AC
protectors		max.		current I <sub>n</sub>	UL I <sub>bc</sub> <sup>3)</sup>	CSA $I_{ m bc}^{(3)}$	$I_{\rm bc}^{(3)}$	CSA $I_{ m bc}^{(3)}$	$I_{bc}^{(3)}$	CSA $I_{bc}^{3)}$
Туре	V	Single- phase	Three- phase	A	kA	kA	kA	kA	kA	kA
Size S3										
3RV1041 + 3RT194	46-4GA07 <sup>4)</sup>			16 75 90; 100	65 65	65 65	65 65	65 65	30 	30
FLA <sup>2)</sup> max. 100 A, 480 V 75 A, 600 V NEMA size 3	115 200 230 460 575/600	10 20 20  	 30 40 75 75							

No approva

#### 3RV1742 motor starter protectors as "Circuit Breakers"

These motor starter protectors are approved as circuit breakers according to UL 489 and CSA 22.2 No. 5. They can be used therefore as upstream short-circuit protective devices for "Manual Motor Controllers" and "Manual Motor Controllers Suitable for Tap Conductor Protection in Group Installations".

The 3RV1742 motor starter protectors are approved as "Circuit Breakers" under the following file numbers:

- UL File No. E235044, CCN: DIVQ
- CSA Master Contract 165071, Product Class: 1432 01

Circuit breakers	Rated current I <sub>n</sub>	240 V AC		480 Y/277 V	AC	480 V AC		600 Y/347 V	AC
		UL	CSA	UL	CSA	UL	CSA	UL	CSA
		$I_{bc}^{1)}$	$I_{bc}^{1)}$	$I_{\rm bc}^{-1)}$	$I_{\rm bc}^{-1)}$	$I_{\rm bc}^{-1)}$	$I_{bc}^{1)}$	$I_{bc}^{1)}$	$I_{\rm bc}^{-1)}$
Type	Α	kA	kA	kA	kA	kA	kA	kA	kA
Size S3									
3RV1742	10 30 35 60 70	65 65 65	65 65 65	65 65 65	65 65 65	65  	65  	20 20 10	20 20 10

<sup>--</sup> No approval

<sup>1)</sup> hp rating = Power rating in horse power (maximum motor rating).

<sup>2)</sup> FLA = Full Load Amps/motor full load current.

<sup>3)</sup> Corresponds to "short-circuit breaking capacity" according to UL/CSA.

<sup>4)</sup> Not required for CSA.

<sup>1)</sup> Corresponds to "short-circuit breaking capacity" according to UL.

## SIRIUS 3RV1 Motor Starter Protectors/Circuit Breakers up to 100 A

## General data

General data					
Туре			3RV1611 <sup>1)</sup>	3RV1.4.	3RV1742
Size			S00	S3	S3
Dimensions (W x H x D)		mm	45 x 90 x 70	70 x 165 x 169	70 x 168 x 169
Simensions (W XTTX D)	↓ W N		40 X 30 X 70	70 X 100 X 100	70 X 100 X 100
Standards	<b>→ → /</b>				
• IEC 60947-1, EN 60947-1 (VDE 0660 Part			Yes		
<ul> <li>IEC 60947-2, EN 60947-2 (VDE 0660 Part</li> <li>IEC 60947-4-1, EN 60947-4-1 (VDE 0660 I</li> </ul>			Yes Yes		No
• UL 508/UL 60947-4-1, CSA C22.2 No.14/0			Yes		No
• UL 489, CSA C22.2 No. 5			No		Yes
Number of poles			3		
Max. rated current I <sub>n max</sub>		Α	12	100	70
(= max. rated operational current I <sub>e</sub> )					
Permissible ambient temperature  Storage/transport		°C	-50 +80		
• Operation		°Č		reduction above +60 °C)	
Permissible rated current at inside tempe	rature of control cabinet				
• +60 °C • +70 °C		% %	100 87		
	norature of analassus	/0	O1		
Permissible rated current at ambient tem (applies for motor starter protector inside					
• +35 °C	· · · · · · · · · · · · · · · · · · ·	%	100		
• +60 °C		%	87		
Rated operational voltage <i>U</i> <sub>e</sub>		V/ ^C	600 (with molded at	natio analogura EOO \/\	
<ul> <li>Acc. to IEC</li> <li>Acc. to UL/CSA</li> </ul>		V AC V AC	690 (with molded-pix	astic enclosure 500 V)	
Rated frequency		Hz	50/60		
Rated insulation voltage <i>U</i> <sub>i</sub>		V	690		
Rated impulse withstand voltage $U_{imp}$		kV	6		
Utilization category		100	0		
<ul> <li>IEC 60947-2 (motor starter protector/circu</li> <li>IEC 60947-4-1 (motor starter)</li> </ul>	it breaker)		A AC-3		
Trip class CLASS	Acc. to IEC 60947-4-1		10	10/20	
DC short-circuit breaking capacity (time o	constant $t = 5 \text{ ms}$ )				
1 conducting path 150 V DC		kA	10		
<ul> <li>2 conducting paths in series 300 V DC</li> <li>3 conducting paths in series 450 V DC</li> </ul>		kA kA	10 10		
Power loss $P_{v}$ for each motor starter	<i>I</i> <sub>n</sub> : 16 63 A	W		20	
protector/circuit breaker	-111				
Dependent on the rated current $I_n$					
(upper setting range)	I <sub>n</sub> : 75 and 90 A	W		30	
$R = \frac{P}{P}$	<i>I</i> <sub>n</sub> : 100 A	W		38	
$R_{\text{per conducting path}} = \frac{P}{I^2 \times 3}$	<i>I</i> <sub>n</sub> : 10 A	W			8
	<i>I</i> <sub>n</sub> : 15 35 A	W			12
Shock resistance	I <sub>n</sub> : 40 70 A			ino pulco)	21
Shock resistance	Acc. to IEC 60068-2-27	g/ms	25/11 (square and s		
Degree of protection	Acc. to IEC 60529		IP20 (IP00 terminal of		
Touch protection	Acc. to EN 50274	00	<u> </u>	al contact from the front	
Temperature compensation	Acc. to IEC 60947-4-1	°C	-20 +60	f ODV/10.4 1 1 1	NI-
Phase failure sensitivity	Acc. to IEC 60947-4-1		Yes (does not apply protectors)	for 3RV134 motor starter	No
Explosion protection – Safe operation of	motors with		Yes, for 3RV10 (CLA	SS 10)	No
"increased safety" type of protection			.50, 101 0/14 10 (OLA	,	110
EC type test certificate number according to	)		DMT 02 ATEX F 001	(a) II (2) GD,	
directive 94/9/EC (ATEX)			DMT 02 ATEX F 001	N1 🐼 II (2) GD	
Isolating function Main and EMERGENCY-STOP switch	Acc. to IEC 60947-2 Acc. to DIN EN 60204-1		Yes Yes		
characteristics (with corresponding accessories)	AGG. 10 DIIN EIN 00204-1		169		
Protective separation between main and	Acc. to IEC 60947-1				
auxiliary circuits, required for					
PELV applications  Up to 400 V +10 %			Yes		
<ul> <li>Up to 400 V + 10 %</li> <li>Up to 415 V +5 % (higher voltages on req</li> </ul>	uest)		Yes		
Permissible mounting position	·			47 start command "I" right-h	nand side or top
Mechanical endurance	Operat	ing cycles	•	50 000	
Mechanical endurance		5 . , 50			
Electrical endurance	Operat	ing cycles	100 000	25 000	

 <sup>&</sup>quot;Technical Specifications" for 3RV1611 voltage transformer circuit breakers, see page 7/60.

For short-circuit breaking capacity  $I_{\rm CU}$ ,  $I_{\rm CS}$  see Reference Manual "Protection Equipment – Circuit Breakers Molded Case Circuit Breakers" http://support.automation.siemens.com/WW/view/en/65032586.

# Motor Starter Protectors/Circuit Breakers SIRIUS 3RV1 Motor Starter Protectors/Circuit Breakers up to 100 A

General data

Conductor cross-sections of main circuit			
Туре		3RV1611 <sup>4)</sup>	3RV1.4./ 3RV1742
Connection type		Screw terminals	Screw terminals with box terminal
Terminal screw		Pozidriv size 2	4 mm Allen screw
Prescribed tightening torque	Nm	0.8 1.2	4 6
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected			
Solid or stranded	mm <sup>2</sup>	2 x (0.5 1.5) <sup>5</sup> , 2 x (0.75 2.5) <sup>5</sup>	2 x (2.5 16) <sup>5)</sup> , 2 x (10 50) <sup>5)</sup> , 1 x (10 70) <sup>5)</sup>
• Finely stranded with end sleeve (DIN 46228-1)	mm <sup>2</sup>	2 x (0.5 1.5) <sup>5)</sup> , 2 x (0.75 2.5) <sup>5)</sup>	2 x (2.5 35) <sup>5)</sup> , 1 x (2.5 50) <sup>5)</sup>
AWG cables, solid or stranded	AWG	2 x (18 14)	2 x (10 1/0) <sup>5)</sup> , 1 x (10 2/0) <sup>5)</sup>
Ribbon cable conductors (Number x Width x Thickness)	mm		2 x (6 x 9 x 0.8)
Removable box terminals <sup>1)</sup>			
• With copper bars <sup>2)</sup>			18 x 10
• With cable lugs <sup>3)</sup>			up to 2 x 70
1) Cable lug and busher connection possible ofter removing the box		4) "Tacksiaal Cassifications" for	2DV/16 valtage transformer size it bree

- Cable lug and busbar connection possible after removing the box terminals.
- 2) If bars larger than 12 mm x 10 mm are connected, a 3RT1946-4EA1 cover is needed to comply with the phase clearance.
- 3) When connecting conductors which are larger than 25 mm<sup>2</sup>, the 3RT1946-4EA1 cover must be used to keep the phase clearance.
- "Technical Specifications" for 3RV16 voltage transformer circuit breakers, see page 7/60.
- 5) If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.

Rated data of the auxiliary switches and Type 3RV19	a signating switches	Lateral	Transverse	
Type SKV 19		auxiliary switch with 1 NO + 1 NC, 2 NO, 2 NC, 2 NO + 2 NC;	auxiliary switches with	1 NO + 1 NC, 2 NO
		Signaling switches		
Max. Rated voltage				
• Acc. to NEMA (UL)	V AC	600		250
• Acc. to NEMA (CSA)	V AC	600		250
Uninterrupted current	А	10	5	2.5
Switching capacity		A600 Q300	B600 B300	C300 R300

## SIRIUS 3RV1 Motor Starter Protectors/Circuit Breakers up to 100 A

## General data

## Voltage transformer circuit breakers

General data					
Type	7.	3RV1611-1AG14	3RV1611-1CG14	3RV1611-1DG14	
Size Dimensions (W x H x D)	mm	S00 45 x 90 x 70	S00 45 x 90 x 70	S00 45 x 90 x 70	
Rated current I <sub>n</sub>	A	1.4	2.5	3	
Ambient temperature					
During storage/transport	°C	-50 <b>+</b> 80			
During operation	°C	-20 +60 (up to +7	O°C is possible with curr	ent reduction)	
Rated operational voltage $U_{\rm e}$	V	400			
Rated frequency	Hz	16.66 60			
Rated insulation voltage <i>U</i> <sub>i</sub>	V	690			
Short-circuit breaking capacity I <sub>cu</sub> at 400 V AC	kA	50			
Set value of the thermal overload release	Α	1.4	2.5	3	
Response value of the instantaneous overcurrent release	Α	6 ± 20 %	10.5 ± 20 %	20 ± 20 %	
Tripping time of the instantaneous overcurrent release	ms	Approx. 6 at 12 A	Approx. 6 at 20 A	Approx. 6 at 40 A	
Internal resistance					
In cold state	Ω	$>0.25\pm6.5$ %			
In heated state	Ω	$> 0.30 \pm 6.5 \%$			
Shock resistance acc. to IEC 60068-2-27	g/ms	15			
Degree of protection acc. to IEC 60529	·	IP20			
Touch protection acc. to EN 50274	·	Finger-safe for vertic	al contact from the front		
Endurance					
Mechanical	Operating cycles	10 000			
Electrical	Operating cycles	10 000			
Permissible mounting position		Any			

Туре			3RV1611-1AG14	3RV1611-1CG14	3RV1611-1DG14		
Conductor cross-sections, main	circuit, 1 or 2 conductors						
Connection type			Screw terminals				
Terminal screw			Pozidriv size 2				
Conductor cross-sections (min./max. connected	), 1 or 2 conductors can be						
Solid or stranded		$\text{mm}^2$	2 x (0.5 1.5) <sup>1)</sup> , 2 x	(0.75 2.5) <sup>1)</sup> , max. 4			
• Finely stranded with end sleeve (DIN	46228-1)	$\rm mm^2$	2 x (0.5 1.5) <sup>1)</sup> , 2 x	(0.75 2.5) <sup>1)</sup>			
Auxiliary switches for blocking t	he distance protection						
With defined lateral assignment for bl	ocking distance protection		1 CO (for use as 1 No	O or 1 NC)			
Rated operational voltage U <sub>e</sub>	Alternating voltage	V	125				
Rated operational current I <sub>e</sub> /AC-14	at $U_{\rm e}$ = 125 V	Α	0.1				
Rated operational voltage U <sub>e</sub>	Direct voltage L/R 200 ms	V	60				
Rated operational current I <sub>e</sub> /DC-13	at $U_e$ = 60 V	Α	0.3				
Minimum load capacity		V mA	5 1				
Short-circuit protection for auxil	iary circuit						
Melting fuses operational class gG		Α	10				
Miniature circuit breakers C characteristic A			6 (prospective short-circuit current < 0.4 kA)				
Auxiliary switches for other sign	aling nurnoses						

Auxiliary switches for other signaling purposes For technical specifications, see the next page.

<sup>1)</sup> If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.

SIRIUS 3RV1 Motor Starter Protectors/Circuit Breakers up to 100 A

General data

## Mountable accessories

Front transverse auxiliary switches			
		Switching capacity for	or different voltages
		1 CO	1 NO + 1 NC, 2 NO
Rated operational current I <sub>e</sub>			
<ul> <li>At AC-15, alternating voltage</li> </ul>			
- 24 V	Α	4	2
- 230 V	Α	3	0.5
<ul> <li>At AC-12 = I<sub>th</sub>, alternating voltage</li> </ul>			
- 24 V	Α	10	2.5
- 230 V	Α	10	2.5
<ul> <li>At DC-13, direct voltage L/R 200 ms</li> </ul>			
- 24 V	A	1	1
- 48 V	A		0.3
- 60 V	Α		0.15
- 110 V	Α	0.22	
- 220 V	A	0.1	
Minimum load capacity	V	17	
· ·	mA	1	

Front transverse solid-state com	patible auxiliary switches		
			Switching capacity for different voltages
			1 CO
Rated operational voltage U <sub>e</sub>	Alternating voltage	V	125
Rated operational current I <sub>e</sub> /AC-14	at $U_{\rm e}$ = 125 V	Α	0.1
Rated operational voltage U <sub>e</sub>	Direct voltage L/R 200 ms	V	60
Rated operational current I <sub>e</sub> /DC-13	at $U_e = 60 \text{ V}$	Α	0.3
Minimum load capacity		V	5
		mA	1

Lateral auxiliary switches with signaling switch		
		Switching capacity for different voltages: Lateral auxiliary switch with 1 NO + 1 NC, 2 NO, 2 NC, 2 NO + 2 NC Signaling switch
Rated operational current I <sub>e</sub>		
<ul> <li>At AC-15, alternating voltage</li> <li>24 V</li> <li>230 V</li> <li>400 V</li> <li>690 V</li> </ul>	A A A	6 4 3 1
<ul> <li>At AC-12 = I<sub>th</sub>, alternating voltage</li> <li>24 V</li> <li>230 V</li> <li>400 V</li> <li>690 V</li> </ul>	A A A	10 10 10 10 10
• At DC, direct voltage <i>L/R</i> 200 ms - 24 V - 110 V - 220 V - 440 V	A A A	2 0.5 0.25 0.1
Minimum load capacity	V mA	17 1

Auxiliary releases				
		Undervoltage releases	Shunt releases	
Power consumption				
<ul><li>During pick-up</li><li>AC voltages</li><li>DC voltages</li></ul>	VA/W W	20.2/13 20	20.2/13 13 80	
<ul><li>During uninterrupted duty</li><li>AC voltages</li><li>DC voltages</li></ul>	VA/W W	7.2/2.4 2.1	 	
Response voltage				
Tripping	V	0.35 0.7 x U <sub>s</sub>	0.7 1.1 x U <sub>s</sub>	
• Pick-up	V	0.85 1.1 x <i>U</i> <sub>s</sub>		
Opening time maximum	ms	20		

## SIRIUS 3RV1 Motor Starter Protectors/Circuit Breakers up to 100 A

## General data

Short-circuit protection for auxiliary and control circuits		
Melting fuses operational class gG	А	10
Miniature circuit breakers C characteristic	Α	6 (prospective short-circuit current < 0.4 kA)

Conductor cross-sections for auxiliary and control circuits		
Connection type		Screw terminals
Terminal screw		Pozidriv size 2
Prescribed tightening torque	Nm	0.8 1.2
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected		
Solid or stranded	mm <sup>2</sup>	2 x (0.5 1.5) <sup>1)</sup> / 2 x (0.75 2.5) <sup>1)</sup>
• Finely stranded with end sleeve (DIN 46228-1)	$\text{mm}^2$	2 x (0.5 1.5) <sup>1)</sup> / 2 x (0.75 2.5) <sup>1)</sup>
AWG cables	AWG	2 x (18 14)
Connection type		Spring-type terminals <sup>2)3)</sup>
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected		
Solid or stranded	mm <sup>2</sup>	2 x (0.25 2.5)
• Finely stranded with end sleeve (DIN 46228-1)	$\text{mm}^2$	2 x (0.25 1.5)
• Finely stranded without end sleeve	$\text{mm}^2$	2 x (0.25 2.5)
AWG cables, solid or stranded	AWG	2 x (24 14)
Max. external diameter of the conductor insulation	mm	3.6

<sup>1)</sup> If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.

<sup>2)</sup> With conductor cross-sections ≤ 1 mm², an "insulation stop" must be used; see Chapter 3 "Controls – Contactors and Contactor Assemblies". → "Accessories".

<sup>&</sup>lt;sup>3)</sup> Corresponding opening tool 3RA2908-1A, see "Accessories", page 7/76.



## **Motor Starter Protectors/Circuit Breakers** SIRIUS 3RV1 Motor Starter Protectors up to 100 A

For motor protection

## Selection and ordering data

## CLASS 10 without auxiliary switches

		xiliary swit									
	Rated current	Suitable for three-phase motors <sup>1)</sup> with <i>P</i>	Setting range for thermal overload release		Short-circuit breaking capacity at 400 V AC	DT	Screw terminals	<b>+</b>	PU (UNIT, SET, M)	PS*	PG
	In		<u> </u>	<i>I</i> >	$I_{ m CU}$		Article No.	Price per PU			
	А	kW	Α	Α	kA						
Ī	40 50 63	18.5 22 30	28 40 36 50 45 63	520 650 819	50 50 50	<b>&gt;</b>	3RV1041-4FA10 3RV1041-4HA10 3RV1041-4JA10		1 1 1	1 unit 1 unit 1 unit	41E 41E 41E
	75 <sup>2)</sup> 90 <sup>2)</sup> 100 <sup>2)</sup>	37 45 45	57 75 70 90 80 100	975 1 170 1 235	50 50 50	<b>&gt;</b>	3RV1041-4KA10 3RV1041-4LA10 3RV1041-4MA10		1 1 1	1 unit 1 unit 1 unit	41E 41E 41E
-4LA10			•								
s, with i	ncrease	d switching 7.5	11 16	208	100	<b></b>	3RV1042-4AA10		1	1 unit	41E
	20 25 32	7.5 7.5 11 15	14 20 18 25 22 32	260 325 416	100 100 100	<b>* *</b>	3RV1042-4BA10 3RV1042-4DA10 3RV1042-4EA10		1 1 1	1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E
	40 50 63	18.5 22 30	28 40 36 50 45 63	520 650 819	100 100 100	<b>* *</b>	3RV1042-4FA10 3RV1042-4HA10 3RV1042-4JA10		1 1 1	1 unit 1 unit 1 unit	41E 41E 41E
4JA10	75 <sup>2)</sup> 90 <sup>2)</sup> 100 <sup>2)</sup>	37 45 45	57 75 70 90 80 100	975 1 170 1 235	100 100 100	<b>* *</b>	3RV1042-4KA10 3RV1042-4LA10 3RV1042-4MA10		1 1 1	1 unit 1 unit 1 unit	41E 41E 41E
3 20, wit	thout au	xiliary swit	ches								
S3, with i	ncrease	d switching	capacity								
	40 50 63	18.5 22 30	28 40 36 50 45 63	520 650 819	100 100 100	A A A	3RV1042-4FB10 3RV1042-4HB10 3RV1042-4JB10		1 1 1	1 unit 1 unit 1 unit	41E 41E 41E
	75 <sup>2)</sup> 90 <sup>2)</sup> 100 <sup>2)</sup>	37 45 45	57 75 70 90 80 100	975 1 170 1 235	100 100 100	A A A	3RV1042-4KB10 3RV1042-4LB10 3RV1042-4MB10		1 1 1	1 unit 1 unit 1 unit	41E 41E 41E
/1042-4KB10											

Auxiliary switches and other accessories can be ordered separately (see "Accessories" page 7/70 onwards).

Multi-unit/reusable packaging available on request.

<sup>1)</sup> Guide value for 4-pole standard motors at 50 Hz 400 V AC. The actual starting and rated data of the motor to be protected must be considered when selecting the units.

 $<sup>^{2)}</sup>$  For the use of 3RV104. motor starter protectors with an energy-efficient IE3 motor we recommend using a contactor for normal switching duty,

SIRIUS 3RV1 Motor Starter Protectors up to 100 A

For motor protection with overload relay function

## Selection and ordering data

## CLASS 10, with overload relay function (automatic RESET), without auxiliary switches

	Rated current	Suitable for three-phase motors <sup>1)</sup> with <i>P</i>	Setting range for thermal overload release	Instantaneous overcurrent release	Short-circuit breaking capacity at 400 V AC	DT	Screw terminals	<b></b>	PU (UNIT, SET, M)	PS*	PG
	I <sub>n</sub>		<u></u> (引	<i>I</i> >	$I_{ extsf{CU}}$		Article No.	Price per PU			
	Α	kW	Α	Α	kA						
Size S3, with in	ncrease	d switching	capacity <sup>2)</sup>								
	16 20 25 32	7.5 7.5 11 15	11 16 14 20 18 25 22 32	208 260 325 416	100 100 100 100	A A A	3RV1142-4AA10 3RV1142-4BA10 3RV1142-4DA10 3RV1142-4EA10		1 1 1 1	1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E
=	40 50 63	18.5 22 30	28 40 36 50 45 63	520 650 819	100 100 100	A A A	3RV1142-4FA10 3RV1142-4HA10 3RV1142-4JA10		1 1 1	1 unit 1 unit 1 unit	41E 41E 41E
3RV1142-4AA10	75 <sup>3)</sup> 90 <sup>3)</sup> 100 <sup>3)</sup>	37 45 45	57 75 70 90 80 100	975 1 170 1 235	100 100 100	A A A	3RV1142-4KA10 3RV1142-4LA10 3RV1142-4MA10		1 1 1	1 unit 1 unit 1 unit	41E 41E 41E

<sup>1)</sup> Guide value for 4-pole standard motors at 50 Hz 400 V AC. The actual starting and rated data of the motor to be protected must be considered when selecting the units.

Auxiliary switches and other accessories can be ordered separately (see "Accessories" page 7/70 onwards).

<sup>&</sup>lt;sup>2)</sup> Accessories (auxiliary releases) for mounting on the right cannot be used.

<sup>3)</sup> For the use of 3RV1142 motor starter protectors with an energy-efficient IE3 motor we recommend using a contactor for normal switching duty, see also page 7/53.

## Motor Starter Protectors/Circuit Breakers SIRIUS 3RV1 Motor Starter Protectors up to 100 A

For starter combinations

## Selection and ordering data

## Without auxiliary switches

Rated current three-phase release <sup>2</sup>   Thermal overload overcurrent releases   Capacity at 400 V AC												
A   kW   A   A   KA   A   KA   Size S3   A   3RV1341-4FC10   1   1   1   41E   50   22   Without   650   50   A   3RV1341-4JC10   1   1   1   1   41E   50   22   Without   975   50   A   3RV1341-4JC10   1   1   1   1   41E   1003   45   Without   1   1235   50   A   3RV1341-4JC10   1   1   1   1   1   1   1   1   1			three-phase motors <sup>1)</sup>		overcurrent	breaking capacity at	DT	Screw terminals	<b>+</b>	(UNIT,	PS*	PG
Size S3		$I_{n}$		<u>द</u>	<i>I</i> >	$I_{\mathrm{CU}}$		Article No.				
40 18.5 Without 520 50 A 3RV1341-4FC10 1 1 unit 41E 63 30 Without 819 50 A 3RV1341-4HC10 1 1 unit 41E 75³] 37 Without 975 50 A 3RV1341-4HC10 1 1 unit 41E 100³] 45 Without 1235 50 A 3RV1341-4HC10 1 1 unit 41E 25 11 Without 208 100 A 3RV1341-4HC10 1 1 unit 41E 25 11 Without 325 100 A 3RV1342-4HC10 1 1 unit 41E 32 15 Without 416 100 A 3RV1342-4HC10 1 1 unit 41E 25 11 Without 325 100 A 3RV1342-4HC10 1 1 unit 41E 25 12 Without 416 100 A 3RV1342-4HC10 1 1 unit 41E 25 12 Without 416 100 A 3RV1342-4HC10 1 1 unit 41E 25 12 Without 416 100 A 3RV1342-4HC10 1 1 unit 41E 25 12 Without 520 100 A 3RV1342-4HC10 1 1 unit 41E 25 12 Without 520 100 A 3RV1342-4HC10 1 1 unit 41E 25 12 Without 520 100 A 3RV1342-4HC10 1 1 unit 41E 25 12 Without 520 100 A 3RV1342-4HC10 1 1 unit 41E 25 12 Without 520 100 A 3RV1342-4HC10 1 1 unit 41E 25 12 Without 520 100 A 3RV1342-4HC10 1 1 unit 41E 25 12 Without 650 100 A 3RV1342-4HC10 1 1 unit 41E 25 12 Without 650 100 A 3RV1342-4HC10 1 1 unit 41E 25 12 Without 650 100 A 3RV1342-4HC10 1 1 unit 41E 25 12 Without 819 100 A 3RV1342-4HC10 1 1 unit 41E 25 12 Without 819 100 A 3RV1342-4HC10 1 1 unit 41E 25 Witho		Α	kW	A	Α	kA						
50   22   Without   819   50   A   3RV1341-4HC10   1   1 unit   41E	Size S3											
63 30 Without 819 50 A 3RV1341-4JC10 1 1 unit 41E  753 37 Without 975 50 A 3RV1341-4KC10 1 1 unit 41E  903 45 Without 1 170 50 A 3RV1341-4LC10 1 1 unit 41E  1003 45 Without 1 235 50 A 3RV1341-4MC10 1 1 unit 41E  3RV1341-4JC10  Size S3, with increased switching capacity  16 7.5 Without 208 100 A 3RV1342-4AC10 1 1 unit 41E  20 7.5 Without 260 100 A 3RV1342-4BC10 1 1 unit 41E  25 11 Without 325 100 A 3RV1342-4BC10 1 1 unit 41E  25 15 Without 416 100 A 3RV1342-4BC10 1 1 unit 41E  40 18.5 Without 416 100 A 3RV1342-4BC10 1 1 unit 41E  40 18.5 Without 520 100 A 3RV1342-4BC10 1 1 unit 41E  40 18.5 Without 520 100 A 3RV1342-4BC10 1 1 unit 41E  50 22 Without 650 100 A 3RV1342-4BC10 1 1 unit 41E  63 30 Without 650 100 A 3RV1342-4BC10 1 1 unit 41E  63 30 Without 975 100 A 3RV1342-4BC10 1 1 unit 41E  753 37 Without 819 100 A 3RV1342-4BC10 1 1 unit 41E  903 45 Without 1 170 100 A 3RV1342-4BC10 1 1 unit 41E  1003 45 Without 1 235 100 A 3RV1342-4BC10 1 1 unit 41E	1									1		
75 <sup>3)</sup> 37 Without 975 50 A 3RV1341-4KC10 1 1 unit 41E 100 <sup>3)</sup> 45 Without 1 235 50 A 3RV1341-4MC10 1 1 unit 41E 100 <sup>3)</sup> 45 Without 1 235 50 A 3RV1341-4MC10 1 1 unit 41E 100 <sup>3)</sup> 45 Without 208 100 A 3RV1342-4AC10 1 1 unit 41E 20 7.5 Without 260 100 A 3RV1342-4BC10 1 1 unit 41E 25 11 Without 325 100 A 3RV1342-4BC10 1 1 unit 41E 32 15 Without 416 100 A 3RV1342-4BC10 1 1 unit 41E 32 15 Without 416 100 A 3RV1342-4BC10 1 1 unit 41E 40 18.5 Without 520 100 A 3RV1342-4BC10 1 1 unit 41E 50 22 Without 650 100 A 3RV1342-4BC10 1 1 unit 41E 63 30 Without 650 100 A 3RV1342-4BC10 1 1 unit 41E 63 30 Without 819 100 A 3RV1342-4BC10 1 1 unit 41E 63 30 Without 819 100 A 3RV1342-4BC10 1 1 unit 41E 63 30 Without 819 100 A 3RV1342-4BC10 1 1 unit 41E 63 30 Without 819 100 A 3RV1342-4BC10 1 1 unit 41E 63 30 Without 819 100 A 3RV1342-4BC10 1 1 unit 41E 63 30 Without 819 100 A 3RV1342-4BC10 1 1 unit 41E 63 30 Without 819 100 A 3RV1342-4BC10 1 1 unit 41E 63 30 Without 819 100 A 3RV1342-4BC10 1 1 unit 41E 63 30 Without 819 100 A 3RV1342-4BC10 1 1 unit 41E 80 30 45 Without 1235 100 A 3RV1342-4BC10 1 1 unit 41E 80 30 45 Without 1235 100 A 3RV1342-4BC10 1 1 unit 41E	A CONTRACTOR OF THE PARTY OF TH									1		
3RV1341-4JC10  Size S3, with increased switching capacity  16 7.5 Without 260 100 A 3RV1342-4AC10 1 1 unit 41E 20 7.5 Without 260 100 A 3RV1342-4BC10 1 1 unit 41E 25 11 Without 325 100 A 3RV1342-4BC10 1 1 unit 41E 32 15 Without 416 100 A 3RV1342-4BC10 1 1 unit 41E 40 18.5 Without 520 100 A 3RV1342-4BC10 1 1 unit 41E 40 18.5 Without 650 100 A 3RV1342-4BC10 1 1 unit 41E 50 22 Without 650 100 A 3RV1342-4BC10 1 1 unit 41E 63 30 Without 819 100 A 3RV1342-4C10 1 1 unit 41E 63 37 Without 975 100 A 3RV1342-4C10 1 1 unit 41E 753 37 Without 975 100 A 3RV1342-4C10 1 1 unit 41E 903 45 Without 1170 100 A 3RV1342-4BC10 1 1 unit 41E 1003 45 Without 1235 100 A 3RV1342-4BC10 1 1 unit 41E	1	75 <sup>3)</sup>		Without	975		Α	3RV1341-4KC10		1	1 unit	
3RV1341-4JC10  Size S3, with increased switching capacity  16 7.5 Without 208 100 A 3RV1342-4AC10 1 1 unit 41E 20 7.5 Without 260 100 A 3RV1342-4BC10 1 1 unit 41E 25 11 Without 325 100 A 3RV1342-4BC10 1 1 unit 41E 32 15 Without 416 100 A 3RV1342-4BC10 1 1 unit 41E 40 18.5 Without 520 100 A 3RV1342-4FC10 1 1 unit 41E 50 22 Without 650 100 A 3RV1342-4FC10 1 1 unit 41E 50 22 Without 650 100 A 3RV1342-4BC10 1 1 unit 41E 63 30 Without 819 100 A 3RV1342-4JC10 1 1 unit 41E 63 30 Without 975 100 A 3RV1342-4JC10 1 1 unit 41E 753 37 Without 975 100 A 3RV1342-4JC10 1 1 unit 41E 903 45 Without 1170 100 A 3RV1342-4JC10 1 1 unit 41E 1003 45 Without 1 235 100 A 3RV1342-4JC10 1 1 unit 41E		90 <sup>3)</sup>								1		
Size S3, with increased switching capacity   16   7.5   Without   208   100   A   3RV1342-4AC10   1   1   1   1   1   1   1   1   1	22	100	40	Without	1 200	00	,,	ORC TO TI THIS TO		'	Turne	712
16 7.5 Without 208 100 A 3RV1342-4AC10 1 1 unit 41E 20 7.5 Without 260 100 A 3RV1342-4BC10 1 1 unit 41E 25 11 Without 325 100 A 3RV1342-4BC10 1 1 unit 41E 32 15 Without 416 100 A 3RV1342-4BC10 1 1 unit 41E 40 18.5 Without 520 100 A 3RV1342-4BC10 1 1 unit 41E 50 22 Without 650 100 A 3RV1342-4BC10 1 1 unit 41E 63 30 Without 819 100 A 3RV1342-4BC10 1 1 unit 41E 63 37 Without 819 100 A 3RV1342-4BC10 1 1 unit 41E 75 <sup>3</sup> 37 Without 975 100 A 3RV1342-4BC10 1 1 unit 41E 90 <sup>3</sup> 45 Without 1 170 100 A 3RV1342-4BC10 1 1 unit 41E 100 <sup>3</sup> 45 Without 1 235 100 A 3RV1342-4BC10 1 1 unit 41E												
20 7.5 Without 260 100 A 3RV1342-4BC10 1 1 unit 41E 25 11 Without 325 100 A 3RV1342-4DC10 1 1 unit 41E 32 15 Without 416 100 A 3RV1342-4EC10 1 1 unit 41E 40 18.5 Without 520 100 A 3RV1342-4FC10 1 1 unit 41E 50 22 Without 650 100 A 3RV1342-4HC10 1 1 unit 41E 63 30 Without 819 100 A 3RV1342-4JC10 1 1 unit 41E 75 <sup>3</sup> 37 Without 975 100 A 3RV1342-4JC10 1 1 unit 41E 90 <sup>3</sup> 45 Without 1 170 100 A 3RV1342-4KC10 1 1 unit 41E 100 <sup>3</sup> 45 Without 1 235 100 A 3RV1342-4HC10 1 1 unit 41E	Size S3, with ir	ncrease	d switching	capacity								
25 11 Without 325 100 A 3RV1342-4DC10 1 1 unit 41E 32 15 Without 416 100 A 3RV1342-4EC10 1 1 unit 41E 40 18.5 Without 520 100 A 3RV1342-4FC10 1 1 unit 41E 50 22 Without 650 100 A 3RV1342-4HC10 1 1 unit 41E 63 30 Without 819 100 A 3RV1342-4JC10 1 1 unit 41E 753 37 Without 975 100 A 3RV1342-4JC10 1 1 unit 41E 903 45 Without 1 170 100 A 3RV1342-4JC10 1 1 unit 41E 1003 45 Without 1 235 100 A 3RV1342-4MC10 1 1 unit 41E	100									1		
32   15   Without   416   100   A   3RV1342-4EC10   1   1   1   1   41E	A STATE OF THE PARTY OF THE PAR									1		
50 22 Without 650 100 A 3RV1342-4HC10 1 1 unit 41E 63 30 Without 819 100 A 3RV1342-4JC10 1 1 unit 41E 753 37 Without 975 100 A 3RV1342-4KC10 1 1 unit 41E 903 45 Without 1 170 100 A 3RV1342-4LC10 1 1 unit 41E 1003 45 Without 1 235 100 A 3RV1342-4MC10 1 1 unit 41E		32	15	Without			Α	3RV1342-4EC10		1	1 unit	
63 30 Without 819 100 A 3RV1342-4JC10 1 1 unit 41E  75 <sup>3)</sup> 37 Without 975 100 A 3RV1342-4KC10 1 1 unit 41E  90 <sup>3)</sup> 45 Without 1 170 100 A 3RV1342-4LC10 1 1 unit 41E  100 <sup>3)</sup> 45 Without 1 235 100 A 3RV1342-4MC10 1 1 unit 41E										1		41E
75 <sup>3)</sup> 37 Without 975 100 A <b>3RV1342-4KC10</b> 1 1 unit 41E 90 <sup>3)</sup> 45 Without 1 170 100 A <b>3RV1342-4LC10</b> 1 1 unit 41E 100 <sup>3)</sup> 45 Without 1 235 100 A <b>3RV1342-4MC10</b> 1 1 unit 41E	4									1		
90 <sup>3)</sup> 45 Without 1 170 100 A <b>3RV1342-4LC10</b> 1 1 unit 41E 100 <sup>3)</sup> 45 Without 1 235 100 A <b>3RV1342-4MC10</b> 1 1 unit 41E	1	75 <sup>3)</sup>								1		
	se !	90 <sup>3)</sup>	45	Without	1 170	100	Α	3RV1342-4LC10		1	1 unit	41E
	3BV1342-4JC10	100 <sup>3)</sup>	45	Without	1 235	100	А	3RV1342-4MC10		1	1 unit	41E

<sup>1)</sup> Guide value for 4-pole standard motors at 50 Hz 400 V AC. The actual starting and rated data of the motor to be protected must be considered when selecting the units.

Auxiliary switches and other accessories can be ordered separately (see "Accessories" page 7/70 onwards).

Multi-unit/reusable packaging available on request.

<sup>2)</sup> For overload protection of the motors, appropriate overload relays must be used.


<sup>3)</sup> For the use of 3RV134. motor starter protectors with an energy-efficient IE3 motor we recommend using a contactor for normal switching duty, see also page 7/53.

SIRIUS 3RV1 Motor Starter Protectors up to 100 A

## For fuse monitoring

## Selection and ordering data

## Without auxiliary switches



Note

Multi-unit/reusable packaging available on request.

The auxiliary switch required for signaling must be ordered separately.

#### Accessories

	Version	Contacts	DT	Screw terminals	<b>+</b>	PU (UNIT, SET, M)	PS*	PG
				Article No.	Price per PU			
Mountable au	ixiliary switches (essential accessories)							,
3RV1901-1E	Transverse auxiliary switches With screw terminals, mountable on front	1 NO + 1 NC	•	3RV1901-1E		1	1 unit	41E
3RV1901-1A	Lateral auxiliary switches With screw terminals, mountable on the left	1 NO + 1 NC	<b>&gt;</b>	3RV1901-1A		1	1 unit	41E

Additional auxiliary switches and other accessories, see "Accessories" page 7/70 onwards.

## Motor Starter Protectors/Circuit Breakers SIRIUS 3RV1 Circuit Breakers up to 100 A

For system protection according to UL 489/CSA C22.2 No. 5

## Selection and ordering data

## Without auxiliary switches

Circuit breakers for system protection and non-motor loads according to UL/CSA

	Rated current <sup>1)</sup>	Thermal overload releases (non-adjustable)	Instantaneous overcurrent release	Short-circuit break capacity at 480 Y/277 V AC <sup>2)</sup>	Ü	DT	Screw terminals	<b></b>	PU (UNIT, SET, M)	PS*	PG
	<i>I</i> <sub>n</sub> <sup>1)</sup>	<u>.</u>	<i>I</i> >	$I_{ m bc}$	$I_{bc}$		Article No.	Price per PU			
Size S3	A	A	A	kA	kA						
	10 15	10 15	150 225	65 65	65 65	B B	3RV1742-5AD10 3RV1742-5BD10		1 1	1 unit 1 unit	41E 41E
	20 25 30 35	20 25 30 35	260 325 390 455	65 65 65 65	65 65 65	B B B B	3RV1742-5CD10 3RV1742-5DD10 3RV1742-5ED10 3RV1742-5FD10		1 1 1 1	1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E
	40 45 50	40 45 50	520 585 650	65 65 65	  	B B B	3RV1742-5FD10 3RV1742-5GD10 3RV1742-5HD10 3RV1742-5JD10		1 1 1	1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E
3RV1742-5FD10	60 70	60 70	780 910	65 65		B B	3RV1742-5LD10 3RV1742-5QD10		1 1	1 unit 1 unit	41E 41E

Rated value 100 % according to UL 489 and IEC 60947-2 ("100 % rated breaker").

Transverse auxiliary switches must not be mounted, lateral auxiliary switches can be ordered separately (see "Accessories" page 7/70 onwards).


<sup>&</sup>lt;sup>2)</sup> Values for 600 Y/347 V AC, see page 7/57.

SIRIUS 3RV1 Motor Starter Protectors up to 100 A

## For distance protection

## Selection and ordering data

## Voltage transformer motor starter protectors with auxiliary switches (1 CO)



#### Accessories

3RV1901-1A

	Version	Contacts	DT	Screw terminals	4	PU (UNIT, SET, M)	PS*	PG
				Article No.	Price per PU			
Mountable aux	xiliary switches for other signaling pur	poses						
	<b>Lateral auxiliary switches</b> With screw terminals, mountable on the left	1 NO + 1 NC	•	3RV1901-1A		1	1 unit	41E

Additional auxiliary switches and other accessories, see "Accessories" page 7/70 onwards.

otectors/Circuit Breakers

## SIRIUS 3RV1 Motor Starter Protectors/Circuit Breakers up to 100 A Accessories

Mountable accessories

## Overview

## Mounting location and function

The 3RV1 motor starter protectors/circuit breakers have three main contact elements. In order to achieve maximum flexibility, auxiliary switches, signaling switches, auxiliary releases and

These components are easily fitted to the switches without the use of any tools according to requirements.

Overview graphic, see page 7/51

The overall width of the auxiliary release is 18 mm.

isolator modules can be supplied sep	parately.	Overview graphic, see page 7/51.					
Front side Notes:  A maximum of four auxiliary contacts with auxiliary switches can be mounted on each motor starter protector.  Transverse auxiliary switches must not be used for the 3RV1742 circuit breakers.	Transverse auxiliary switches, solid-state compatible transverse auxiliary switches  1 NO + 1 NC or 2 NO or 1 CO	An auxiliary switch block can be inserted transversely on the front. The overall width of the motor starter protectors remains unchanged.					
Left-hand side     Notes:     A maximum of four auxiliary contacts with auxiliary switches can be mounted on each motor starter protector/circuit breakers.     Lateral auxiliary switches (two contacts) and signaling switches can be mounted	Lateral auxiliary switches (2 contacts) 1 NO + 1 NC or 2 NO or 2 NC	One of the three lateral auxiliary switches can be mounted on the left side per motor starter protector/circuit breaker. The contacts of the auxiliary switch close and open together with the main contacts of the motor starter protector/circuit breaker.  The width of the lateral auxiliary switch with two contacts is 9 mm.					
separately or together.  The signaling switch cannot be used for the 3RV1742 circuit breakers.	Lateral auxiliary switches (4 contacts) 2 NO + 2 NC	One lateral auxiliary switch with four contacts can be mounted on the left side per motor starter protector/circuit breaker. The contacts of the auxilia switch close and open together with the main contacts of the motor starte protector/circuit breaker.  The width of the lateral auxiliary switch with four contacts is 18 mm.					
	Signaling switches Tripping 1 NO + 1 NC Short circuit 1 NO + 1 NC	One signaling switch can be mounted on the left side of each motor starter protector.  The signaling switch has two contact systems.  One contact system always signals tripping irrespective of whether this was caused by a short circuit, an overload or an auxiliary release. The other contact system only switches in the event of a short circuit. There is no signaling as a result of switching off with the actuator.  In order to be able to switch on the motor starter protector again after a short circuit, the signaling switch must be reset manually after the error cause has been eliminated.  The overall width of the signaling switch is 18 mm.					
Right-hand side	Auxiliary releases						
Notes:  One auxiliary release can be mounted per motor starter protector/circuit breaker.	Shunt releases	For remote-controlled tripping of the motor starter protector/circuit breaker. The release coil should only be energized for short periods (see circuit diagrams).					
<ul> <li>Accessories cannot be mounted at the right-hand side of the 3RV11 motor starter</li> </ul>	or						
protectors for motor protection with overload relay function.	Undervoltage releases	Trips the motor starter protector/circuit breaker when the voltage is inter- rupted and prevents the motor from being restarted accidentally when the voltage is restored. Used for remote-controlled tripping of the motor starter protector/circuit breaker.					
		Particularly suitable for EMERGENCY-STOP disconnection by way of corresponding EMERGENCY-STOP pushbuttons according to DIN EN 60204-1.					
	or						
	Undervoltage releases with leading auxiliary contacts 2 NO	Function and use as for the undervoltage release without leading auxiliary contacts, but with the following additional function: the auxiliary contacts will open in switch position OFF to deenergize the coil of the undervoltage release, thus interrupting energy consumption. In the "tripped" position, these auxiliary contacts are not guaranteed to open. The leading contacts permit the motor starter protector/circuit breaker to reclose.					
		T					

For a complete overview of which accessories can be used for the various motor starter protectors, see page 7/3.

# SIRIUS 3RV1 Motor Starter Protectors/Circuit Breakers up to 100 A Accessories

#### Mountable accessories

#### Selection and ordering data Contacts For motor starter DT Screw terminals PS\* PG Version (H) protectors/ (UNIT, circuit breakers SET, M) Article No. Price per PU Size Auxiliary switches<sup>1)</sup> 1 CO 3RV1901-1D Transverse auxiliary switches S00, S3 1 unit With screw terminals, 1 NO + 1 NC 3RV1901-1E 1 unit 41E 00 00 mountable on front 2 NO 3RV1901-1F 1 1 unit 41E 3RV1901-1E Electronic compatible 1 CO S00, S3 Α 3RV1901-1G 1 unit 41E transverse auxiliary switches 0 0 0 With screw terminals. front mountable, 3RV1901-1G for operation in dusty atmosphere and in solid-state circuits with low operating currents Covers for transverse auxiliary S00, S3 • 3RV1901-0H 1 10 units 41E switches 3RV1901-0H Lateral auxiliary switches 1 NO + 1 NC S00, S3 $\triangleright$ 3RV1901-1A 1 unit 41E 3RV1901-1B 3RV1901-1C With screw terminals, 2 NO ь 1 unit 41E mountable on the left 2 NC $\triangleright$ 1 1 unit 41F 2 NO + 2 NC Α 3RV1901-1J 1 unit 41E 3RV1901-1A 3RV1901-1J

<sup>1)</sup> Each motor starter protector can be fitted with one transverse and one lateral auxiliary switch. The lateral auxiliary switch with 2 NO + 2 NC is used without a transverse auxiliary switch. Transverse auxiliary switches must not be used for the 3RV1742 circuit breakers.

	Version	Contacts	For motor starter protectors/ circuit breakers	DT	Spring-type terminals		PU (UNIT, SET, M)	PS*	PG
	. 1)		Size		Article No.	Price per PU			
Auxiliary swit	ches'								
3RV1901-2E 3RV1901-2A	<b>Transverse auxiliary switches</b> With spring-type terminals, mountable on the front	1 NO + 1 NC 2 NO	S00, S3	<b>&gt;</b>	3RV1901-2E 3RV1901-2F		1 1	1 unit 1 unit	41E 41E
	Lateral auxiliary switches	1 NO + 1 NC	S00, S3	<b></b>	3RV1901-2A		1	1 unit	41E
	With spring-type terminals, mountable on the left	2 NO 2 NC		<b>A A</b>	3RV1901-2B 3RV1901-2C		1 1	1 unit 1 unit	41E 41E

<sup>1)</sup> Each motor starter protector can be fitted with one transverse and one lateral auxiliary switch. Transverse auxiliary switches must not be used for the 3RV1742 circuit breakers.

## otectors/Circuit Breakers

## SIRIUS 3RV1 Motor Starter Protectors/Circuit Breakers up to 100 A Accessories

## **Mountable accessories**

	Version	For motor starter protectors	DT	Screw terminals	<b></b>	PU (UNIT, SET, M)	PS*	PG	
			Size		Article No.	Price per PU			
Signaling swit	tches <sup>1)</sup>								
OD) MODEL AND	Signaling switches One signaling switch can be mounted on the left per motor starter protector.	Separate tripped and short-circuit alarms, 1 NO + 1 NC each	\$3	•	3RV1921-1M		1	1 unit	41E
3RV1921-1M									
<ol> <li>This accessory</li> </ol>	cannot be used for the	3RV1742 circuit breakers.							

	Rated control supply voltage U <sub>s</sub>					For motor starter	DT	Screw terminals	<b>(1)</b>	PU	PS*	PG
	AC 50 Hz	AC 60 Hz	AC 50/60 Hz 100 % ON period <sup>1)</sup>	AC/DC 50/60 Hz, DC 5 s ON period <sup>2)</sup>	DC	protectors/ circuit breakers				(UNIT, SET, M)		
	V	V	V	V	V	Size		Article No.	Price per PU			
Auxiliary relea		·	•	•	<u>,                                     </u>	0120						
-370		voltage	releases									
3RV1902-1DP0	24 110  230 400	120 208 240 440	   	   	24    	\$3 \$3 \$3 \$3 \$3 \$3 \$3	A A A A	3RV1902-1AB4 3RV1902-1AB0 3RV1902-1AF0 3RV1902-1AM1 3RV1902-1AP0 3RV1902-1AV0		1 1 1 1 1	1 unit 1 unit 1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E 41E 41E
	415 500	480 600				S3 S3	A A	3RV1902-1AV1 3RV1902-1AS0		1	1 unit 1 unit	41E 41E
			releases with acts 2 NO	leading								
	230 400 415	240 440 480	 	  	  	\$3 \$3 \$3	A A A	3RV1922-1CP0 3RV1922-1CV0 3RV1922-1CV1		1 1 1	1 unit 1 unit 1 unit	41E 41E 41E
	Shunt releases											
	   	   	20 24 90 110 210 240 350 415 500	20 70 70 190 190 330 330 500 500	   	\$3 \$3 \$3 \$3 \$3 \$3	A A A	3RV1902-1DB0 3RV1902-1DF0 3RV1902-1DP0 3RV1902-1DV0 3RV1902-1DS0		1 1 1 1	1 unit 1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E 41E

<sup>1)</sup> The voltage range is valid for 100 % (infinite) ON period. The response voltage lies at 0.9 of the lower limit of the voltage range.

 $<sup>^{2)}\,</sup>$  The voltage range is valid for 5 s ON period at AC 50/60Hz and DC. The response voltage lies at 0.85 of the lower limit of the voltage range.

<sup>3)</sup> One auxiliary release can be mounted on the right per motor starter protector (does not apply to 3RV11 motor starter protectors with overload relay function).

## SIRIUS 3RV1 Motor Starter Protectors/Circuit Breakers up to 100 A

## Accessories


**Busbar accessories** 

#### Overview

#### 8US busbar adapters for 40 mm and 60 mm systems

The motor starter protectors/circuit breakers are mounted directly with the aid of busbar adapters on busbar systems with 40 mm and 60 mm center-to-center clearance in order to save space and to reduce infeed times and costs. Busbar adapters for busbar systems with 40 mm center-to-center clearance are suitable for copper busbars with a width of 12 mm to 15 mm, while those with 60 mm center-to-center clearance are suitable for copper busbars with a width of 12 mm to 30 mm. The busbars can be 4 to 5 mm or 10 mm thick.

The motor starter protectors/circuit breakers are snapped onto the adapter and connected on the line side. This prepared unit is then plugged directly onto the busbar system, and is thus connected both mechanically and electrically at the same time. For further busbar adapters for snap-mounting direct-on-line starters and reversing starters as well as additional accessories such as line terminals and outgoing terminals, flat copper profile, etc., see Catalog LV 10 "Low-Voltage Power Distribution and Electrical Installation Technology"



SIRIUS load feeders with busbar adapters snapped onto busbars

#### Selection and ordering data

#### 8US busbar adapters





8US1111-4SM00

8US1211-4TR00

For motor starter protectors	Rated current	Connecting cable	Adapter length	Adapter width	Rated voltage	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
Size	A	AWG	mm	mm	V						
Busbar adapter	s for 40 mm sy	stems									
For flat copper prof Width: 12 mm and Thickness: 5 mm ar	15 mm	DIN 46433									
S3 S3	100 100	4 4	182 182	70 72	400 <sup>1)</sup> 415 690 <sup>2)</sup>	<b>&gt;</b>	8US1111-4SM00 8US1011-4TM00		1 1	1 unit 1 unit	140 140
Busbar adapter	s for 60 mm sy	stems									
For flat copper prof Width: 12 mm and 3 Thickness: 5 mm ar also for T and doub	30 mm nd 10 mm										
\$3 \$3 \$3 <sup>3)</sup>	100 100 70 <sup>4)</sup>	4 4 4	182 182 215	70 72 72	400 <sup>1)</sup> 415 690 <sup>2)</sup> 600 <sup>4)</sup>	A A	8US1111-4SM00 8US1211-4TM00 8US1211-4TR00		1 1 1	1 unit 1 unit 1 unit	140 140 140

- 1) At rated voltage
  - ≤ 400 V: short-circuit breaking capacity 50 kA,
  - > 400 to 460 V: short-circuit breaking capacity 25 kA.
- 2) Short-circuit breaking capacity 415/500/525 V AC:

- Up to  $I_n = 25$  A: max. 30 kA Up to  $I_n = 90$  A: max. 16 kA Up to  $I_n = 100$  A: max. 6 kA Up to  $I_n = 100$  A: max. 6 kA Short-circuit breaking capacity 690 V AC:
- Max. 12 kA
- 3) This busbar adapter is approved specially for 3RV1742 circuit breakers for applications according to UL/CSA
- 4) Values according to UL/CSA
   Rated current: 70 A at 600 V AC;
  - Short-circuit breaking capacity 480 V AC: 65 kA, up to  $I_n = 30$  A; 480 Y/277 V AC: 65 kA, 600 Y/347 V AC: 20 kA

For additional busbar adapters, see Catalog LV 10 "Low-Voltage Power Distribution and Electrical Installation Technology".

### otectors/Circuit Breakers


# SIRIUS 3RV1 Motor Starter Protectors/Circuit Breakers up to 100 A Accessories

Rotary operating mechanisms


#### Overview

#### Door-coupling rotary operating mechanisms

Motor starter protectors/circuit breakers with a rotary operating mechanism can be mounted in a control cabinet and operated externally by means of a door-coupling rotary operating mechanism. When the cabinet door with motor starter protector/circuit breaker is closed, the operating mechanism is coupled. When the motor starter protector/circuit breaker closes, the coupling is locked which prevents the door from being opened unintentionally. This interlock can be defeated by the maintenance personnel. In the OPEN position, the rotary operating mechanism can be secured against reclosing with up to three padlocks. Inadvertent opening of the door is not possible in this case either.



SIRIUS 3RV1926-0K door-coupling rotary operating mechanism



SIRIUS 3RV2946-2B door-coupling rotary operating mechanism for arduous conditions

#### Remote motorized operating mechanisms

3RV1 motor starter protectors/circuit breakers are manually operated controls. They automatically trip in case of an overload or short circuit. Intentional remote-controlled tripping is possible by means of a shunt release or an undervoltage release. Reclosing is only possible directly at the motor starter protector/circuit breaker.

The remote motorized operating mechanism allows the motor starter protectors/circuit breakers to be opened and closed by electrical commands. This enables a load or an installation to be isolated from the network or reconnected to it from an operator panel.


If the motor starter protector/circuit breaker is tripped as a result of overload or short circuit, it will be in tripped position. For reclosing, the remote motorized operating mechanism must first be set manually or electrically to the 0 position (electrically by means of the Open command). Then it can be reclosed.

The remote motorized operating mechanism is available for motor starter protectors/circuit breakers in size S3 for control voltages of 230 V AC and 24 V DC. The motor starter protector/circuit breaker is fitted into the remote motorized operating mechanism as shown in the drawing.

In the "MANUAL" position, the motor starter protector/circuit breaker in the remote motorized operating mechanism can continue to be switched manually on site. In the "AUTOMATIC" position, the motor starter protector/circuit breaker is switched by means of electrical commands. The switching command must be applied for a minimum of 100 ms. The remote motorized operating mechanism closes the motor starter protector/circuit breaker after a maximum of 1 s. On voltage failure during the switching operation it is ensured that the motor starter protector/circuit breaker remains in the "OPEN" or "CLOSED" position. In the "MANUAL" and "OFF" position, the remote motorized operating mechanism can be locked with a padlock.

#### RESET function

The RESET button on the motorized operating mechanism serves to reset any 3RV1921-1M signaling switch that might be installed.



SIRIUS 3RV1946-3A.. remote motorized operating mechanism

### SIRIUS 3RV1 Motor Starter Protectors/Circuit Breakers up to 100 A Accessories

#### Rotary operating mechanisms

#### Technical specifications

Remote motorized operating mechanisms		
Туре		3RV1946
Max. power consumption  • At U <sub>S</sub> = 24 V DC  • At U <sub>S</sub> = 230 V AC	W VA	48 170
Operating range		0.85 1.1 x <i>U</i> <sub>s</sub>
Minimum command duration at $U_{S}$	S	0.1
Max. command duration		Unlimited (uninterrupted operation)
Max. total break time, remote-controlled	S	2
Ready to reclose after approx.	S	2.5
Switching frequency	1/h	25
Internal back-up fuse • 230 V AC • 24 V DC	A A	0.8 1.6
Connection type of control cables		Plug-in connectors with screw terminals
Shock resistance acc. to IEC 60068-2-27	<i>g</i> /ms	25/11 (square and sine pulse)

#### Selection and ordering data

Version	Color of actuator	Version of extension shaft	For motor starter protectors/ circuit breakers	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
		mm	Size						

#### Door-coupling rotary operating mechanisms



3RV2926-0R

The door-coupling rotary operating mechanisms consist of a knob, a coupling driver and a 130/330 mm long extension shaft (6 mm x 6 mm).

The door-coupling rotary operating mechanisms are designed to degree of protection IP64. The door locking device prevents accidental opening of the control cabinet door in the ON position of the motor starter protector/circuit breaker. The OFF position can be locked with up to 3 padlocks.

Door-coupling rotary operating mechanisms	Black	130 330	S3 S3	<b>&gt;</b>	3RV2926-0B 3RV2926-0K	1 1	1 unit 1 unit	41E 41E
EMERGENCY STOP door- coupling rotary operating mechanisms	Red/yellow	130 330	S3 S3	•	3RV2926-0C 3RV2926-0L	1 1	1 unit 1 unit	41E 41E

#### Door-coupling rotary operating mechanisms for arduous conditions



3RV2946-2B

The door-coupling rotary operating mechanisms consist of a knob, a coupling driver, an extension shaft of 300 mm in length (8 mm x 8 mm), a spacer and two metal brackets, into which the motor starter protector/circuit breaker is inserted.

The door-coupling rotary operating mechanisms are designed to degree of protection IP65. The door interlocking reliably prevents opening of the control cabinet door in the ON position of the motor starter protector/circuit breaker. The OFF position can be locked with up to three padlocks.

Laterally mountable auxiliary releases and two-pole auxiliary switches can be used.

S3 S3

AC 50/60 Hz, 230 V

24 V DC

The door-coupling rotary operating mechanisms thus meet the requirements for isolating functions according to IEC 60947-2.

Door-coupling rotary operating mechanisms	Gray	300	S3	•	3RV2946-2B	1	1 unit	41E
EMERGENCY STOP door- coupling rotary operating mechanisms	Red/yellow	300	S3	•	3RV2946-2C	1	1 unit	41E

Version	Rated control supply voltage $U_{\rm S}$	For motor starter protectors/ circuit breakers	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
		Size						

Χ

3RV1946-3AP0

3RV1946-3AB4

#### Remote motorized operating mechanisms

Remote

motorized

operating mechanisms

	1
1	-
1	6
ı	
Į	-

3RV1946-3A.

41F

41E

1 unit

1 unit

# otectors/Circuit Breakers

SIRIUS 3RV1 Motor Starter Protectors/Circuit Breakers up to 100 A Accessories


**Mounting accessories** 

#### Overview

#### Terminal blocks for "Self-Protected Combination Motor Controllers (Type E)" according to UL 508/UL 60947-4-1

The 3RV10 motor starter protector/circuit breakers in size S3 are approved according to UL 508/UL 60947-4-1 as "Self-Protected Combination Motor Controllers" (Type E).

This requires increased clearance and creepage distances (1 inch and 2 inches respectively) at the input side of the device, which are achieved by replacing the standard box terminal with the 3RT1946-4GA07 terminal block.



Terminal block (Type E) SIRIUS 3RT1946-4GA07

According to CSA, the terminal blocks can be omitted when the device is used as a "Self-Protected Combination Motor Controller" (Type E).

#### Selection and ordering data

#### Accessories

Accessories							
	Version	For motor starter protectors/ circuit breakers	DT	Article No. Price per PU		PS*	PG
		Size					
Covers							
	<b>Terminal covers for box terminals</b> Additional touch protection to be fitted at the box terminals (2 units mountable per device)	S3	<b>&gt;</b>	3RT1946-4EA2	1	1 unit	41B
	Terminal covers For cable lug and busbar connection for maintaining the required voltage clearances and as touch protection if box terminal is removed (2 units can be mounted per motor starter protector/circuit breaker)	S3	В	3RT1946-4EA1	1	1 unit	41B
3RV1 (size S3) with 3RT1946-4EA1 (left) 3RV1908-0P (right)	Scale covers Sealable, for covering the set current scale	S3	•	3RV1908-0P	100	10 units	41E
Fixing accessories							
	<b>Push-in lugs</b> For screwing the motor starter protector onto mounting plates	S00	Α	3RB1900-0B	100	10 units	41F
3RB1900-0B	For each motor starter protector, two units are required.						
Terminal blocks for " according to UL 508/	Self-Protected Combination Motor Control UL 60497-4-1	lers (Type	E)"				
2DT1046 4CA07	Note: UL 508/UL 60947-4-1 approval demands 1-inch cle 2-inch creepage distance for "Combination Motor Type E". The following terminal blocks must be use in 3RV10 motor starter protector size S3.	Controllers					
3RT1946-4GA07	The terminal blocks are not required for use accor	ding to CSA.					
	With size S3, these terminal blocks cannot be used combination with a transverse auxiliary switch.	d in					
	<b>Terminal block type E</b> for extended clearance and creepage distances (1 and 2 inch)	S3	В	3RT1946-4GA07	1	1 unit	41B
Auxiliary terminals, 3	B-pole						·
and the	For connection of auxiliary and control cables to the main conductor connections (for one side)	S3	В	3RT1946-4F	1	1 unit	41B
3RT1946-4F							

SIRIUS 3RV1 Motor Starter Protectors/Circuit Breakers up to 100 A

# Accessories

Mounting accessories

# Link modules

	Actuating voltage of contactor	Size Contactors	protecte		DT	Screw terminals	<b>+</b>	PU (UNIT, SET, M)	PS*	PG
						Article No.	Price per PU			
Link modules from m	otor starter protec	ctor/circuit breal	ker to con	itactor						
	For mechanical and starter protector/circle terminals									
(i) / 300 mm	Single-unit packagi	ng								
13 2 4	AC	S3	S3		<b></b>	3RA1941-1AA00		1	1 unit	41B
11 11 11 11	DC	S3	S3		<b></b>	3RA1941-1BA00		1	1 unit	41B
N N N	Multi-unit packaging	g								
3BA1941-1AA00	AC	S3	S3		<b>&gt;</b>	3RA1941-1A		1	5 units	41B
311A 1941-1AA00	DC	S3	S3		<b>&gt;</b>	3RA1941-1B		1	5 units	41B
Miscellaneous acces	ssories									
	Version	Size	Color	For motor starter protectors/ circuit breakers	DT	Spring-type terminals	<u> </u>	PU (UNIT, SET, M)	PS*	PG
						Article No.	Price			
				Size			per PU			
Tools for opening sp	ring-type terminals	5								
3RA2908-1A	Screwdrivers For all SIRIUS devices with spring-type terminals	Length approx. 200 mm, 3.0 mm x 0.5 mm	Titanium gray/ black, partially insulated	S3	А	3RA2908-1A		1	1 unit	41B

# otectors/Circuit Breakers


SIRIUS 3RV1 Motor Starter Protectors/Circuit Breakers up to 100 A Accessories

Front plates

# Overview

# Front plates

Motor starter protectors are frequently required to be actuated in any enclosure. Front plates equipped with a rotary operating mechanism for 3RV1.4. motor starter protectors/circuit breakers are available for this purpose.



Front plate for size S3

#### Selection and ordering data

	Version	Degree of protection	For motor starter protectors	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
			Size						
Front plates									
	Molded-plastic front plates with rotary operating mechanism, lockable in 0 position	IP55 (front side)	S3	•	3RV1923-4B		1	1 unit	41E
	For actuation of 3RV1 motor starter protectors in any enclosure								
3RV1923-4B	Molded-plastic front plates with EMERGENCY-STOP rotary operating mechanism, red/yellow, lockable in 0 position	IP55 (front side)	S3	Α	3RV1923-4E		1	1 unit	41E
	EMERGENCY-STOP actuation of 3RV1 motor starter protectors in any enclosure								
	Version	Us	protectors	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
		V	Size						
Indicator lights									
	Indicator lights For all enclosures and front plates	110 120 220 240	S3	C	3RV1903-5B 3RV1903-5C		1 1	1 unit 1 unit	41E 41E
	With LED lamp for versions 110 120 V, with glow lamp for versions 220 500 V	380 415 480 500		CC	3RV1903-5E 3RV1903-5G		1 1	1 unit 1 unit	41E 41E
3RV1903-5B	<ul> <li>With colored lenses red, green, yellow, orange and clear</li> </ul>								

#### SIRIUS 3RV1 Molded Case Motor Starter Protectors up to 800 A

#### **General data**

#### Overview



SIRIUS 3RV1063-7AL10 molded case motor starter protector

The 3RV10 and 3RV13 molded case motor starter protectors for up to 800 A are compact, current-limiting motor starter protectors which can be used above all in motor feeders for special voltages of 440 V, 480 V, 550 V and 690 V. They are used for switching and protecting three-phase motors and other loads with rated currents up to 800 A.

#### Note:

For motor feeders above 100 A and at 400 V and 500 V. the 3VL molded case circuit breakers must be used, see Catalog LV 10 "Low-Voltage Power Distribution and Electrical Installation Technology".

#### Type of construction

The molded case motor starter protectors are available in 4 widths:

- 3RV1353 width 90 mm, max. rated current 32 A, at 550 V AC suitable for three-phase motors up to 22 kW
- 3RV1.6. width 105 mm, max. rated current 250 Å, at 690 V AC suitable for three-phase motors up to 160 kW
- 3RV1.7. width 140 mm, max. rated current 630 A at 690 V AC suitable for three-phase motors up to 315 kW
- 3RV1.83 width 210 mm, max. rated current 800 A, at 690 V AC suitable for three-phase motors up to 500 kW

The 3RV1 molded case motor starter protectors for up to 800 A can be mounted in horizontal, vertical or lying arrangement directly on a mounting plate or mounting rail. Their rated data are adversely affected as the result.

The phase barriers for better insulation between the phases are included in the scope of supply, and it is essential to use them.

The motor starter protectors can be supplied through top and bottom terminals without impairing their function, enabling them to be installed in any type of switchgear without any further steps.

#### Connection methods

The 3RV1 molded case motor starter protectors for up to 800 A are suitable solely for screw connection.

Screw terminals

The terminals are indicated in the corresponding tables by the symbols shown on orange backgrounds.

#### Article No. scheme

Digit of the Article No.	1st - 3rd	4th	5th	6th	7th		8th	9th	10th	11th	12th		13th	14th	15th	16th	
						-						-					
Molded case motor starter protectors	3 R V																
SIRIUS 1st generation		1															
Type of motor starter protector																	
Size																	
Breaking capacity																	
Setting range for overload release																	
Trip class (CLASS)																	
Connection methods																	
With or without auxiliary switch																	
Special versions																	
Example	3 R V	1	0	6	3	_	7	Α	L	1	0						

#### Note:

The Article No. scheme is presented here merely for information purposes and for better understanding of the logic behind the article numbers.

For your orders, please use the article numbers quoted in the catalog in the Selection and ordering data.

# Motor Starter Protectors/Circuit Breakers SIRIUS 3RV1 Molded Case Motor Starter Protectors up to 800 A

**General data** 

#### Benefits

- · High short-circuit breaking capacity in the feeder
- Optimum usability in motor feeders for the special voltages 440 V, 480 V, 550 V and 690 V
- · Compact design

- The releases are available both in purely magnetic (up to 32 A) and in solid-state versions (100 A to 800 A)
- Available for motor or starter protection (short-circuit protection alone)

#### Application

#### Operating conditions

The 3RV1 molded case motor starter protectors for up to 800 A can be operated at ambient temperatures between -25 °C and +70 °C. They can be used according to IEC 60721-2-1 in the most difficult environmental conditions with a hot and damp

Since operational currents, starting currents and current peaks are different even for motors with identical power ratings due to the inrush current, the motor ratings in the selection tables are only guide values. The specific rated and start up data of the motor to be protected is always paramount to the choice of the most suitable molded case motor starter protectors.

The 3RV1 molded case motor starter protectors up to 800 A have not been tested for use with frequency converters. The possibility of premature tripping in such applications cannot therefore be ruled out.

#### Possible uses

The 3RV1 molded case motor starter protectors for up to 800 A are suitable as switching and protection devices for motors. The following versions are available:

- For motor protection;
  - the overload and short-circuit releases are designed for optimized protection and direct-on-line starting of induction squirrel-cage motors. The motor starter protectors have an electronic release which not only provides short-circuit and overload protection but is also sensitive to phase failure and phase unbalance and offers protection in the event of rotor blockage.
- For starter combinations;
  - these molded case motor starter protectors are used for short-circuit protection in combinations of circuit breaker, motor contactor and overload relay. They are equipped with a purely magnetic release (up to 32 A) or a solid-state release (100 A to 800 A).

#### Standards and specifications

The electronic releases for motor protection comply with IEC 60947-4-1. Isolating features are also compliant with IEC 60947-2.

The 3RV1 molded case motor starter protectors comply in addition with IEC 60068-2-6 (shock and vibration strength) and are certified for the specifications of the most important marine classification societies:

- RINA
- Det Norske Veritas
- · Bureau Veritas
- Lloyds Register of Shipping
- Germanischer Lloyd
- American Bureau of Shipping

# SIRIUS 3RV1 Molded Case Motor Starter Protectors up to 800 A

#### General data

# Technical specifications

General data										
Туре		3RV1063	3RV1073	3RV1083	3RV1353	3RV1363	3RV1364	3RV1373	3RV1374	3RV1383
Dimensions				• • • • • • • • • • • • • • • • • • • •					•	0.11.1000
• w = 1   F	mm	105	140	210	90	105	105	140	140	210
• H	mm	205	205	268	130	205	205	205	205	268
• D	mm	139	139	159	102	139	139	139	139	159
Standard			7-2, EN 609	947-2						
Motor protection		✓								
Starter combinations					✓					
Rated current I <sub>n</sub>	Α	160	400	630	160	250		400, 630		630, 800
Number of poles		3								
Rated operational voltage $U_{\rm e}$ 50 60 Hz AC	V	690								
Rated impulse withstand voltage $U_{imp}$	V	8								
Rated insulation voltage <i>U</i> <sub>i</sub>	V	1 000			800	1 000				
Test voltage at industrial frequency for 1 min	V	3 500			3 000	3 500				
Rated ultimate short-circuit breaking capacity $I_{\text{cu}}$										
• At 220/230 V AC, 50 60 Hz	kA	200			120	200				
• At 380/415 V AC, 50 60 Hz	kA	120		100	85	120	200	120	200	100
• At 440 V AC, 50 60 Hz	kA	100		80	75	100	180	100	180	80
• At 500 V AC, 50 60 Hz	kA	85		65	50	85	150	85	150	65
• At 550 V AC, 50 60 Hz	kA				35					
• At 690 V AC, 50 60 Hz	kA	70		30	10	70	80	70	80	30
Rated service short-circuit breaking capacity $I_{cs}$ (% of $I_{cu}$ )										
<ul> <li>At 220/230 V AC, 50 60 Hz</li> </ul>	%	100		75	100					75
• At 380/415 V AC, 50 60 Hz	%	100		75		100				75
• At 440 V AC, 50 60 Hz	%	100		75		100				75
• At 500 V AC, 50 60 Hz	%	100		75		100		100 <sup>1)</sup> /75 <sup>2)</sup>	100	75
• At 690 V AC, 50 60 Hz	%	100		75		100		100 <sup>1)</sup> /50 <sup>2)</sup>	100	75
Rated short-circuit making capacity (415 V)	kA	264		220	187	264	440	264	440	220
Break time (415 V at I <sub>cu</sub> )	ms	5	6	7	3	5		6		7
Category (IEC 60947-2)		А	B (400 A), A (630 A)	В	А			B (400 A), A (630 A)		В
Isolating features		/								
Trip class CLASS		10A, 10, 2	20, 30							
Releases										
Magnetic type					/					
Electronic (motor protection)		1			3)					
Electronic (starter combinations)						1				
Permissible ambient temperature										
Operation	°C	-25 +70	) <sup>4)</sup>							
Storage	°C	-40 +70								
Mechanical endurance										
Operating cycles		20 000			25 000	20 000				
Operating cycles per hour		240	120		240			120		
Electrical endurance										
Operating cycles		8 000	7 000	5 000	8 000			7 000		5 000
Operating cycles per hour (415 V AC)		120	60		120			60		
- 1- 1- 1- 1- 1- 1- 1- 1- 1- 1- 1- 1- 1-										

<sup>✓</sup> Has this function

<sup>--</sup> Does not have this function

<sup>1)</sup> Value applies for 3RV1373-7GN10 molded case motor starter protectors.

 $<sup>^{2)}\,</sup>$  Value applies for 3RV1373-7JN10 molded case motor starter protectors.

<sup>3)</sup> For overload protection of the motors, appropriate overload relays must be used.

<sup>4)</sup> From 50 °C, please note derating, see "Reference Manual "Protection Equipment – Circuit Breakers · Molded Case Circuit Breakers", http://support.automation.siemens.com/WW/view/en/35681600.

SIRIUS 3RV1 Molded Case Motor Starter Protectors up to 800 A

Main circuit terminals						
Туре		3RV1353	3RV1.6.	3RV1.7.	3RV1083-7JL10, 3RV1383-7JN10	3RV1383-7KN10
Terminal dimensions						
Front-accessible standard terminals						
Busbars/cable lug						
Number	Unit(s)	11			2	
Dimensions						
• W	mm	20	25	35	40	50
• D • H	mm mm	5 7.5	8 9.5	10 11	5 12	
Lock hasp diameter	mm	6.5	8.5	10.5	7	
Front-extended terminals						
Busbars						
Number	Unit(s)	1		2		
Dimensions						
• W	mm	20	- 40	30	40	50
D    Lock hasp diameter	mm mm	4 8.5	10 10	7 11	5	5 14
Cable lug		0.0				
Number	Unit(s)	1		2		
Dimensions	(-)					
• W	mm	20		30	40	50
Lock hasp diameter	mm	8.5	10	11		14
Front-extended cable terminals for copper cable						
Busbars, flexible						
Number	Unit(s)	1				
Dimensions W x D x N						
• W	mm	13	15.5	24		
<ul><li>D</li><li>N (= number of laminations)</li></ul>	mm mm	0.5 10	0.8	1		
Cable lug, flexible						
Number	Unit(s)	1 or 2				
Dimensions						
• For 1 unit	mm <sup>2</sup> mm <sup>2</sup>	1 70	2.5 120	16 240		
• For 2 units	mm <sup>2</sup>	1 50	2.5 95	16 150		
Cable lug, rigid		1		1 0 0		
Number Dimensions	Unit(s)	1		1 or 2		
For 1 unit	mm <sup>2</sup>	1 05	0.E 10E	16 200		
For 1 unit     For 2 units (for outside mounting)	mm <sup>2</sup> mm <sup>2</sup>	1 95	2.5 185	16 300 120 240		
Rear terminals						
Busbars						
Number	Unit(s)	1		2		
Dimensions						
• W	mm	20		30	40	50
<ul><li>D</li><li>Lock hasp diameter</li></ul>	mm mm	4 8.5	10	7 11	5 14	
200K Haop diamotol	111111	0.0			1 7	

SIRIUS 3RV1 Molded Case Motor Starter Protectors up to 800 A

Auxiliary switches		
Туре		3RV1991-1.A0
Rated operational current I <sub>e</sub>		
• At 250 V AC/DC		
<ul> <li>At AC-14 (utilization category according to IEC 60947-5-1)</li> <li>Control supply voltage 125 V</li> <li>Control supply voltage 250 V</li> </ul>	A A	6 5
<ul> <li>At DC-13 (utilization category according to IEC 60947-5-1)</li> <li>Control supply voltage 125 V</li> <li>Control supply voltage 250 V</li> </ul>	A A	0.3 0.15
• At 24 V DC		
- Control supply voltage 24 V	mA	≥ 0.75
- Control supply voltage 5 V	mA	≥1

Auxiliary releases					
		Power consul	mption during p	ick-up	
Molded case motor starter protectors		3RV1353		3RV1.6., 3R	V1.7., 3RV1.83
Version		AC	DC	AC	DC
Undervoltage releases		3RV1952-1A.0	)	3RV1982-1A	۸.0
• 24 30 V AC/DC • 110 127 V AC/110 125 V DC • 220 240 V AC/220 250 V DC		1.5 VA 2 VA 2.5 VA	1.5 W 2 W 2.5 W	6 VA 6 VA 6 VA	150 W 150 W 150 W
Opening times	ms	15	15	≤ 25	≤ 15
Shunt releases		3RV1952-1E.0	)	3RV1982-1E	.0
• 24 30 V AC/DC • 110 127 V AC/110 125 V DC • 220 240 V AC/220 250 V DC		50 VA 50 VA 50 VA	50 W 50 W 50 W	150 VA 150 VA 150 VA	150 W 150 W 150 W
Opening times	ms	15	15	15	15

SIRIUS 3RV1 Molded Case Motor Starter Protectors up to 800 A

For motor protection

# Selection and ordering data

#### CLASS 10A, 10, 20, 30; without auxiliary switch

Rated current	inverse-time delayed	Operating current of the instantaneous short-circuit releases " $I_i$ "	breaking	DT	Screw terminals	<b></b>	PU (UNIT, SET, M)	PS*	PG
$I_{n}$	5	[ >	$I_{\mathrm{CU}}$		Article No.	Price per PU			
А	Α	Α	kA						

#### With electronic releases

# 1

Standard switching capacity, adjustable short-circuit and overload release, TU 4
--

100	40 100	600 1 300	120
160	64 160	960 2 080	120
200	80 200	1 200 2 600	120
400	160 400	2 400 5 200	120
630	252 630	3 780 8 190	100

D 3RV1063-7AL10 D 3RV1063-7CL10 D 3RV1063-7DL10 D 3RV1073-7GL10 D 3RV1083-7JL10

1 1 unit 41E 1 1 unit 41E 1 1 unit 41E 1 1 unit 41E 1 1 unit 41E

3RV10.3-7.L10

TU = trip unit (release)

Further accessories can be ordered separately (see "Accessories" page 7/85 onwards).

SIRIUS 3RV1 Molded Case Motor Starter Protectors up to 800 A

#### For starter combinations

#### Selection and ordering data

#### Without auxiliary switches

Rated current	Inverse-time delayed overload release "L" $I_{\rm R}$	Operating current of the instantaneous short-circuit releases " $I_i$ " $I_i$	breaking capacity	Screw terminals	<b>+</b>	PU (UNIT, SET, M)	PS*	PG
$I_{n}$	<u> </u>	<i>I</i> >	$I_{\mathrm{CU}}$	Article No.	Price per PU			
Α	Α	Α	kA					

#### With magnetic releases



3RV1353-6.P10

Standard switching capacity	/, non-adjustable short-circuit release, 1	"U 1
-----------------------------	--	------

Standard Switching Capacity, non-adjustable short-circuit release, 10 1										
1	Without	13	85	D	3RV1353-6AP10	1	1 unit	41E		
1.6	Without	21	85	D	3RV1353-6BP10	1	1 unit	41E		
2	Without	26	85	D	3RV1353-6CP10	1	1 unit	41E		
3.2	Without	42	85	D	3RV1353-6DP10	1	1 unit	41E		
4	Without	52	85	D	3RV1353-6EP10	1	1 unit	41E		
5	Without	65	85	D	3RV1353-6FP10	1	1 unit	41E		
6.5	Without	85	85	D	3RV1353-6GP10	1	1 unit	41E		
8.5	Without	111	85	D	3RV1353-6HP10	1	1 unit	41E		
12.5	Without	163	85	D	3RV1353-6JP10	1	1 unit	41E		
Standard switching capacity, adjustable short-circuit release, TU 2										
20	Without	120 240	85	D	3RV1353-6LM10	1	1 unit	41E		
32	Without	192 384	85	D	3RV1353-6MM10	1	1 unit	41E		

#### With electronic release

ŝ	MENTER!
	2
e.	71

3RV13..-7.N10

Standard switching ca	pacity, adjustable short	t-circuit release. TU

u	Standa	rd switching cap	acity, adjustable s	hort-circuit rele	ase, T	TU 3					
	100	Without	100 1 000	120	D	3RV1363-7AN10	1	1 unit	41E		
	160	Without	160 1 600	120	D	3RV1363-7CN10	1	1 unit	41E		
	250	Without	250 2 500	120	D	3RV1363-7EN10	1	1 unit	41E		
ı	400	Without	400 4 000	120	D	3RV1373-7GN10	1	1 unit	41E		
	630	Without	630 6 300	120	D	3RV1373-7JN10	1	1 unit	41E		
	630	Without	630 6 300	100	D	3RV1383-7JN10	1	1 unit	41E		
	800	Without	800 8 000	100	D	3RV1383-7KN10	1	1 unit	41E		
	Increased switching capacity, adjustable short-circuit release, TU 3										
	100	Without	100 1 000	200	D	3RV1364-7AN10	1	1 unit	41E		
	160	Without	160 1 600	200	D	3RV1364-7CN10	1	1 unit	41E		
	250	Without	250 2 500	200	D	3RV1364-7EN10	1	1 unit	41E		
	400	Without	400 4 000	200	D	3RV1374-7GN10	1	1 unit	41E		

TU = trip unit (release)

Further accessories can be ordered separately (see "Accessories" page 7/85 onwards).

#### More information

Configuration Manual "SIRIUS Configuration – Selection Data for Fuseless Load Feeders", see

http://support.automation.siemens.com/WW/view/en/68115040.

# otectors/Circuit Breakers

# SIRIUS 3RV1 Molded Case Motor Starter Protectors up to 800 A Accessories

**Mountable accessories** 

Selection	and	ordering	data
-----------	-----	----------	------

Selection and ord	ering data									
	Туре	Version		For molded case motor starter protectors	DT	Screw terminals	<b>(†)</b>	PU (UNIT, SET, M)	PS*	PG
						Article No.	Price per PU			
Auxiliary switches	;									
CHELED.	Auxiliary switches for front mounting	1 signaling si + 1 tripped s (250 V AC/DI	ignal	3RV1353, 3RV1.6.	D	3RV1991-1AA0		1	1 unit	41E
		3 signaling si + 1 tripped s (250 V AC/D0		3RV1.83	D	3RV1991-1BA0		1	1 unit	41E
2		•	witches Off-On		D	3RV1991-1CA0		1	1 unit	41E
3RV1991-1AA0	Connection cables for auxiliary switches	Length 2 m, (	6-pole	3RV1353, 3RV1.6.	D	3RV1991-1FA0		1	1 unit	41E
	Ciritorios			3RV1.83						
	Туре	Rated contro voltage <i>U</i> <sub>s</sub> AC 50/60 Hz	l supply	For molded case motor starter protectors	DT	Screw terminals	<b>+</b>	PU (UNIT, SET, M)	PS*	PG
		V	V			Article No.	Price per PU			
Auxiliary releases		•								
	Undervoltage releases for front mounting	24 30 110 127 220 240	24 30 110 125 220 250	3RV1353	D D D	3RV1952-1AA0 3RV1952-1AD0 3RV1952-1AE0		1 1 1	1 unit 1 unit 1 unit	41E 41E 41E
		24 30 110 127 220 240	24 30 110 125 220 250	3RV1.6.  3RV1.83	D D D	3RV1982-1AA0 3RV1982-1AD0 3RV1982-1AF0		1 1 1	1 unit 1 unit 1 unit	41E 41E 41E
3RV1952-1AA0										
(2/15/14)	Shunt releases for front mounting	24 30 110 127 220 240	24 30 110 125 220 250	3RV1353	D D D	3RV1952-1EA0 3RV1952-1ED0 3RV1952-1EF0		1 1 1	1 unit 1 unit 1 unit	41E 41E 41E
		24 30 110 127 220 240	24 30 110 125 220 250	3RV1.6.  3RV1.83	D D D	3RV1982-1EA0 3RV1982-1ED0 3RV1982-1EF0		1 1 1	1 unit 1 unit 1 unit	41E 41E 41E
3RV1952-1EA0		1 " 0		00//1050		OD1/4000 1712				
	Connection cables for undervoltage and shunt releases	Length 2 m, 6-pole		3RV1353, 3RV1.6. 	D	3RV1992-1FA0		1	1 unit	41E

3RV1.83

SIRIUS 3RV1 Molded Case Motor Starter Protectors up to 800 A

Accessories

#### Rotary operating mechanisms, mounting accessories

Selection and orde	ring data								
	Version		For molded case motor starter protectors	DT	Screw terminals	<b>(+)</b>	PU (UNIT, SET, M)	PS*	PG
					Article No.	Price per PU			
Rotary operating m	echanisms								
and the second	Lever-type rotary operating mechanisms	With adjustable distance, with lock/door interlocking (padlocks are not included in scope of supply)	3RV1353 3RV1.6., 3RV1.7. 3RV1.83	D D D	3RV1956-0BA0 3RV1976-0BA0 3RV1986-0BA0		1 1 1	1 unit 1 unit 1 unit	41E 41E 41E
3RV19.6-0BA0									
LINEO GEN	Motorized operating mechanisms	With stored energy mechanism, 220 250 V AC/DC	3RV1.6., 3RV1.7. 3RV1.83	D D	3RV1976-3AP3 3RV1986-3AP3		1	1 unit 1 unit	41E 41E
3RV19.6-3AP3									
Connections									
3RV1975-1CA0	Connections	Front-extended (1 set = 6 units)	3RV1353 3RV1.6. 3RV1.7. 3RV1.83-7J.10 3RV1.83-7KN10	D D D D	3RV1955-1AA0 3RV1965-1BA0 3RV1975-1CA0 3RV1985-1DA0 3RV1985-1EA0		1 1 1 1	1 unit 1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E 41E
3RV1955-3AA0		Rear (1 set = 3 units)	3RV1353 3RV1.6. 3RV1.7. 3RV1.83	D D D	3RV1955-3AA0 3RV1965-3AA0 3RV1975-3AA0 3RV1985-3AA0		1 1 1 1	1 unit 1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E 41E
3RV1975-2AA0	Cable terminals	Front-extended (1 set = 6 units)	3RV1353 3RV1.6. 3RV1.77G.10 3RV1.73-7JN10	D D D	3RV1955-2AA0 3RV1965-2BA0 3RV1975-2CA0 3RV1975-2DA0		1 1 1 1	1 unit 1 unit 1 unit 1 unit	41E 41E 41E 41E

General data

#### Overview



		8 6 6	SANGE OF	witten .		-	
Features	3RU21	3RU11	3RB30/3RB31	3RB20/3RB21	3RB22/3RB23	3RB24	Benefits
General data							
Sizes	S00 S2	\$3	S00 S2	S3 S12	S00 S12	S00 S12	<ul> <li>Are coordinated with the dimensions, connections and technical characteristics of the other devices in the SIRIUS modular system (contactors, etc.,)</li> <li>Permit the mounting of slim and compact load feeders in widths of 45 mm (S00, S0), 55 mm (S2), 70 mm (S3), 120 mm (S6) and 145 mm (S10/S12); this does not include the current measuring modules for the 3RB22 to 3RB24 evaluation modules</li> </ul>
							<ul><li>sizes S00 to S3</li><li>Simplify configuration</li></ul>
Seamless current range	0.11 80 A	18 100 A	0.1 80 A	12.5 630 A	0.3 630 A (up to 820 A) <sup>1)</sup>	0.3 630 A (up to 820 A) <sup>1)</sup>	Allows easy and consistent configuration
Protection fun	ctions						
Tripping due to overload	✓	✓	✓	✓	✓	✓	Provides optimum inverse-time delayed protection of loads against excessive temperature rises due to overload
Tripping due to phase unbalance	<b>✓</b>	/	<b>✓</b>	1	<b>✓</b>	/	Provides optimum inverse-time delayed protection of loads against excessive temperature rises due to phase unbalance
Tripping due to phase failure	✓	✓	✓	✓	✓	✓	Minimizes heating of three-phase motors during phase failure
Protection of single-phase loads	✓	✓			✓	✓	Enables the protection of single-phase loads
Tripping in the event of overheating by integrated thermistor motor protection function	2)	2)	2)	2)	,	/	Provides optimum temperature-dependent protection of loads against excessive temperature rises e.g. for stator-critical motors or in the event of insufficient coolant flow, contamination of the motor surface or for long starting or braking operations  Eliminates the need for additional special equipment  Saves space in the control cabinet  Reduces wiring outlay and costs
Tripping in the event of a ground fault by internal ground-fault detection (activatable)	-	-	(only 3RB31)	(only 3RB21)	/	/	<ul> <li>Provides optimum protection of loads against high-resistance short circuits or ground faults due to moisture, condensed water, damage to the insulation material, etc.</li> <li>Eliminates the need for additional special equipment</li> <li>Saves space in the control cabinet</li> <li>Reduces wiring outlay and costs</li> </ul>
✓ Available				1	Motor currents	s up to 820 A ca	n be recorded and evaluated by a current

- ✓ Available
- -- Not available

- 1) Motor currents up to 820 A can be recorded and evaluated by a current measuring module, e.g. 3RB2906-2BG1 (0.3 to 3 A), in combination with a 3UF1868-3GA00 (820 A/1 A) series transformer. 3UF18 transformers, see Chapter 10, "Monitoring and Control Devices" → "SIMOCODE 3UF Motor Management and Control Devices".
- 2) The SIRIUS 3RN thermistor motor protection devices can be used to provide additional temperature-dependent protection.













Features	3RU21	3RU11	3RB30/3RB31	3RB20/3RB21	3RB22/3RB23	3RB24	Benefits
Features							
RESET function	1	✓	✓	✓	✓	✓	Allows manual or automatic resetting of the device
Remote RESET function	(by means of separate module)	(by means of separate module)	(only with 3RB31 and external auxiliary voltage 24 V DC)	(only with 3RB21 and external auxiliary voltage 24 V DC)	(electrically via external button)	(electrically with button or via IO-Link)	Allows the remote resetting of the device
TEST function for auxiliary contacts	✓	✓	✓	✓	✓	✓	Allows easy checking of the function and wiring
TEST function for electronics			✓	✓	✓	✓	Allows checking of the electronics
Status display	✓	✓	✓	✓	✓	✓	Displays the current operating state
Large current adjustment button	✓	✓	✓	✓	✓	✓	Makes it easier to set the relay exactly to the correct current value
Integrated auxiliary contacts (1 NO + 1 NC)	1	<b>✓</b>	1	1	<b>✓</b> (2 ×)		<ul> <li>Allows the load to be switched off if necessary</li> <li>Can be used to output signals</li> </ul>
Integrated auxiliary contacts (1 CO and 1 NO in series)						✓	Enables the controlling of contactors directly from the higher-level control system through IO-Link
IO-Link connection						✓	<ul><li>Reduction of wiring in the control cabinet</li><li>Enables communication</li></ul>
Connection of optional hand-held device						✓	Enables local operation
Communication	on capability t	through IO-Li	nk				
Full starter functionality through IO-Link						✓	<ul> <li>Enables in combination with the SIRIUS 3RT contactors the assembly of communication-capable motor starters (direct-on-line, reversing and wye-delta starting)</li> </ul>
Reading out of diagnostics functions						✓	Enables the reading out of diagnostics information such as overload, open circuit, ground fault, etc.
Reading out of current values						✓	Enables the reading out of current values and their direct processing in the higher- level control system
Reading out all set parameters						✓	Enables the reading out of all set parameters, e.g. for plant documentation

<sup>✓</sup> Available

<sup>--</sup> Not available













Design of load feeders	
Short-circuit strength up to 100 kA at 690 V (in conjunction with the corre- sponding fuses or the corre- sponding motor starter protector)  Electrical and mechanical matching to 3RT contactors  Straight- through trans- formers for main circuit <sup>2</sup> ) (in this case the cables are routed through openings of the overload relay and connected directly to the box terminals of	
strength up to 100 kA at 690 V (in conjunction with the corresponding fuses or the corresponding fuses or the corresponding motor starter protector)  Electrical and mechanical matching to 3RT contactors  Straight— through transformers for main circuit <sup>2</sup> (in this case the cables are routed through the feed-through openings of the overload relay and connected directly to the box terminals of	
mechanical matching to 3RT contactors  Straight-through transformers for main circuit <sup>2</sup> (in this case the cables are routed through the feed-through openings of the overload relay and connected directly to the box terminals of	ent of
through transformers for main circuit <sup>2</sup> ) (in this case the cables are routed through the feed-through openings of the overload relay and connected directly to the box terminals of	well as
Spring-type	
Spring-type	
Ring terminal (S00, S0)	
Full starter	rtérs
Starter function ✓ • Integration of feeders via IO-Link in the control system up to 630 A or 820 A	

<sup>✓</sup> Available

<sup>--</sup> Not available

 $<sup>^{1)}\,</sup>$  Exception: up to size S3, only stand-alone installation is possible.

<sup>&</sup>lt;sup>2)</sup> Alternatively available for screw terminals.



Features	3RU21	3RU11	3RB30/3RB31	3RB20/3RB21	3RB22/3RB23	3RB24	Benefits
Other features							
Temperature compensation	✓	✓	✓	1	✓	1	Allows the use of the relays at high temperatures without derating
							<ul> <li>Prevents premature tripping</li> </ul>
							Allows compact installation of the control cabinet without distance between the devices/load feeders
							<ul> <li>Simplifies configuration</li> </ul>
							Enables space to be saved in the control cabinet
Very high long- term stability	✓	✓	✓	✓	✓	<b>√</b>	Provides safe protection for the loads even after years of use in severe operating conditions
Wide setting ranges			<b>✓</b> (1:4)	<b>✓</b> (1:4)	<b>✓</b> (1:10)	<b>✓</b> (1:10)	<ul> <li>Minimize the configuration outlay and costs</li> </ul>
							<ul> <li>Minimize storage overheads, storage costs, tied-up capital</li> </ul>
Fixed trip class	CLASS 10, CLASS 10A	CLASS 10	3RB30: CLASS 10E or CLASS 20E	3RB20: CLASS 10 or CLASS 20			Optimum motor protection for standard starts
Trip classes adjustable on the device			3RB31: ✓	3RB21: <b>✓</b>	✓	1	Enables solutions for very fast starting motors requiring special protection (e.g. Ex motors)
CLASS 5E, 10E, 20E, 30E							<ul> <li>Enables heavy starting solutions</li> </ul>
,							<ul> <li>Reduces the number of variants</li> </ul>
							<ul> <li>Minimizes the configuring outlay and costs</li> </ul>
							<ul> <li>Minimizes storage overhead, storage costs, and tied-up capital</li> </ul>
Low power loss			✓	/	✓	1	<ul> <li>Reduces energy consumption and energy costs (up 98 % less energy is used than for thermal overload relays)</li> </ul>
							Minimizes temperature rises of the contactor and control cabinet – in some cases this may eliminate the need for controlgear cabinet cooling
							Direct mounting to contactor saves space, even for high motor currents (i.e. no heat decoupling is required)
Internal power supply	1)	1)	✓	✓			Eliminates the need for configuration and connecting an additional control circuit
Supplied from an external voltage through IO-Link						<b>✓</b>	Eliminates the need for configuration and connecting an additional control circuit

<sup>✓</sup> Available

<sup>--</sup> Not available

SIRIUS 3RU11 and 3RU21 thermal overload relays use a bimetal contactor and therefore do not require a control supply voltage.

General data



		2 6 5	FINANCE		******	-	
Features	3RU21	3RU11	3RB30/3RB31	3RB20/3RB21	3RB22/3RB23	3RB24	Benefits
Other charact	eristics (conti	nued)					
Overload warning					✓	<b>✓</b>	<ul> <li>Indicates imminent tripping of the relay directly on the device due to overload, phase unbalance or phase failure through flickering of the LEDs or in the case of the 3RB24 as a signal through IO-Link</li> </ul>
							Allows the imminent tripping of the relay to be signaled
							Allows measures to be taken in time in the event of inverse-time delayed overloading of the load for an extended period over the current limit
							<ul> <li>Eliminates the need for an additional device</li> </ul>
							Saves space in the control cabinet
							Reduces wiring outlay and costs
Analog output					1	/	Allows the output of an analog output signal for actuating moving-coil instru- ments, feeding programmable logic controllers or transfer to bus systems
							Eliminates the need for an additional measuring transducer and signal converter
							Saves space in the control cabinet

- ✓ Available
- -- Not available

• Reduces wiring outlay and costs

#### General data

#### Overview of overload relays - matching contactors

Overload		Current	Contactors	s (type, size, rating	in kW)					
relays	measure- ment	range	3RT201.	3RT202.	3RT203.	3RT104.	3RT105.	3RT106.	3RT107.	3TF68/3TF69
			S00	S0	S2	S3	S6	S10	S12	S14
Туре		Α	3/4/5.5/7.5	5.5/7.5/11/15/18.5	15/18.5/22/ 30/37	30/37/45	55/75/90	110/132/160	200/250	375/450

#### 

3RU21

SIRIUS 3RU11 thermal overload relays											
	3RU114	Integrated	18 100				✓				



3RU11

SIRIUS 3RB30	electronic	c overload	relays <sup>1)</sup>						
I william	3RB301	Integrated	0.1 16	✓			 	 	
	3RB302	Integrated	0.1 40		✓		 	 	
	3RB303	Integrated	12.5 80			✓	 	 	

3RB30

SIRIUS 3RB31 electronic overload relays <sup>1)</sup>											
	3RB311	Integrated	0.1 16	✓							
	3RB312	Integrated	0.1 40		✓						
	3RB313	Integrated	12.5 80			✓					

SIRIUS 3RB20	SIRIUS 3RB20 electronic overload relays <sup>1)</sup>											
	3RB204	Integrated	12.5 100				✓					
	3RB205	Integrated	50 200					✓				
	3RB206	Integrated	55 630						✓	✓	✓	
	3RB201 + 3UF18	Integrated	630 820								1	

3RB20

US 3RB21	electronic	c overload	relays <sup>1)</sup>							
00	3RB214	Integrated	12.5 100	 	 ✓					
-	3RB215	Integrated	50 200	 	 	✓				
160	3RB216	Integrated	55 630	 	 		✓	✓	✓	
	3RB211 + 3UF18	Integrated	630 820	 	 				✓	

3RB21

- ✓ Can be used
- -- Cannot be used

 "Technical specifications" for the use of overload relays with trip class ≥ CLASS 20 can be found in "Short-circuit protection with fuses for motor feeders".

see Configuration Manuals

- "SIRIUS Configuration Selection data for Fuseless Load Feeders", http://support.automation.siemens.com/WW/view/en/68115040.
- "Configuring SIRIUS Innovations Selection data for Fuseless and Fused Load Feeders",

http://support.automation.siemens.com/WW/view/en/50250599.

General data

#### Overview of overload relays - matching contactors (continued)

Overload	Current	Current	Contactors	Contactors (type, size, rating in kW)								
relays	measur- ing module	range	3RT201.	3RT202.	3RT203.	3RT104.	3RT105.	3RT106.	3RT107.	3TF68/3TF69		
			S00	S0	S2	S3	S6	S10	S12	S14		
Type		Δ	3/4/5.5/7.5	5.5/7.5/11/15/18.5	15/18.5/22/	30/37/45	55/75/90	110/132/160	200/250	375/450		

	Туре		Α	3/4/5.5/7.5	5.5/7.5/11/15/18.5	15/18.5/22/ 30/37	30/37/45	55/75/90	110/132/160	200/250	375/450
SIRIUS 3RB22	2 to 3RB24	electroni	c overload	relays <sup>1)</sup>							
		3RB2906	0.3 25	✓	✓						
955556	3RB2283/	3RB2906	10 100	✓	✓	✓	✓				
600000	3RB2383/		20 200		✓	✓	✓	✓			
	3RB2483+	3RB2966	63 630						1	✓	✓
1 0		3RB2906 + 3UF18	630 820								<b>√</b>
3RB22, 3RB23 3RB24											

- ✓ Can be used
- -- Cannot be used

"Technical Specifications" for the use of overload relays with trip class
 ≥ CLASS 20 can be found in "Short-circuit protection with fuses for motor feeders".

see Configuration Manuals

- "SIRIUS Configuration Selection Data for Fuseless Load Feeders", http://support.automation.siemens.com/WW/view/en/68115040
- "Configuring SIRIUS Innovations Selection Data for Fuseless and Fused Load Feeders",
- http://support.automation.siemens.com/WW/view/en/50250599.

#### **General data**

#### Connection methods

#### 3RU2 thermal overload relays

- Sizes S00 and S0:
  - Main and auxiliary circuit: Either screw terminals, spring-type terminals or ring terminal lug connections
- Size S2:
- Main circuit: Screw terminals with box terminal
- Auxiliary circuit: Either screw or spring-type terminals

#### 3RU1 thermal overload relays

- Size S3:
  - Main circuit: Screw terminals
  - Auxiliary circuit: Either screw or spring-type terminals

#### 3RB3 electronic overload relays

- Sizes S00 and S0:
  - Main and auxiliary circuit: Either screw or spring-type terminals
- Size S2:
  - Main circuit: Screw terminals with box terminal or as straight-through transformer
  - Auxiliary circuit: Either screw or spring-type terminals

#### 3RB2 electronic overload relays

3RB20 and 3RB21 overload relays:

- Size S3:
  - Main circuit: Screw terminals with box terminal or as straight-through transformer
  - Auxiliary circuit: Either screw or spring-type terminals
- Size S6:
  - Main circuit: With busbar connection or as straight-through transformer
  - Auxiliary circuit: Either screw or spring-type terminals
- Sizes S10/S12:
  - Main circuit: With busbar connection
  - Auxiliary circuit: Either screw or spring-type terminals

#### 3RB22 to 3RB24 evaluation modules:

• Screw or spring-type terminals

#### 3RB29 current measuring modules:

- Up to size S3: Straight-through transformers
- As from size S6:
  - Main circuit: With busbar connection
  - Auxiliary circuit: Either screw or spring-type terminals


- Screw terminals
- Spring-type terminals
- Ring terminal lug connections
- Busbar connections
- Straight-through transformers

The various terminals and straight-through transformers are indicated in the corresponding tables by the symbols shown on orange backgrounds.

# Overload Relays SIRIUS 3RU2 Thermal Overload Relays

3RU2 up to 80 A for standard applications

#### Overview



- 1 Switch position indicator and TEST function of the wiring: Indicates a trip and enables the wiring test.
- Motor current setting:
   Setting the device to the rated motor current is easy with the large rotary knob.
- Connecting terminals:
   Depending on the device version, the connecting terminals for screw, spring-type or ring terminal lug connection are configured for the main and auxiliary circuit.
- 4 STOP button: If the STOP button is pressed, the NC contact is opened. This switches off the contactor downstream. The NC contact is closed again when the button is released.
- (5) Selector switch for manual/automatic RESET and RESET button: With this switch you can choose between manual and automatic RESET. A device set to manual RESET can be reset locally by pressing the RESET button. A remote RESET is possible using the RESET modules (accessories), which are independent of size.
- (6) Connection for mounting onto contactors: Optimally adapted in electrical, mechanical and design terms to the contactors. The overload relay can be connected directly to the contactor using these pins. Stand-alone installation is possible as an alternative (in conjunction with a terminal bracket for stand-alone installation).

A sealable transparent cover can be optionally mounted (accessory). It secures the motor current setting against adjustment

The 3RU21 thermal overload relays up to 80 A have been designed for inverse-time delayed protection of loads with normal starting (for "Function", see manual "SIRIUS Innovations – SIRIUS 3RU2/3RB3 Overload Relays", http://support.automation.siemens.com/WW/view/en/60298164) against excessive temperature rises due to overload or phase failure

An overload or phase failure results in an increase of the motor current beyond the set rated motor current. Via heating elements, this current rise heats up the bimetal strips inside the device which then bend and as a result trigger the auxiliary contacts by means of a tripping mechanism. The auxiliary contacts then switch off the load by means of a contactor. The break time depends on the ratio between the tripping current and current setting  $I_{\rm e}$  and is stored in the form of a long-term stable tripping characteristic (see "Characteristic Curves" http://support.automation.siemens.com/WW/view/en/34291410/134300).

The "tripped" status is signaled by means of a switch position indicator. Resetting takes place either manually or automatically after a recovery time has elapsed (for "Function", see manual "SIRIUS Innovations – SIRIUS 3RU2/3RB3 Overload Relays", http://support.automation.siemens.com/WW/view/en/60298164).

The 3RU2 thermal overload relays are suitable for operation with frequency converters. Please follow the instructions in the manual "SIRIUS Innovations – 3RU2/3RB3 Overload Relays", see http://support.automation.siemens.com/WW/view/en/60298164.

The devices are manufactured in accordance with environmental guidelines and contain environmentally friendly and reusable materials. They comply with all important worldwide standards and approvals.

3RU11 overload relays for currents over 80 A in size S3, see page 7/111 onwards.

#### Use in hazardous areas

The 3RU21 thermal overload relays are suitable for the protection of motors with "Flameproof enclosure d" or "Increased safety e" types of protection.

EC type test certificate for Category (2) G/D exists. It has the number DMT 98 ATEX G001.

SIRIUS 3RU2136-4.B0 thermal overload relay

#### Article No. scheme

Al tiole Ito. Solicine											
Digit of the Article No.	1st - 3rd	4th	5th	6th	7th		8th	9th	10th	11th	
						-					
Thermal overload relays	3 R U										
SIRIUS 2nd generation		2									
Device series											
Size, rated operational current and power											
Setting range of the overload release											
Connection methods											
Installation type											
Example	3 R U	2	1	1	6	-	0	Α	В	0	

#### Note:

The Article No. scheme is presented here merely for information purposes and for better understanding of the logic behind the article numbers.

For your orders, please use the article numbers quoted in the catalog in the Selection and ordering data.

# Overload Relays SIRIUS 3RU2 Thermal Overload Relays

#### 3RU2 up to 80 A for standard applications

#### Benefits

The most important features and benefits of the 3RU21 thermal overload relays are listed in the overview table (see "General Data", page 7/87 onwards).

#### Application

#### Industries

The 3RU21 thermal overload relays are suitable for customers from all industries who want to guarantee optimum inverse-time delayed protection of their electrical loads (e.g. motors) under normal starting conditions (CLASS 10, 10A).

#### Application

The 3RU21 thermal overload relays have been designed for the protection of three-phase and single-phase AC and DC motors.

#### Note:

For the use of 3RU21 thermal overload relays in conjunction with highly energy-efficient IE3 motors, please read the information on dimensioning and configuration,

see "Configuration Manual for SIRIUS Controls with IE3 Motors", http://support.automation.siemens.com/WW/view/en/94770820

More information, see page 3.

If single-phase AC or DC loads are to be protected by the 3RU21 thermal overload relays, all three bimetal strips must be heated. For this purpose, all main current paths of the relay must be connected in series

#### **Ambient conditions**

The 3RU21 thermal overload relays have temperature compensation according to IEC 60947-4-1 for the temperature range of -40 to +60 °C. For temperatures from +60 to +70 °C, the upper set value of the setting range must be reduced by the factor listed in the table below.

#### Technical specifications

The following technical information is intended to provide an initial overview of the various types of device and functions.

Detailed information, see

- Manual "SIRIUS Innovations SIRIUS 3RU2/3RB3 Overload Relays",
  - http://support.automation.siemens.com/WW/view/en/60298164
- - http://support.automation.siemens.com/WW/view/en/34291410/133200

Type		3RU2116	3RU2126	3RU2136			
Size		S00	S0	S2			
Dimensions (W x H x D) (overload relay with stand-alone installation support)							
<ul><li>Screw terminals</li><li>Spring-type terminals</li></ul>	mm mm	45 x 89 x 80 45 x 102 x 79	45 x 97 x 95 45 x 114 x 95	55 x 105 x 117 55 x 105 x 117			
General data				_			
Trips in the event of		Overload and phase failure	е				
Trip class acc. to IEC 60947-4-1	Class	10		10, 10A			
Phase failure sensitivity		Yes					
Overload warning		No					
Reset and recovery							
Reset options after tripping		Manual, Automatic and Re (Remote RESET in combin	emote RESET lation with the correspondin	g accessories)			
Recovery time							
For automatic RESET     For manual RESET	min. min.		of the tripping current and c				
- For remote RESET	min.	Depends on the strength of the tripping current and characteristic Depends on the strength of the tripping current and characteristic					
Features		-					
Display of operating state on device		Yes, by means of TEST fur	nction/switch position indica	tor slide			
TEST function		Yes					
RESET button		Yes					
STOP button		Yes					
Protection and operation of motors with "Increased safety e" and "Flameproof enclosure d" types of protection							
EC type test certificate number according to directive 94/9/EC (ATEX)		DMT 98 ATEX G 001  II (2) GD  see  http://support.automation.siemens.com/\WW/view/en/47205444					



# **Overload Relays** SIRIUS 3RU2 Thermal Overload Relays

# 3RU2 up to 80 A for standard applications

Туре		3RU2116	3RU2126	3RU2136
Size		S00	S0	S2
Dimensions (W x H x D) (overload relay with stand-alone installation support)				
<ul><li>Screw terminals</li><li>Spring-type terminals</li></ul>	mm mm	45 x 89 x 80 45 x 102 x 79	45 x 97 x 95 45 x 114 x 95	55 x 105 x 117 55 x 105 x 117
General data (continued)				
Ambient temperature				
Storage/transport	°C	-55 +80		
Operation	°C	-40 +70		
Temperature compensation	°C	Up to +60		
Permissible rated current at				
- Temperature inside control cabinet 60 °C	%	100 (over +60 °C current	reduction is not required)	
- Temperature inside control cabinet 70 °C	%	87		
Repeat terminals				
Coil repeat terminals		Yes	Not required	
Auxiliary contact repeat terminal		Yes	Not required	
Degree of protection acc. to IEC 60529		IP20		
Touch protection acc. to IEC 61140				
<ul> <li>Screw terminals and spring-type terminals</li> </ul>		Finger-safe for vertical con	ntact from the front	
Ring terminal lug connections		Finger-safe only with optic		
Shock resistance with sine acc. to IEC 60068-2-27	<i>g</i> /ms	15/11 (auxiliary contacts 9	95/96 and 97/98: 8 <i>g</i> /11 ms)	
Electromagnetic compatibility (EMC)				
Interference immunity		Not relevant		
Emitted interference		Not relevant		
Resistance to extreme climates – air humidity	%	90		
Dimensions		<ul><li>http://support.automatio</li><li>Product data sheet,</li></ul>	ee lons – SIRIUS 3RU2/3RB3 C n.siemens.com/WW/view/er emens.com/WW/view/en/34291	n/60298164
Installation altitude above sea level	m	Up to 2 000; above this or	request	
Mounting position		contactors and stand-alor area, a setting correction stand-alone installation:	0°	position in the hatched
Type of mounting			stand-alone installation with nounting onto TH 35 standa	

Mounting onto contactor/stand-alone installation with terminal support (For screw and snap-on mounting not DT H35 standard mounting rail. Technical specifications of the terminal supports, see manual SIRIUS Innovations – SIRIUS 3RU2/3RB3 Overload Relays\*, http://support.automation.siemens.com/WW/view/en/60298164.)

# Overload Relays SIRIUS 3RU2 Thermal Overload Relays

# 3RU2 up to 80 A for standard applications

Туре		3RU2116	3RU2126	3RU2136
Size		S00	SO	S2
Main circuit				
Rated insulation voltage U <sub>i</sub>	V	690		
(pollution degree 3)				
Rated impulse withstand voltage U <sub>imp</sub>	kV	6		
Rated operational voltage U <sub>e</sub>	V	690		
Type of current				
Direct current		Yes		
Alternating current		Yes, frequency range up	n to 400 Hz	
Current setting	Α	0.11 0.16	1.8 2.5	11 16
Our ent setting	^	up to	up to	up to
	Α	11 16	34 40	70 80
Power loss per unit (max.)	W	4.1 6.3	6.2 7.5	8 14
Short-circuit protection				
With fuse without contactor		See "Selection and orde	ering data" on pages 7/100 7	/102
With fuse and contactor		"Short-Circuit Protection	with Fuses/Motor Starter Prote	ctors for Motor Feeders".
		see Configuration Manu	ual "Configuring SIRIUS Innovat	
		Fuseless and Fused Loa		0050500
But at a sure and a su		nttp://support.automatic	on.siemens.com/WW/view/en/50	J250599.
Protective separation between main and auxiliary current paths				
acc. to IEC 60947-1				
Screw terminals or ring terminal lug connections	V	440	690: Setting ranges ≤ 25 A	690
Spring-type terminals	V	440	440: Setting ranges > 25 A	
Conductor cross-sections of main circuit	<u> </u>	110	440. Octaing ranges > 207	. 000
		- Carayy tarminala		
Connection type		Screw terminals		
Terminal screw		M3, Pozidriv size 2	M4, Pozidriv size 2	M6, Pozidriv size 2
Operating devices	mm	Ø 5 6	Ø 5 6	Ø 5 6
Prescribed tightening torque	Nm	0.8 1.2	2 2.5	3 4.5
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected				
Solid or stranded	$mm^2$	2 x (0.5 1.5) <sup>1)</sup> ,	2 x (1 2.5) <sup>1)</sup> ,	2 x (2.5 35) <sup>1)</sup> ,
		2 x (0.75 2.5) <sup>1)</sup> ,	2 x (2.5 10) <sup>1)</sup>	1 x (2.5 50) <sup>1)</sup>
	0	max. 2 x 4	4)	4)
<ul> <li>Finely stranded with end sleeve (DIN 46228-1)</li> </ul>	mm <sup>2</sup>	2 x (0.5 1.5) <sup>1)</sup>	2 x (1 2.5) <sup>1)</sup> ,	2 x (1 25) <sup>1)</sup> ,
		2 x (0.75 2.5) <sup>1)</sup>	2 x (2.5 6) <sup>1)</sup> ; max. 1 x 10	1 x (1 35) <sup>1)</sup>
AWG cables, solid or stranded	AWG	2 x (20 16) <sup>1)</sup> ,		2 v (19 2)1)
AWG capies, solid of stranded	AWG	2 x (20 16) <sup>7</sup> , 2 x (18 14) <sup>1)</sup> ,	2 x (16 12) <sup>1)</sup> , 2 x (14 8) <sup>1)</sup>	2 x (18 2) <sup>1)</sup> , 1 x (18 1) <sup>1)</sup>
		2 x 12	- /	( - ,
Connection type		Spring-type term	inals	
Operating devices	mm	3.0 x 0.5 and 3.5 x 0.5		
Conductor cross-sections (min./max.),		2 11 212 211d 310 % 010		
1 conductor can be connected				
Solid or stranded	$\text{mm}^2$	1 x (0.5 4)	1 x (1 10)	
Finely stranded without end sleeve	$mm^2$	1 x (0.5 2.5)	1 x (1 6)	
• Finely stranded with end sleeve (DIN 46228-1)	mm <sup>2</sup>	1 x (0.5 2.5)	1 x (1 6)	
AWG cables, solid or stranded	AWG	1 x (20 12)	1 x (18 8)	
Connection type	/.vv G			
Connection type		Ring terminal lug	Connections	
Terminal screw	•	M3, Pozidriv size 2	M4, Pozidriv size 2	
Operating devices	mm	Ø 5 6	Ø 5 6	
Prescribed tightening torque	Nm	0.8 1.2	2 2.5	
Usable ring terminal lugs   ←d <sub>3</sub> ←	mm	$d_2 = min. 3.2,$	$d_2 = \min. 4.3,$	
• DIN 46234 without insulation sleeve		$d_3 = \text{max. 7.5}$	$d_3^2 = \text{max. } 12.2$	
DIN 46225 without insulation sleeve				
17   11				
DIN 46237 with insulation sleeve     US C3905 Type B without insulation				
• JIS C2805 Type R without insulation sleeve				
Sleeve     JIS C2805 Type RAV with insulation sleeve				
• JIS C2805 Type RAP with insulation sleeve				
- 010 OZ000 Type nar withinsulation sieeve				

<sup>1)</sup> If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.



# Overload Relays SIRIUS 3RU2 Thermal Overload Relays

# 3RU2 up to 80 A for standard applications

Tuno		3DI 12116	3D112426	3DI12426
Type Size		<b>3RU2116</b> S00	<b>3RU2126</b> S0	<b>3RU2136</b> S2
Auxiliary circuit			55	J.
Number of NO contacts		1		
Number of NC contacts		1		
Auxiliary contacts – assignment		1 NO for the signal "t	ripped"; 1 NC for disco	nnecting the contactor
Rated insulation voltage U <sub>i</sub>	V	690		
(pollution degree 3)	1.) /	0		
Rated impulse withstand voltage U <sub>imp</sub> Contact rating of the auxiliary contacts	kV	6		
NC, NO contact with alternating current AC-15, rated operational				
current $I_{ m e}$ at $U_{ m e}$ :				
- 24 V - 120 V	A A	3		
- 125 V	Â	3		
- 230 V	A	2		
- 400 V - 600 V	A A	1 0.75		
- 690 V	Α	0.75		
• NC contact, NO contact with direct current DC-13, rated operational				
current $I_{\rm e}$ at $U_{\rm e}$ : - 24 V	Α	1		
- 110 V	Α	0.22		
- 125 V - 220 V	A A	0.22 0.11		
Contact reliability (suitability for PLC control; 17 V, 5 mA)	^	Yes		
Short-circuit protection		163		
With fuse				
- Operational class gG	A	6		
- Quick	A	10		
With miniature circuit breaker (C characteristic)	A	6 (up to $I_k \le 0.5 \text{ kA}$ ;	<i>U</i> ≤ 260 V)	
Reliable operational voltage for protective separation between auxiliary current paths acc. to IEC 60947-1	V	440		
CSA, UL, UR rated data				
Auxiliary circuit – switching capacity		B600, R300		
Conductor cross-sections for auxiliary circuit				
Connection type		Screw termina	als	
Terminal screw		M3, Pozidriv size 2		
Operating devices	mm	Ø 5 6		
Prescribed tightening torque	Nm	0.8 1.2		
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected				
Solid or stranded	mm <sup>2</sup>	2 x (0.5 1.5) <sup>1)</sup> , 2 x	(0.75 2.5) <sup>1</sup> )	
Finely stranded with end sleeve (DIN 46228-1)	mm <sup>2</sup>	2 x (0.5 1.5) <sup>1)</sup> , 2 x	,	
AWG cables, solid or stranded	AWG	2 x (20 16) <sup>1)</sup> , 2 x (		
Connection type	AWG	Spring-type to		
Operating devices	mm	3.0 x 0.5 and 3.5 x 0	.5	
Conductor cross-sections (min./max.),  1 or 2 conductors can be connected				
Solid or stranded	mm <sup>2</sup>	2 x (0.5 2.5)		
Finely stranded without end sleeve	mm <sup>2</sup>	2 x (0.5 2.5)		
Finely stranded with end sleeve     Finely stranded with end sleeve (DIN 46228-1)	mm <sup>2</sup>	2 x (0.5 1.5)		
AWG cables, solid or stranded	AWG	2 x (20 14)		
Connection type			lug connections	
Terminal screw		M3, Pozidriv size 2		
Operating devices	mm	Ø 5 6		
Prescribed tightening torque	Nm	0.8 1.2		
Usable ring terminal lugs  →d <sub>3</sub> →	mm	$d_2 = min. 3.2,$		
• DIN 46234 without insulation sleeve		$d_3^2 = \text{max. 7.5}$		
DIN 46225 without insulation sleeve				
DIN 46237 with insulation sleeve				
JIS C2805 Type R without insulation				
sleeve				
• JIS C2805 Type RAV with insulation sleeve				
JIS C2805 Type RAP with insulation sleeve				
If two different conductor cross sections are connected to one clams		t both arose coations		:401

<sup>1)</sup> If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.

#### SIRIUS 3RU2 Thermal Overload Relays

#### 3RU2 up to 80 A for standard applications

#### Selection and ordering data

### 3RU21 thermal overload relays for mounting onto contactor 1), sizes S00 and S0, CLASS 10

Features and technical specifications:

- Connection method
   Main and auxiliary circuit: Either screw terminals, spring-type
   terminals or ring terminal lug connections<sup>2)</sup>
- · Overload and phase failure protection
- Auxiliary contacts 1 NO + 1 NC
- · Manual and automatic RESET
- · Switch position indicator

- TEST function
- STOP button
- Sealable covers (optional accessory)
- Terminal covers for devices with ring terminal lug connection (optional accessory)

$$PU (UNIT, SET, M) = 1$$

$$PS^* = 1 \text{ unit}$$

$$PG = 41F$$







3RU2116-4AC0



3RU2126-4FB0



3RU2126-4AC0

Size contactor	Trip class	Current setting value of the inverse-time delayed overload release	Short-circuit protection with fuse, type of coordination "2", operational class gG <sup>3)</sup>	DT	Screw terminals	<b></b>	DT	Spring-type terminals	
	Class	Α	A		Article No.	Price per PU		Article No.	Price per PU
Size S00	0								
S00	10 10 10 10	0.11 0.16 0.14 0.2 0.18 0.25 0.22 0.32	0.5 1 1 1.6	<b>* * *</b>	3RU2116-0AB0 3RU2116-0BB0 3RU2116-0CB0 3RU2116-0DB0		B B B	3RU2116-0AC0 3RU2116-0BC0 3RU2116-0CC0 3RU2116-0DC0	
	10 10 10 10	0.28 0.4 0.35 0.5 0.45 0.63 0.55 0.8	2 2 2 4	<b>* * *</b>	3RU2116-0EB0 3RU2116-0FB0 3RU2116-0GB0 3RU2116-0HB0		B B B	3RU2116-0EC0 3RU2116-0FC0 3RU2116-0GC0 3RU2116-0HC0	
	10 10 10 10	0.7 1 0.9 1.25 1.1 1.6 1.4 2	4 4 6 6	* * *	3RU2116-0JB0 3RU2116-0KB0 3RU2116-1AB0 3RU2116-1BB0		B B B	3RU2116-0JC0 3RU2116-0KC0 3RU2116-1AC0 3RU2116-1BC0	
	10 10 10 10	1.8 2.5 2.2 3.2 2.8 4 3.5 5	10 10 16 20	<b>* * *</b>	3RU2116-1CB0 3RU2116-1DB0 3RU2116-1EB0 3RU2116-1FB0		B B B	3RU2116-1CC0 3RU2116-1DC0 3RU2116-1EC0 3RU2116-1FC0	
	10 10 10 10	4.5 6.3 5.5 8 7 10 9 12.5	20 25 35 35	<b>* * *</b>	3RU2116-1GB0 3RU2116-1HB0 3RU2116-1JB0 3RU2116-1KB0		B B B	3RU2116-1GC0 3RU2116-1HC0 3RU2116-1JC0 3RU2116-1KC0	
	10	11 16	40	•	3RU2116-4AB0		В	3RU2116-4AC0	
Size S0									
S0	10 10 10 10	1.8 2.5 2.2 3.2 2.8 4 3.5 5	10 10 16 20	<b>* * * *</b>	3RU2126-1CB0 3RU2126-1DB0 3RU2126-1EB0 3RU2126-1FB0		B B B	3RU2126-1CC0 3RU2126-1DC0 3RU2126-1EC0 3RU2126-1FC0	
	10 10 10 10	4.5 6.3 5.5 8 7 10 9 12.5	20 25 35 35	<b>* * * *</b>	3RU2126-1GB0 3RU2126-1HB0 3RU2126-1JB0 3RU2126-1KB0		B B B	3RU2126-1GC0 3RU2126-1HC0 3RU2126-1JC0 3RU2126-1KC0	
	10 10 10 10	11 16 14 20 17 22 20 25	40 50 63 63	* * * *	3RU2126-4AB0 3RU2126-4BB0 3RU2126-4CB0 3RU2126-4DB0		<b>A A A</b>	3RU2126-4AC0 3RU2126-4BC0 3RU2126-4CC0 3RU2126-4DC0	
	10 10 10 10	23 28 27 32 30 36 34 40	63 80 80 80	<b>A A A A</b>	3RU2126-4NB0 3RU2126-4EB0 3RU2126-4PB0 3RU2126-4FB0		<b>A A A</b>	3RU2126-4NC0 3RU2126-4EC0 3RU2126-4PC0 3RU2126-4FC0	

<sup>1)</sup> With the suitable terminal supports (see "Accessories", page 7/103), the 3RU2 overload relays for mounting on contactors can also be installed as stand-alone units.

Overload relays in size S2, see page 7/101.

<sup>2)</sup> When ordering the ring terminal lug version, the Article No. must be changed in the 10th digit to "J": e.g. 3RU2116-0AJ0.

Maximum protection by fuse only for overload relay, type of coordination "2". Fuse values in connection with contactors, see Configuration Manual "Configuring SIRIUS Innovations – Selection Data for Fuseless and Fused Load Feeders", http://support.automation.siemens.com/WW/view/en/50250599.

# Overload Relays SIRIUS 3RU2 Thermal Overload Relays

3RU2 up to 80 A for standard applications

# 3RU21 thermal overload relays for mounting onto contactor 1), size S2, CLASS 10

Features and technical specifications:

- Connection methods
  - Main circuit: Screw terminals with box terminal
  - Auxiliary circuit: Either screw or spring-type terminals
- Overload and phase failure protection
- Auxiliary contacts 1 NO + 1 NC
- · Manual and automatic RESET

- Switch position indicator
- TEST function
- STOP button
- Sealable covers (optional accessory)

 $\begin{array}{ll} PU \text{ (UNIT, SET, M)} &= 1 \\ PS^* &= 1 \text{ unit} \\ PG &= 41F \end{array}$ 





3RU2136-4.B0

3RU2136-4.D0

Size contactor	Trip class	Current setting value of the inverse-time delayed overload release	Short-circuit protection with fuse, type of coordination "2", operational class gG <sup>2)</sup>		Screw terminals	⊕ D	T Spring-type terminals (on auxiliary current side)	
	Class	A	A		Article No.	Price per PU	Article No.	Price per PU
Size S2								
S2	10 10 10 10	11 16 14 20 18 25 22 32	50 <b>6</b> 3 <b>6</b> 3	NEW > NEW > NEW >	3RU2136-4AB0 3RU2136-4BB0 3RU2136-4DB0 3RU2136-4EB0	X X X	3RU2136-4BD0 3RU2136-4DD0	
	10 10 10 10 10 10	28 40 36 45 40 50 47 57 54 65	100 III	NEW > NEW > NEW > NEW >	3RU2136-4FB0 3RU2136-4GB0 3RU2136-4HB0 3RU2136-4QB0 3RU2136-4JB0	X X X X	3RU2136-4GD0 3RU2136-4HD0 3RU2136-4QD0	
	10A 10A	62 73 70 80		NEW ►	3RU2136-4KB0 3RU2136-4RB0	X		

With the suitable terminal supports (see "Accessories", page 7/103), the 3RU2 overload relays for mounting on contactors can also be installed as stand-alone units.

coordination "2".
Fuse values in connection with contactors, see

Configuration Manual "Configuring SIRIUS Innovations – Selection Data for Fuseless and Fused Load Feeders", http://support.automation.siemens.com/WW/view/en/50250599.

<sup>2)</sup> Maximum protection by fuse only for overload relay, type of coordination "2".

# SIRIUS 3RU2 Thermal Overload Relays

#### 3RU2 up to 80 A for standard applications

#### 3RU21 thermal overload relays for stand-alone installation, sizes S00 to S2, CLASS 10

Features and technical specifications:

- Connection methods
  - Sizes S00 and S0: Main and auxiliary circuit: Either screw or spring-type terminals
  - Size S2:
  - Main circuit: Screw terminals with box terminal, main circuit: Either screw or spring-type terminals
- Auxiliary contacts 1 NO + 1 NC
- · Manual and automatic RESET

- Switch position indicator
- TEST function
- STOP button
- Sealable covers (optional accessory)

 $\begin{array}{ll} PU \text{ (UNIT, SET, M)} &= 1 \\ PS^* &= 1 \text{ unit} \\ PG &= 41F \end{array}$ 



3RU2116-4AC1

Trip class

Size



3RU2136-4.B1



3RU2126-4FB1

Current setting value Short-circuit protection DT Screw terminals



3RU2126-4FC1



 $\infty$ 

3RU2136-4.D1

□ DT Spring-type

contactor	Trip class	of the inverse-time delayed overload release	with fuse, type of coordination "2", operational class gG <sup>2)</sup>	וט	Screw terminals	<b>+</b>	וטו	terminals	
	Class	Α	A		Article No.	Price per PU		Article No.	Price per PU
Size S00									
S00	10 10 10 10	0.11 0.16 0.14 0.2 0.18 0.25 0.22 0.32	0.5 1 1 1.6	B B B	3RU2116-0AB1 3RU2116-0BB1 3RU2116-0CB1 3RU2116-0DB1		B B B	3RU2116-0AC1 3RU2116-0BC1 3RU2116-0CC1 3RU2116-0DC1	
	10 10 10 10	0.28 0.4 0.35 0.5 0.45 0.63 0.55 0.8	2 2 2 4	B B B	3RU2116-0EB1 3RU2116-0FB1 3RU2116-0GB1 3RU2116-0HB1		B B B	3RU2116-0EC1 3RU2116-0FC1 3RU2116-0GC1 3RU2116-0HC1	
	10 10 10 10	0.7 1 0.9 1.25 1.1 1.6 1.4 2	4 4 6 6	B B B	3RU2116-0JB1 3RU2116-0KB1 3RU2116-1AB1 3RU2116-1BB1		B B B	3RU2116-0JC1 3RU2116-0KC1 3RU2116-1AC1 3RU2116-1BC1	
	10 10 10 10	1.8 2.5 2.2 3.2 2.8 4 3.5 5	10 10 16 20	B B B	3RU2116-1CB1 3RU2116-1DB1 3RU2116-1EB1 3RU2116-1FB1		B B B	3RU2116-1CC1 3RU2116-1DC1 3RU2116-1EC1 3RU2116-1FC1	
	10 10 10 10	4.5 6.3 5.5 8 7 10 9 12.5	20 25 35 35	B B B	3RU2116-1GB1 3RU2116-1HB1 3RU2116-1JB1 3RU2116-1KB1		B B B B	3RU2116-1GC1 3RU2116-1HC1 3RU2116-1JC1 3RU2116-1KC1	
	10	11 16	40	В	3RU2116-4AB1		В	3RU2116-4AC1	
Size S0 S0	10 10 10 10 10 10	14 20 17 22 20 25 23 28 27 32 30 36	50 63 63 63 80 80	B B B B	3RU2126-4BB1 3RU2126-4CB1 3RU2126-4DB1 3RU2126-4NB1 3RU2126-4EB1 3RU2126-4PB1		B B B B	3RU2126-4BC1 3RU2126-4CC1 3RU2126-4DC1 3RU2126-4DC1 3RU2126-4EC1 3RU2126-4PC1	
Size S2	10	34 40	80	В	3RU2126-4FB1		В	3RU2126-4FC1	
Size SZ	10 10 10 10 10	22 32 28 40 36 45 40 50 47 57	80 MEX 80 MEX 100 MEX 100 MEX 100 MEX	V > V >	3RU2136-4EB1 3RU2136-4FB1 3RU2136-4GB1 3RU2136-4HB1 3RU2136-4QB1		<b>A A A A</b>	3RU2136-4ED1 3RU2136-4FD1 3RU2136-4GD1 3RU2136-4HD1 3RU2136-4QD1	
	10 10A 10A	54 65 62 73 70 80	125 NEV 160 NEV 160 NEV	V ► V ►	3RU2136-4JB1 3RU2136-4KB1 3RU2136-4RB1		<b>&gt; &gt; &gt;</b>	3RU2136-4JD1 3RU2136-4KD1 3RU2136-4RD1	

<sup>1)</sup> Guide value for 4-pole standard motors at 50 Hz 400 V AC. The actual starting and rated data of the motor to be protected must be considered when selecting the units.

<sup>&</sup>lt;sup>2)</sup> Maximum protection by fuse only for overload relay, type of coordination "2". Fuse values in connection with contactors, see Configuration Manual "Configuring SIRIUS Innovations – Selection Data for Fuseless and Fused Load Feeders", http://support.automation.siemens.com/WW/view/en/50250599.

# **Overload Relays** SIRIUS 3RU2 Thermal Overload Relays

**Accessories** 

#### Overview

#### Overload relays for standard applications

The following optional accessories are available for the 3RU21 thermal overload relays:

- Size-specific terminal support for stand-alone installation, in sizes S00 and S0 also with spring-type terminals
- Mechanical RESET (for all sizes)

- Cable release for resetting devices which are difficult to access (for all sizes)
- Electrical remote RESET module in three voltage variants (for all sizes)
- Sealable cover (for all sizes)
- Terminal covers for devices with screw terminals (box terminals) and ring terminal lug connections

Selection and order	ing data							
	Version	Size	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
Terminal supports f	or stand-alone installation							
	Terminal supports for overload relays with screw terminals			Screw terminals	<b>(+)</b>			
***	For separate mounting of the overload relays;	S00	<b>&gt;</b>	3RU2916-3AA01		1	1 unit	41F
-	screw and snap-on mounting onto standard mounting rail	S0	<b>&gt;</b>	3RU2926-3AA01 3RU2936-3AA01		1 1	1 unit	41F 41F
1211	Terminal supports for overload relays with	S2 NEV	<b>V</b> A	Spring-type		'	1 unit	411
3RU2916-3AA01	spring-type terminals			terminals	8			
	For separate mounting of the overload relays; screw and snap-on mounting onto standard mounting rail	S00 S0	B B	3RU2916-3AC01 3RU2926-3AC01		1	1 unit 1 unit	41F 41F
3RU2926-3AA01								
3RU2936-3AA01								
3RU2916-3AC01								
3RU2926-3AC01 Mechanical RESET				•				
di	Resetting plungers, holders and formers	S00 S2	<b>&gt;</b>	3RU2900-1A		1	1 unit	41F
<i>J</i> *	Pushbuttons with extended stroke (12 mm), IP65, Ø 22 mm	S00 S2	В	3SB3000-0EA11		1	1 unit	41J
	Extension plungers For compensation of the distance between the pushbutton and the unlatching button of the relay	S00 S2	А	3SX1335		1	1 unit	41J
3RU2900-1A with pushbutton and extension plunger								

# SIRIUS 3RU2 Thermal Overload Relays

# Accessories

	Version	Size	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
Cable releases with	holder for RESET							
A	For Ø 6.5 mm holes in the control panel; max. control panel thickness 8 mm  • Length 400 mm  • Length 600 mm	S00 S2 S00 S2	<b>&gt;</b>	3RU2900-1B 3RU2900-1C		1	1 unit 1 unit	41F 41F
3RU2900-1.								
Modules for remote	RESET, electrical							
	Operating range 0.85 1.1 × <i>U</i> <sub>s</sub> , power consumption AC 80 VA, DC 70 W, ON period 0.2 4 s, switching frequency 60/h  • 24 30 V AC/DC	S00 S2	A	3RU1900-2AB71		1	1 unit	41F
100	• 110 127 V AC/DC	S00 S2	Α	3RU1900-2AF71		1	1 unit	41F
3RU1900-2A.71	• 220 250 V AC/DC	S00 S2	Α	3RU1900-2AM71		1	1 unit	41F
Sealable covers								
3RV2908-0P	For covering the setting knobs	S00 S2	•	3RV2908-0P		100	10 units	41E
Terminal covers								
1	Covers for devices with screw terminals (box terminals) Additional touch protection for fastening to the box terminals			Screw terminals	<b>+</b>			
3RT2936-4EA2	Main current level	S2 NEW	B	3RT2936-4EA2		1	1 unit	41B
LICECCO L	Covers for devices with ring terminal lug connection (ensure finger-safety)  • Main current level			Ring terminal lug connection	<b>(1)</b>			
3RU2916-3BJ21	- Cover between contactor and overload relay	S00	С	3RU2916-3BJ21		1	10 units	41F
5.75.75 st	for direct mounting of the overload relay	S0	С	3RU2926-3BJ21		1	10 units	41F
AL AL	- Cover for overload relay on load side	S00 S0	C B	3RU2916-3BJ20 3RV2928-4AA00		1	10 units 1 unit	41F 41E
3RU2926-3BJ21	Auxiliary current level	S00, S0	В	3RT2916-4EA13		1	10 units	41B
3RU2916-3BJ20								
3RV2928-4AA00								
HUUU								
3RT2916-4EA13								



# **Overload Relays** SIRIUS 3RU2 Thermal Overload Relays

Accessories

#### General accessories Price per PU PS\* PU (UNIT, PG Version Size Color For DT Article No. overload relays SET, M) Tools for opening spring-type terminals Spring-type terminals $\underset{\square}{\infty}$ Screwdrivers Length approx. Titanium Main and Α 3RA2908-1A 1 unit 41B For all SIRIUS devices 200 mm, auxiliary gray/ black, with spring-type 3.0 mm x 0.5 mm circuit 3RA2908-1A terminals partially connection: insulated 3RU2 Blank labels Unit labeling plates<sup>1)</sup> 20 mm x 7 mm Pastel 3RU2 D 3RT1900-1SB20 100 340 units 41B for SIRIUS devices turquoise 20 mm x 7 mm 3RU2 D 3RT2900-1SB20 100 340 units 41B Titanium gray

#### More information

#### Manuals

- System Manual "SIRIUS Innovations System Overview" http://support.automation.siemens.com/WW/view/en/60311318
- Manual "SIRIUS Innovations SIRIUS 3RU2/3RB3 Overload Relays"
  - http://support.automation.siemens.com/WW/view/en/60298164

<sup>1)</sup> PC labeling system for individual inscription of unit labeling plates available from: murrplastik Systemtechnik GmbH (see Chapter 16, "Appendix" → "External Partners").

# Overload Relays SIRIUS 3RU1 Thermal Overload Relays


#### 3RU11 up to 100 A for standard applications

#### Overview

#### Note:

The 3RU11 devices (sizes S00/S0 to S3) can be found

- in the Catalog Add-On IC 10 AO · 2015 at the Information and Download Center
- in the interactive catalog CA 01
- in the Industry Mall



- (1) Switch position indicator and TEST function of the wiring: Indicates a trip and enables the wiring test.
- 2 Motor current setting: Setting the device to the rated motor current is easy with the large rotary knob.
- (3) Transparent, sealable cover: Secures the motor current setting and the TEST function against adjustment.
- Connecting terminals:
   The generously sized terminals permit connection of two conductors with different cross-sections for main and auxiliary circuits. The auxiliary circuit can be connected with screw terminals and alternatively with spring-type terminals.
- (5) STOP button: If the STOP button is pressed, the NC contact is opened. This switches off the contactor downstream. The NC contact is closed again when the button is released.
- Selector switch for manual/automatic RESET and RESET button: With this switch you can choose between manual and automatic RESET. A device set to manual RESET can be reset locally by pressing the RESET button. A remote RESET is possible using the RESET modules (accessories), which are independent of size.
- (7) Connection for mounting onto contactors:
  Optimally adapted in electrical, mechanical and design terms to the contactors. These connecting pins can be used for direct mounting of the overload relay to the contactor. Stand-alone installation is possible as an alternative (partly in conjunction with a terminal support for stand-alone installation).

The 3RU11 thermal overload relays up to 100 A have been designed for inverse-time delayed protection of loads with normal starting ("Function", see Reference Manual "Protection Equipment – 3RU1, 3RB2 Overload Relays, http://support.automation.siemens.com/WW/view/en/35681830) against excessive temperature rises due to overload or phase failure

An overload or phase failure results in an increase of the motor current beyond the set rated motor current. Via heating elements, this current rise heats up the bimetal strips inside the device which then bend and as a result trigger the auxiliary contacts by means of a tripping mechanism. The auxiliary contacts then switch off the load by means of a contactor. The break time depends on the ratio between the tripping current and current setting  $I_{\rm e}$  and is stored in the form of a long-term stable tripping characteristic (see "Characteristic Curves"

http://support.automation.siemens.com/WW/view/en/20356133/134300).

The "tripped" status is signaled by means of a switch position indicator. Resetting takes place either manually or automatically after a recovery time has elapsed ("Function", see Reference Manual "Protection Equipment – 3RU1, 3RB2 Overload Relays" http://support.automation.siemens.com/WW/view/en/35681830).

The 3RU11 thermal overload relays are suitable for operation with frequency converters. Please follow the instructions in the Reference Manual "Protection Equipment – 3RU1, 3RB2 Overload Relays", see

http://support.automation.siemens.com/WW/view/en/35681830.

The devices are manufactured in accordance with environmental guidelines and contain environmentally friendly and reusable materials.

They comply with all important worldwide standards and approvals.

3RU21 overload relays in sizes S00 to S2, see page 7/100 onwards.

#### Use in hazardous areas

The 3RU11 thermal overload relays are suitable for the protection of motors with "Flameproof enclosure d" or "Increased safety e" types of protection.

EC type test certificate for Category (2) G/D exists. It has the number DMT 98 ATEX G001.

SIRIUS 3RU1146-1HB0 thermal overload relay

#### Article No. scheme

Digit of the Article No.	1st - 3rd	4th	5th	6th	7th		8th	9th	10th	11th
						_				
Thermal overload relays	3 R U									
SIRIUS 1st generation		1								
Device series										
Size, rated operational current and power										
Setting range of the overload release										
Connection methods										
Installation type										
Example	3 R U	1	1	4	6	_	4	D	В	0

#### Note:

The Article No. scheme is presented here merely for information purposes and for better understanding of the logic behind the article numbers.

For your orders, please use the article numbers quoted in the catalog in the Selection and ordering data.

# Overload Relays SIRIUS 3RU1 Thermal Overload Relays

3RU11 up to 100 A for standard applications

#### Benefits

The most important features and benefits of the 3RU11 thermal overload relays are listed in the overview table (see "General Data", page 7/87 onwards).

#### Application

#### Industries

The 3RU11 thermal overload relays are suitable for customers from all industries who want to guarantee optimum inverse-time delayed protection of their electrical loads (e.g. motors) under normal starting conditions (CLASS 10).

#### Application

Type

Size

The 3RU11 thermal overload relays have been designed for the protection of three-phase and single-phase AC and DC motors.

If single-phase AC or DC loads are to be protected by the 3RU11 thermal overload relays, all three bimetal strips must be heated. For this purpose, all main current paths of the relay must be connected in series.

#### Ambient conditions

The 3RU11 thermal overload relays have temperature compensation in accordance with IEC 60947-4-1 for the temperature range of -20 to +60 °C. For temperatures from +60 to +70 °C, the upper set value of the setting range must be reduced by the factor listed in the table below.

#### Technical specifications

· Auxiliary contact repeat terminal

The following technical information is intended to provide an initial overview of the various types of device and functions.

Detailed information, see

3RU1146

S3

Reference Manual "Protection Equipment – 3RU1, 3RB2 Overload Relays",

http://support.automation.siemens.com/WW/view/en/35681830

Dimensions (W x H x D) (overload relay with stand-alone installation support)		53 70 x 120 x 140					
General data							
Trips in the event of	C	Overload and phase failure					
Trip class acc. to IEC 60947-4-1	LASS 1	10					
Phase failure sensitivity	Y	Yes					
Overload warning	N	No					
Reset and recovery							
Reset options after tripping		Manual, Automatic and Remote RESET (Remote RESET in combination with the corresponding accessories)					
- For manual RESET	nin. D	Depends on the strength of the tripping current and characteristic Depends on the strength of the tripping current and characteristic Depends on the strength of the tripping current and characteristic					
Features							
Display of operating state on device	Y	Yes, by means of TEST function/switch position indicator slide					
TEST function	Y	Yes					
RESET button	Y	Yes					
STOP button	Y	Yes					
Protection and operation of motors with "Increased safety e" and "Flameproof enclosure d" types of protection							
EC type test certificate number according to directive 94/9/EC (ATEX)	S	DMT 98 ATEX G 001 😥 II (2) GD, see http://support.automation.siemens.com/WW/view/en/5355912					
Ambient temperature							
• Storage/transport	C -	55 +80					
• Operation °C	C -2	20 +70					
• Temperature compensation	C u	up to 60					
<ul> <li>Permissible rated current at</li> <li>Temperature inside control cabinet 60 °C</li> <li>Temperature inside control cabinet 70 °C</li> </ul>		100 (over +60 °C current reduction is not required) 37					
Repeat terminals							
Coil repeat terminals	N	Not required					

Not required

# SIRIUS 3RU1 Thermal Overload Relays

# 3RU11 up to 100 A for standard applications

Type Size Dimensions (W x H x D) (overload relay with stand-alone installation support)	mm	<b>3RU1146</b> S3 70 x 120 x 140
General data (continued)		
Degree of protection acc. to IEC 60529		IP20 (terminal compartment: IP00 degree of protection)
Touch protection acc. to IEC 61140		Finger-safe for vertical contact from the front
Shock resistance with sine acc. to IEC 60068-2-27	g/ms	8/10
Electromagnetic compatibility (EMC)		
Interference immunity		Not relevant
Emitted interference		Not relevant
Resistance to extreme climates – air humidity	%	100
Dimensions		"Dimensional drawings", see Reference Manual "Protection Equipment – 3RU1, 3RB2 Overload Relays", http://support.automation.siemens.com/WW/view/en/35681830
Installation altitude above sea level	m	Up to 2 000; above this on request
Mounting position		The diagrams show the permissible mounting positions for mounting onto contactors and stand-alone installation. For mounting position in the hatched area, a setting correction of 10 % must be implemented. Stand-alone installation:

Type of mounting

Direct mounting/stand-alone installation with terminal support (For screw and snap-on mounting onto TH 35 standard mounting rail; size S3 also for TH 75 standard mounting rail. For technical specifications of the terminal supports, see Reference Manual "Protection Equipment – 3RU1, 3RB2 Overload Relays", http://support.automation.siemens.com/WW/view/en/35681830.)

## Overload Relays SIRIUS 3RU1 Thermal Overload Relays

## 3RU11 up to 100 A for standard applications

Туре		3RU1146
Size		S3
Main circuit		
Rated insulation voltage <i>U</i> <sub>i</sub> (pollution degree 3)	V	1 000
Rated impulse withstand voltage $U_{\rm imp}$	kV	8
Rated operational voltage U <sub>e</sub>	V	1 000
Type of current		
Direct current		Yes
Alternating current		Yes, frequency range up to 400 Hz
Current setting	Α	18 25 up to 80 100
Power loss per unit (max.)	W	10 16.5
Short-circuit protection		
With fuse without contactor		See "Selection and ordering data" on page 7/111
With fuse and contactor		See Reference Manual "Protection Equipment – 3RU1, 3RB2 Overload Relays", http://support.automation.siemens.com/WW/view/en/35681830 → "Technical Specifications" → "Short-circuit protection with fuses/motor starte protectors for motor feeders".
Protective separation between main and auxiliary current paths acc. to IEC 60947-1	V	690
Conductor cross-section of the main circuit		
Connection type		Screw terminals with box terminal
Terminal screw		M8, 4 mm Allen screw
Operating devices	mm	4 mm Allen screw
Prescribed tightening torque	Nm	4 6
<b>Conductor cross-sections (min./max.),</b> 1 or 2 conductors can be connected		
• Solid	$\text{mm}^2$	2 x (2.5 16)
• Finely stranded with end sleeve (DIN 46228-1)	mm <sup>2</sup>	2 x (2.5 35) <sup>1)</sup> , 1 x (2.5 50) <sup>1)</sup>
• Stranded	mm <sup>2</sup>	2 x (10 50) <sup>1)</sup> , 1 x (10 70) <sup>1)</sup>
AWG cables, solid or stranded	AWG	2 x (10 1/0) <sup>1)</sup> , 1 x (10 2/0) <sup>1)</sup>
Ribbon cable conductors (Number x Width x Thickness)	mm	2 x (6 x 9 x 0.8)
Connection type		Busbar connection <sup>2)</sup>
Terminal screw		M6 x 20
Prescribed tightening torque	Nm	4 6
Conductor cross-sections (min./max.)		
Finely stranded with cable lug	mm <sup>2</sup>	2 x 70
Stranded with cable lug	mm <sup>2</sup>	3 x 70
<ul> <li>AWG cables, solid or stranded, with cable lug</li> </ul>	AWG	2/0

12

• With connecting bars (max. width)

<sup>1)</sup> If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.

The box terminal is removable. Rail and cable lug connections are possible if the box terminal is removed.

## SIRIUS 3RU1 Thermal Overload Relays

## 3RU11 up to 100 A for standard applications

Туре		3RU1146
Size		S3
Auxiliary circuit		
Number of NO contacts		1
Number of NC contacts		1
Auxiliary contacts – assignment		NO for the signal "tripped";     NC for disconnecting the contactor
Rated insulation voltage U <sub>i</sub> (pollution degree 3)	V	690
Rated impulse withstand voltage $U_{\rm imp}$	kV	6
Contact rating of the auxiliary contacts		
<ul> <li>NC contact with alternating current AC-14/AC-15, rated operational current I<sub>e</sub> at U<sub>e</sub>:</li> <li>24 V</li> </ul>	٨	
- 24 V - 120 V	A A	4
- 125 V	Α	4
- 230 V - 400 V	A A	3 2
- 400 V - 600 V	A	0.6
- 690 V	Α	0.5
<ul> <li>NO contact with alternating current AC-14/AC-15, rated operational current I<sub>e</sub> at U<sub>e</sub>:</li> </ul>		
- 24 V - 120 V	A	3
- 125 V - 125 V	A A	3
- 230 V	Α	2
- 400 V	A	1
- 600 V - 690 V	A A	0.6 0.5
• NC contact, NO contact with direct current DC-13, rated operational current $I_{\rm e}$ at $U_{\rm e}$ :	,,	0.0
- 24 V - 60 V	A	1 On request
- 60 V - 110 V	A A	On request 0.22
- 125 V	A	0.22
- 220 V	Α	0.11
$ullet$ Conventional thermal current $I_{ m th}$	Α	6
<ul> <li>Contact reliability (suitability for PLC control; 17 V, 5 mA)</li> </ul>		Yes
Short-circuit protection		
With fuse     Operational class gG     Quick	A A	6 10
With miniature circuit breaker (C characteristic)	Α	6 <sup>1)</sup>
Protective separation between auxiliary current paths acc. to IEC 60947-1	V	440
CSA, UL, UR rated data		110
Auxiliary circuit – switching capacity		B600, R300
Conductor cross-sections of the auxiliary circuit		2000, 11000
Connection type		Screw terminals
Terminal screw		M3, Pozidriv size 2
Operating devices	mm	Ø 5 6
Prescribed tightening torque	Nm	0.8 1.2
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected		
• Solid	mm <sup>2</sup>	2 x (0.5 1.5) <sup>2)</sup> , 2 x (0.75 2.5) <sup>2)</sup>
Finely stranded without end sleeve	mm <sup>2</sup>	-
• Finely stranded with end sleeve (DIN 46228-1)	$\text{mm}^2$	2 x (0.5 1.5) <sup>2)</sup> , 2 x (0.75 2.5) <sup>2)</sup>
Stranded	$\text{mm}^2$	2 x (0.5 1.5) <sup>2)</sup> , 2 x (0.75 2.5) <sup>2)</sup>
AWG cables, solid or stranded	AWG	2 x (18 14)
Connection type		Spring-type terminals
Operating devices	mm	3.0 x 0.5 and 3.5 x 0.5
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected		
Solid or stranded	$\text{mm}^2$	2 x (0.5 2.5)
Finely stranded without end sleeve	mm <sup>2</sup>	2 x (0.5 2.5)
Finely stranded with end sleeve (DIN 46228-1)	mm <sup>2</sup>	2 x (0.5 1.5)
AWG cables, solid or stranded	AWG	2 x (20 14)
1) Up to $I_k \le 0.5 \text{ kA}; \le 260 \text{ V}.$	AWG	۵ / (۵ ۱۹)
7 OU TO I <sub>1</sub> ≤ U.5 KA: ≤ 20U V.		

2) If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.

## Overload Relays SIRIUS 3RU1 Thermal Overload Relays

3RU11 up to 100 A for standard applications

## Selection and ordering data

Features and technical specifications:

- · Connection methods
- Main circuit: Screw terminals
- Auxiliary circuit: Either screw or spring-type terminals
- Tripping class CLASS 10
- Overload and phase failure protection
- Auxiliary contacts 1 NO + 1 NC

- Manual and automatic RESET
- · Switch position indicator
- · TEST function
- STOP button
- Integrated sealable cover

## 3RU11 thermal overload relays with screw terminals on the auxiliary current side, CLASS 10

	Size contactor	Trip class	Current setting value of the inverse-time delayed overload release	Short-circuit protection with fuse, type of coordination "2", operational class gG <sup>1)</sup>	DT	Screw terminals (on auxiliary current side)	<b>+</b>	PU (UNIT, SET, M)	PS*	PG
		CLASS	А	А		Article No.	Price per PU			
Size S3										
900 #	For mou	nting onto c	ontactor <sup>2)</sup>			_				
No. of Street, or other Persons and the Street, or other Persons a	S3	10 10	18 25 22 32	63 80	<b>&gt;</b>	3RU1146-4DB0 3RU1146-4EB0		1 1	1 unit 1 unit	41F 41F
o o o		10 10 10 10	28 40 36 50 45 63 57 75	80 125 125 160	<b>* * *</b>	3RU1146-4FB0 3RU1146-4HB0 3RU1146-4JB0 3RU1146-4KB0		1 1 1 1	1 unit 1 unit 1 unit 1 unit	41F 41F 41F 41F
3RU1146B0		10 10	70 90 80 100 <sup>3)</sup>	160 200	<b>&gt;</b>	3RU1146-4LB0 3RU1146-4MB0		1 1	1 unit 1 unit	41F 41F
The same of the	For stan	d-alone inst	allation							
	\$3	10 10 10 10	45 63 57 75 70 90 80 100 <sup>3)</sup>	125 160 160 200	<b>* * *</b>	3RU1146-4JB1 3RU1146-4KB1 3RU1146-4LB1 3RU1146-4MB1		1 1 1	1 unit 1 unit 1 unit 1 unit	41F 41F 41F 41F
3RU1146-4JB1										

1) Maximum protection by fuse only for overload relay, type of coordination "2". Fuse values in connection with contactors, see Reference Manual "Protection Equipment – 3RU1, 3RB2 Overload Relays", http://support.automation.siemens.com/WW/view/en/35681830 → "Technical Specifications" → "Short-Circuit Protection with

Fuses/Motor Starter Protectors for Motor Feeders"

- With the appropriate terminal supports (see "Accessories", page 7/112), the 3RU11 overload relays for mounting onto contactors can also be installed as stand-alone units.
- 3) For overload relays > 100 A, see 3RB2 electronic overload relays, page 7/130 onwards.

### 3RU11 thermal overload relays with screw terminals, CLASS 10

	Size contactor	Trip class	Current setting value of the inverse-time delayed overload release	Short-circuit protection with fuse, type of coordination "2", operational class gG <sup>1)</sup>	DT	Spring-type terminals (on auxiliary current side)	<u> </u>	PU (UNIT, SET, M)	PS*	PG
		CLASS	А	A		Article No.	Price per PU			
Size S3 <sup>2)</sup>										
	For mou	nting onto d	ontactor³)							
	S3	10 10	18 25 22 32	63 80	B B	3RU1146-4DD0 3RU1146-4ED0		1 1	1 unit 1 unit	41F 41F
0 0		10 10	28 40 36 50	80 125	B B	3RU1146-4FD0 3RU1146-4HD0		1 1	1 unit 1 unit	41F 41F
Times I		10	45 63	125	<b></b>	3RU1146-4JD0		1	1 unit	41F
6 Thanks		10	57 75	160	<b></b>	3RU1146-4KD0		1	1 unit	41F
9 6		10	70 90	160	<b></b>	3RU1146-4LD0		4	1 unit	41F

<sup>1)</sup> Maximum protection by fuse only for overload relay, type of coordination "2". Fuse values in connection with contactors, see Reference Manual "Protection Equipment – 3RU1, 3RB2 Overload Relays", http://support.automation.siemens.com/WW/view/en/35681830 → "Technical Specifications" → "Short-Circuit Protection with Fuses/Motor Starter Protectors for Motor Feeders".

<sup>2)</sup> Auxiliary conductor connections with spring-type terminals and main conductor connections with screw terminals.

<sup>3)</sup> With the appropriate terminal supports (see "Accessories", page 7/112), the 3RU11 overload relays for mounting onto contactors can also be installed as stand-alone units.

## SIRIUS 3RU1 Thermal Overload Relays

### **Accessories**

## Overview

## Overload relays for standard applications

The following optional accessories are available for the 3RU11 thermal overload relays:

- Terminal supports for stand-alone installation for the overload relays
- Mechanical RESET (for all sizes)

- Cable release for resetting devices which are difficult to access (for all sizes)
- Electrical remote RESET module in three voltage variants (for all sizes)
- · Terminal covers

## Technical specifications

#### Terminal supports for stand-alone installation

Туре		3RU1946-3AA01
For overload relays		3RU1146
Mounting type		For screw and snap-on mounting onto TH 35 and TH 75 standard mounting rails
Connection for main circuit		
Connection type		Screw terminals with box terminal
Terminal screw	mm	4 mm Allen screw
Operating devices	mm	4 mm Allen screw
Prescribed tightening torque	Nm	4 6
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected		
Solid or stranded	$\text{mm}^2$	2 x (2.5 16)
Finely stranded without end sleeve	$\text{mm}^2$	
• Finely stranded with end sleeve (DIN 46228-1)	$\text{mm}^2$	2 x (2.5 35) <sup>1)</sup> , 1 x (2.5 50) <sup>1)</sup>
Stranded	$\text{mm}^2$	2 x (10 50) <sup>1)</sup> , 1 x (10 70) <sup>1)</sup>
AWG cables, solid or stranded	AWG	2 x (10 1/0) <sup>1)</sup> , 1 x (10 2/0) <sup>1)</sup>
• Ribbon cable conductors (Number x Width x Thickness)	mm	2 x (6 x 9 x 0.8)
1) If two different conductor cross-sections are connected to one clamping		

If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.

## Selection and ordering data

Selection and ord	lering data							
	Version	Size	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
Terminal supports	s for stand-alone installation							
3RU19.6-3AA01	For separate mounting of the overload relays; screw and snap-on mounting onto standard mounting rail	S3	•	3RU1946-3AA01		1	1 unit	41F
Mechanical RESE								
eff.	Resetting plungers, holders and formers	S3	<b>&gt;</b>	3RU1900-1A		1	1 unit	41F
<i>)</i> *	Pushbuttons with extended stroke (12 mm), IP65, Ø 22 mm	S3	В	3SB3000-0EA11		1	1 unit	41J
3RU1900-1A with pushbutton and	Extension plungers For compensation of the distance between the pushbutton and the unlatching button of the relay	S3	A	3SX1335		1	1 unit	41J
extension plunger								



# Overload Relays SIRIUS 3RU1 Thermal Overload Relays

Α	100	Ðς	뭐	-7	-71	.0)	=	-


									Access	01103
	Version			Size	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
Cable releases w	ith holder for RESE1									
	For Ø 6.5 mm holes in max. control panel thi  Length 400 mm  Length 600 mm	the control panel;		\$3 \$3	<b>&gt;</b>	3RU1900-1B 3RU1900-1C		1	1 unit 1 unit	41F 41F
3RU1900-1.										
Modules for remo	Operating range 0.85 power consumption A ON period 0.2 4 s, switching frequency 6 • 24 30 V AC/DC • 110 127 V AC/DC • 220 250 V AC/DC	1.1 × <i>U</i> <sub>s</sub> , .C 80 VA, DC 70 W, 50/h		\$3 \$3 \$3	A A A	3RU1900-2AB71 3RU1900-2AF71 3RU1900-2AM71		1 1 1	1 unit 1 unit 1 unit	41F 41F 41F
3RU1900-2A.71										
Terminal covers										
	Covers for cable lug	s and busbar conr	nections							
	Length 55 mm			S3	В	3RT1946-4EA1		1	1 unit	41B
	<ul><li>Covers for box termi</li><li>Length 20.8 mm</li></ul>	nals		S3	<b>•</b>	3RT1946-4EA2		1	1 unit	41B
General accesso	<b>Version</b>	Size	Color	For overload relays	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
Tools for opening	g spring-type termin	als								
3RA2908-1A	Screwdrivers For all SIRIUS devices with spring-type terminals	Length approx.	Titanium gray/ black, partially insulated	Main and auxiliary circuit connection: 3RU1	A	Spring-type terminals 3RA2908-1A		1	1 unit	41B
Blank labels										
	Unit labeling plates <sup>1)</sup> for SIRIUS devices	20 mm x 7 mm 20 mm x 7 mm	Pastel turquoise	3RU1	D	3RT1900-1SB20		100	340 units	41B
		20 Min x 7 Min	Titanium gray	3RU1	D	3RT2900-1SB20		100	340 units	41B
B0_01428b	Adhesive inscription labels <sup>1)</sup>	19 mm x 6 mm	Pastel turquoise	3RU1	С	3RT1900-1SB60		100	3 060 units	41B
3RT1900-1SB20	for SIRIUS devices	19 mm x 6 mm	Zinc yellow	3RU1	С	3RT1900-1SD60		100	3 060 units	41B

PC labeling system for individual inscription of unit labeling plates available from: murrplastik Systemtechnik GmbH (see Chapter 16, "Appendix" → "External Partners").

## SIRIUS 3RB3 Electronic Overload Relays

3RB30, 3RB31 up to 80 A for standard applications

#### Overview



- 1 Switch position indicator and TEST function of the wiring: Indicates a trip and enables the wiring test.
- 2 Trip class setting/internal ground-fault detection (only 3RB31): Using the rotary switch you can set the required trip class and activate the internal ground-fault detection dependent on the start-up conditions.
- Solid-state test (device test): Enables a test of all important device components and functions.
- Connecting terminals (removable joint block for auxiliary circuits):
   Depending on the device version, the terminals for screw and spring-type connection are configured for the main and auxiliary circuit.
- Selector switch for manual/automatic RESET: With the slide switch you can choose between manual and automatic RESET.
- Motor current setting: Setting the device to the rated motor current is easy with the large rotary knob.
- A device set to manual RESET can be reset locally by pressing the RESET button. On 3RB31 overload relays an electrical remote RESET is integrated.
- 8 Connection for mounting onto contactors:
  Optimally adapted in electrical, mechanical and design terms to the contactors 3RT2. The overload relay can be connected directly using these connection pins. Stand-alone installation is possible as an alternative (in conjunction with a terminal support for stand-alone installation).

A sealable transparent cover can be optionally mounted (accessory). It secures the motor current setting against adjustment.

SIRIUS 3RU3133-4.B0 electronic overload relay

The 3RB30/3RB31 electronic overload relays up to 80 A with internal power supply have been designed for inverse-time delayed protection of loads with normal and heavy starting (for "Function", see the manual

"SIRIUS Innovations – SIRIUS 3RU2/3RB3 Overload Relays", http://support.automation.siemens.com/WW/view/en/60298164) against excessive temperature rises due to overload, phase unbalance or phase failure. An overload, phase unbalance or phase failure result in an increase of the motor current beyond the set rated motor current. This current rise is detected by the current transformers integrated into the devices and evaluated by corresponding solid-state circuits which then output a pulse to the auxiliary contacts. The auxiliary contacts then switch off the load by means of a contactor. The break time depends on the ratio between the tripping current and current setting  $I_{\rm e}$  and is stored in the form of a long-term stable tripping characteristic (see "Characteristic Curves"

http://support.automation.siemens.com/WW/view/en/34290881/134300).

In addition to inverse-time delayed protection of loads against excessive temperature rises due to overload, phase unbalance and phase failure, the 3RB31 electronic overload relays also allow internal ground-fault detection (not possible in conjunction with contactor assemblies for wye-delta starting). This provides protection of loads against high-resistance short circuits due to damage to the insulation material, moisture, condensed water etc.

The "tripped" status is signaled by means of a switch position indicator. Resetting takes place either manually or automatically after the recovery time has elapsed ("Function", see manual "SIRIUS Innovations – SIRIUS 3RU2/3RB3 Overload Relays", http://support.automation.siemens.com/WW/view/en/60298164).

The 3RB3 electronic overload relays are suitable for operation with frequency converters. Please follow the instructions in the manual "SIRIUS Innovations – 3RU2/3RB3 Overload Relays", see http://support.automation.siemens.com/WW/view/en/60298164.

The devices are manufactured in accordance with environmental guidelines and contain environmentally friendly and reusable materials. They comply with all important worldwide standards and approvals.

3RB20 and 3RB21 overload relays in sizes S2 to S10/S12, see page 7/130 onwards.

#### Use in hazardous areas

The 3RB30/3RB31 electronic overload relays are suitable for the overload protection of motors with the following types of protection:

- 🐼 II (2) G [Ex e] [Ex d] [Ex px]
- 🐼 II (2) D [Ex t] [Ex p]

EC type test certificate for Group II, Category (2) G/D exists. It has the number PTB 09 ATEX 3001.

3RB30, 3RB31 up to 80 A for standard applications

#### Article No. scheme

Block of the Author Ma	4 . 0 .	411		OIL	7.1		011	011	4011	440
Digit of the Article No.	1st - 3rd	4th	5th	6th	/th		8th	9th	10th	11th
						-				
Electronic overload relays	3 R B									
SIRIUS 3rd generation		3								
Device series										
Size, rated operational current and power										
Version of the automatic RESET, electrical remote RESET										
Trip class (CLASS)										
Setting range of the overload release										
Connection methods										
Installation type										
Example	3 R B	3	0	1	6	-	1	R	В	0

#### Note:


The Article No. scheme is presented here merely for information purposes and for better understanding of the logic behind the article numbers.

For your orders, please use the article numbers quoted in the catalog in the Selection and ordering data.

#### Benefits

The most important features and benefits of the 3RB30/3RB31 electronic overload relays are listed in the overview table (see "General Data" on page 7/87).

#### Advantages through energy efficiency



Overview of the energy management process

We offer you a unique portfolio for industrial energy management, using an energy management system that helps to optimally define your energy needs. We split up our industrial energy management into three phases – identify, evaluate and realize – and we support you with the appropriate hardware and software solutions in every process phase.

The innovative products of the SIRIUS industrial controls portfolio can also make a substantial contribution to a plant's energy efficiency (see www.siemens.com/sirius/energysaving).

3RB30/3RB31 electronic overload relays contribute to energy efficiency throughout the plant as follows:

- Reduced inherent power loss
- · Less heating of the control cabinet
- Smaller control cabinet air conditioners can be used

## Application

#### Industries

The 3RB30/3RB31 electronic overload relays are suitable for customers from all industries who want to guarantee optimum inverse-time delayed protection of their electrical loads (e.g. motors) under normal and heavy starting conditions (CLASS 5E to 30E), minimize project completion times, inventories and energy consumption, and optimize plant availability and maintenance management.

### Application

The 3RB30/3RB31 electronic overload relays have been designed for the protection of three-phase motors in sinusoidal 50/60 Hz voltage networks. The relays are not suitable for the protection of single-phase AC or DC loads.

The 3RU21 thermal overload relay or the 3RB22/3RB23 solid-state overload relay can be used for single-phase AC loads. For DC loads we recommend the 3RU21 thermal overload relay.

#### **Ambient conditions**

The devices are insensitive to external influences such as shocks, corrosive ambient conditions, ageing and temperature fluctuations.

For the temperature range from -25 °C to +60 °C, the 3RB30/3RB31 electronic overload relays compensate the temperature in accordance with IEC 60947-4-1.

## SIRIUS 3RB3 Electronic Overload Relays

## 3RB30, 3RB31 up to 80 A for standard applications

## Technical specifications

The following technical information is intended to provide an initial overview of the various types of device and functions.

### Detailed information, see

- Manual "SIRIUS Innovations SIRIUS 3RU2/3RB3 Overload Relays", http://support.automation.siemens.com/WW/view/en/60298164
- or specific information on a particular article number via the product data sheet,

http://support.automation.siemens.com/WW/view/en/34290881/133200

		http://support.automation.siemens.com/WW/view/en/34290881/13320							
Туре		3RB301., 3RB311.	3RB302., 3RB312.	3RB3036, 3RB3133					
Size	}	S00	S0	S2					
Dimensions (W x H x D)	· /								
(overload relay with stand-alone installation support)		45 00 00	45 07 04	55 105 117					
<ul> <li>Screw terminals</li> <li>Spring-type terminals</li> </ul>	mm mm	45 x 89 x 80 45 x 102 x 80	45 x 97 x 94 45 x 116 x 95	55 x 105 x 117 55 x 105 x 117					
General data									
Trips in the event of		Overload, phase failure	, and phase unbalance						
		+ ground fault (for 3RB							
Trip class acc. to IEC 60947-4-1	CLASS	3RB30: 10E, 20E; 3RB31: 5E, 10E, 20E or	30E adjustable						
Phase failure sensitivity		Yes							
Reset and recovery									
Reset options after tripping		Manual and automatic electrical remote RESE	RESET, 3RB31 has an integrat Γ (24 V DC)	ed connection for					
Recovery time     For sustametic PECET.		Ammroy Ore-in							
- For automatic RESET - For manual RESET		Approx. 3 min Immediately							
- For remote RESET		Immediately							
Features									
Display of operating state on device			n position indicator slide						
TEST function			by pressing the TEST button/ s and wiring of control circuit to self-monitoring	by actuating the switch					
RESET button		Yes							
STOP button		No							
Protection and operation of explosion-proof motors									
EC type test certificate number according to		PTB 09 ATEX 3001	1 [[]	On request					
directive 94/9/EC (ATEX)		(x) II (2) G [Ex e] [Ex d (x) II (2) G [Ex t] [Ex p]							
		See							
			emens.com/WW/view/en/40591327	7					
Ambient temperatures									
Storage/transport	°C	-40 +80							
Operation	°C	-25 +60							
Temperature compensation	°C	+60							
<ul> <li>Permissible rated current at</li> <li>Temperature inside control cabinet 60 °C</li> <li>Temperature inside control cabinet 70 °C</li> </ul>	%	100 On request							
Repeat terminals									
Coil repeat terminals		Yes	Not required						
Auxiliary contact repeat terminal		Yes	Not required						
Degree of protection acc. to IEC 60529		IP20							
Touch protection acc. to IEC 61140	•	Finger-safe for vertical	contact from the front						
Shock resistance with sine acc. to IEC 60068-2-27	g/ms	15/11 (signaling contact 97/9 "Tripped" position: 9 g/11 ms)	3 in	15/11 (signaling contact 97/98 in "Tripped" position: 8 g/11 ms)					
Electromagnetic compatibility (EMC) – Interference immunity									
Conductor-related interference			1						
- Burst acc. to IEC 61000-4-4 (corresponds to degree of severity 3)	kV	2 (power ports), 1 (sign	al ports)						
- Surge acc. to IEC 61000-4-5 (corresponds to degree of severity 3)	kV								
<ul> <li>Electrostatic discharge according to IEC 61000-4-2 (corresponds to degree of severity 3)</li> </ul>	kV	8 (air discharge), 6 (co	ntact discharge)						
Field-related interference acc. to IEC 61000-4-3 (corresponds to degree of severity 3)	V/m	10							
Electromagnetic compatibility (EMC) – emitted interference		EN 55022 (CISPR 22)	c. to EN 55011 (CISPR 11) and	d					
Resistance to extreme climates – air humidity	%	95							



## 3RB30, 3RB31 up to 80 A for standard applications

Туре		3RB301., 3RB311.	3RB302., 3RB312.	3RB3036, 3RB3133
Size Dimensions (W x H x D)		S00	S0	S2
overload relay with stand-alone installation support)	<i>?</i>	45 00 00	45 07 04	55 405 447
Screw terminals Spring-type terminals	mm mm	45 x 89 x 80 45 x 102 x 80	45 x 97 x 94 45 x 116 x 95	55 x 105 x 117 55 x 105 x 117
General data (continued)				
Dimensions		"Dimensional drawings"	, see	
		<ul><li>http://support.automa</li><li>Product data sheet,</li></ul>	ations – SIRIUS 3RU2/3REtion.siemens.com/WW/vie .siemens.com/WW/view/en/3-	w/en/60298164
nstallation altitude above sea level	m	Up to 2 000		
Mounting position		Any		
Type of mounting		Direct mounting/stand-a	alone installation with term	inal support
Гуре		3RB301., 3RB311.	3RB302., 3RB312.	3RB3036, 3RB3133
Size		S00	S0	S2
Main circuit	1/	000		
Rated insulation voltage <i>U</i> <sub>i</sub> pollution degree 3)	V	690		
Rated impulse withstand voltage $U_{\rm imp}$	kV	6		
Rated operational voltage <i>U</i> <sub>e</sub>	V	690		
Type of current  Direct current  Alternating current		No Yes, 50/60 Hz ± 5 %		
Current setting	Α	0.1 0.4	0.1 0.4	12.5 50
Tarront Sotting		up to	up to	and
Heavy starting	A		10 40 novations – SIRIUS 3RU2/3 on.siemens.com/WW/view/	
Power loss per unit (max.)	W	0.05 0.2	on.siemens.com/ww/view/	611/00230104
Short-circuit protection  With fuse without contactor  With fuse and contactor		"Short-Circuit Protection Feeders", see Configura Selection Data for Fusel	ering data" on pages 7/11s with Fuses/Motor Starter ation Manual for "Configuri less and Fused Load Fee on.siemens.com/WW/view/	Protectors for Motor ng SIRIUS Innovations – ders",
Protective separation between main and auxiliary current paths				
acc. to IEC 60947-1 (pollution degree 2) • For systems with grounded neutral point	V V	690 600		
acc. to IEC 60947-1 (pollution degree 2) For systems with grounded neutral point For systems with ungrounded neutral point		690 600		
acc. to IEC 60947-1 (pollution degree 2) For systems with grounded neutral point For systems with ungrounded neutral point Conductor cross-sections of main circuit		600		
acc. to IEC 60947-1 (pollution degree 2) For systems with grounded neutral point For systems with ungrounded neutral point Conductor cross-sections of main circuit Connection type		600  Screw terminals	M4 Pozidrivojao 2	
acc. to IEC 60947-1 (pollution degree 2) For systems with grounded neutral point For systems with ungrounded neutral point Conductor cross-sections of main circuit Connection type Ferminal screw	V	Screw terminals M3, Pozidriv size 2	M4, Pozidriv size 2	
acc. to IEC 60947-1 (pollution degree 2) For systems with grounded neutral point For systems with ungrounded neutral point Conductor cross-sections of main circuit Connection type  Terminal screw  Degrating devices		600  Screw terminals	M4, Pozidriv size 2 Ø 5 6 2 2.5	
acc. to IEC 60947-1 (pollution degree 2) For systems with grounded neutral point For systems with ungrounded neutral point Conductor cross-sections of main circuit Connection type  Terminal screw Operating devices Prescribed tightening torque Conductor cross-sections (min./max.),	V	Screw terminals M3, Pozidriv size 2 Ø 5 6	Ø 5 6	
cacc. to IEC 60947-1 (pollution degree 2) For systems with grounded neutral point For systems with ungrounded neutral point Conductor cross-sections of main circuit Connection type  Terminal screw  Degrating devices  Prescribed tightening torque Conductor cross-sections (min./max.), 1 or 2 conductors can be connected	V	Screw terminals M3, Pozidriv size 2 Ø 5 6 0.8 1.2  2 × (0.5 1.5) <sup>1</sup> ) 2 × (0.75 2.5) <sup>1</sup> )	Ø 5 6	1 × (1 50) <sup>1)</sup> , 2 × (1 35) <sup>1)</sup>
acc. to IEC 60947-1 (pollution degree 2)  • For systems with grounded neutral point  • For systems with ungrounded neutral point  Conductor cross-sections of main circuit  Connection type  Terminal screw  Operating devices  Prescribed tightening torque  Conductor cross-sections (min./max.),  1 or 2 conductors can be connected  • Solid or stranded  • Finely stranded with end sleeve (DIN 46228-1)	mm Nm	Screw terminals  M3, Pozidriv size 2  Ø 5 6  0.8 1.2  2 x (0.5 1.5) <sup>1)</sup> , 2 x (0.75 2.5) <sup>1</sup> , 2 x (0.5 4) <sup>1)</sup> , 2 x (0.5 1.5) <sup>1</sup> ),	Ø 5 6 2 2.5 2 x (1 2.5) <sup>1</sup> ) 2 x (2.5 10) <sup>1</sup> )	2 x (1 35) <sup>1)</sup> 2 x (1 25) <sup>1)</sup>
acc. to IEC 60947-1 (pollution degree 2)  • For systems with grounded neutral point  • For systems with ungrounded neutral point  Conductor cross-sections of main circuit  Connection type  Terminal screw  Operating devices  Prescribed tightening torque  Conductor cross-sections (min./max.),  1 or 2 conductors can be connected  • Solid or stranded	mm Nm	Screw terminals  M3, Pozidriv size 2  Ø 5 6  0.8 1.2  2 × (0.5 1.5) <sup>1)</sup> , 2 × (0.75 2.5) <sup>1)</sup> , 2 × (0.5 4) <sup>1)</sup> 2 × (0.5 1.5) <sup>1)</sup> , 2 × (0.75 2.5) <sup>1)</sup> , 2 × (0.75 2.5) <sup>1)</sup> , 2 × (1.75 2.5) <sup>1)</sup> , 2 × (20 16) <sup>1)</sup> , 2 × (18 14) <sup>1)</sup> ,	Ø 5 6 2 2.5	2 x (1 35) <sup>1)</sup>
Acc. to IEC 60947-1 (pollution degree 2) For systems with grounded neutral point For systems with ungrounded neutral point Conductor cross-sections of main circuit Connection type  Terminal screw  Degrating devices  Prescribed tightening torque Conductor cross-sections (min./max.), I or 2 conductors can be connected Solid or stranded  Prinely stranded with end sleeve (DIN 46228-1)  AWG cables, solid or stranded	mm Nm mm² mm²	Screw terminals  M3, Pozidriv size 2  Ø 5 6  0.8 1.2  2 × (0.5 1.5) <sup>1</sup> ) 2 × (0.75 2.5) <sup>1</sup> ) 2 × (0.5 1.5) <sup>1</sup> ) 2 × (0.5 1.5) <sup>1</sup> ) 2 × (0.75 2.5) <sup>1</sup> ) 2 × (0.75 2.5) <sup>1</sup> )	Ø 5 6 2 2.5 2 x (1 2.5) <sup>1)</sup> 2 x (2.5 10) <sup>1)</sup> 2 x (1 2.5) <sup>1)</sup> , 2 x (2.5 6) <sup>1)</sup> , max. 1 x 10 2 x (16 12) <sup>1)</sup> , 2 x (14 8) <sup>1)</sup>	2 x (1 35) <sup>1)</sup> 2 x (1 25) <sup>1)</sup> , 1 x (1 35) <sup>1)</sup>
Acc. to IEC 60947-1 (pollution degree 2) For systems with grounded neutral point For systems with ungrounded neutral point Conductor cross-sections of main circuit Connection type  Terminal screw Operating devices Prescribed tightening torque Conductor cross-sections (min./max.), I or 2 conductors can be connected Solid or stranded Finely stranded with end sleeve (DIN 46228-1)  AWG cables, solid or stranded  Connection type	mm Nm mm² mm²	Screw terminals  M3, Pozidriv size 2  Ø 5 6  0.8 1.2  2 x (0.5 1.5) <sup>1)</sup> , 2 x (0.75 2.5) <sup>1)</sup> , 2 x (0.5 4) <sup>1)</sup> , 2 x (0.5 15) <sup>1)</sup> , 2 x (0.5 15) <sup>1)</sup> , 2 x (0.75 2.5) <sup>1</sup> )  2 x (20 16) <sup>1</sup> ), 2 x (18 14) <sup>1)</sup> , 2 x 12  Spring-type term	Ø 5 6 2 2.5 2 x (1 2.5) <sup>1)</sup> 2 x (2.5 10) <sup>1)</sup> 2 x (1 2.5) <sup>1)</sup> , 2 x (2.5 6) <sup>1)</sup> , max. 1 x 10 2 x (16 12) <sup>1)</sup> , 2 x (14 8) <sup>1)</sup>	2 x (1 35) <sup>1)</sup> 2 x (1 25) <sup>1)</sup> , 1 x (1 35) <sup>1)</sup>
Acc. to IEC 60947-1 (pollution degree 2)  For systems with grounded neutral point  For systems with ungrounded neutral point  Conductor cross-sections of main circuit  Connection type  Terminal screw  Operating devices  Prescribed tightening torque  Conductor cross-sections (min./max.),  1 or 2 conductors can be connected  Solid or stranded  Finely stranded with end sleeve (DIN 46228-1)  AWG cables, solid or stranded  Connection type  Operating devices  Conductor cross-sections (min./max.),	mm Nm mm <sup>2</sup> mm <sup>2</sup>	Screw terminals  M3, Pozidriv size 2  Ø 5 6  0.8 1.2  2 × (0.5 1.5) <sup>1)</sup> 2 × (0.75 2.5) <sup>1)</sup> 2 × (0.5 4) <sup>1)</sup> 2 × (0.5 4) <sup>1)</sup> 2 × (0.5 2.5) <sup>1)</sup> 2 × (0.5 2.5) <sup>1)</sup> 2 × (0.75 2.5) <sup>1)</sup> 2 × (18 14) <sup>1)</sup> 2 × (20 16) <sup>1)</sup> 2 × (18 14) <sup>1)</sup> 2 × 12  Spring-type term	Ø 5 6 2 2.5 2 x (1 2.5) <sup>1)</sup> 2 x (2.5 10) <sup>1)</sup> 2 x (1 2.5) <sup>1)</sup> , 2 x (2.5 6) <sup>1)</sup> , max. 1 x 10 2 x (16 12) <sup>1)</sup> , 2 x (14 8) <sup>1)</sup>	2 x (1 35) <sup>1)</sup> 2 x (1 25) <sup>1)</sup> , 1 x (1 35) <sup>1)</sup>
Acc. to IEC 60947-1 (pollution degree 2) For systems with grounded neutral point For systems with ungrounded neutral point Conductor cross-sections of main circuit Connection type  Terminal screw Degrating devices Prescribed tightening torque Conductor cross-sections (min./max.), 1 or 2 conductors can be connected Solid or stranded Finely stranded with end sleeve (DIN 46228-1)  AWG cables, solid or stranded  Connection type  Degrating devices Conductor cross-sections (min./max.), 1 conductor cross-sections (min./max.), 1 conductor cross-sections (min./max.), 1 conductor cross-sections (min./max.), 1 conductor can be connected	mm Nm mm <sup>2</sup> AWG	Screw terminals  M3, Pozidriv size 2  Ø 5 6  0.8 1.2  2 × (0.5 1.5) <sup>1)</sup> 2 × (0.75 2.5) <sup>1)</sup> , 2 × (0.5 4) <sup>1)</sup> 2 × (0.75 2.5) <sup>1)</sup> 2 × (0.75 2.5) <sup>1)</sup> 2 × (20 16) <sup>1)</sup> , 2 × (18 14) <sup>1)</sup> , 2 × 12  Spring-type term  3.0 × 0.5 and 3.5 × 0.5	Ø 5 6 2 2.5  2 x (1 2.5) <sup>1)</sup> 2 x (2.5 10) <sup>1)</sup> 2 x (2.5 6) <sup>1)</sup> , 2 x (2.5 6) <sup>1)</sup> , max. 1 x 10 2 x (16 12) <sup>1)</sup> , 2 x (14 8) <sup>1)</sup>	2 x (1 35) <sup>1)</sup> 2 x (1 25) <sup>1)</sup> , 1 x (1 35) <sup>1)</sup>
acc. to IEC 60947-1 (pollution degree 2)  For systems with grounded neutral point  For systems with ungrounded neutral point  Conductor cross-sections of main circuit  Connection type  Terminal screw  Operating devices  Prescribed tightening torque  Conductor cross-sections (min./max.),  1 or 2 conductors can be connected  Solid or stranded  Finely stranded with end sleeve (DIN 46228-1)  AWG cables, solid or stranded  Connection type  Operating devices  Conductor cross-sections (min./max.),  1 conductor can be connected  Solid or stranded  Finely stranded without end sleeve	mm Nm mm² AWG	Screw terminals  M3, Pozidriv size 2  Ø 5 6  0.8 1.2  2 × (0.5 1.5) <sup>1)</sup> 2 × (0.75 2.5) <sup>1</sup> , 2 × (0.5 4) <sup>1)</sup> 2 × (0.5 4) <sup>1)</sup> 2 × (0.75 2.5) <sup>1</sup> ) 2 × (20 16) <sup>1</sup> ), 2 × (18 14) <sup>1</sup> ), 2 × (18 14) <sup>1</sup> ), 3 × 12  Spring-type term  3.0 × 0.5 and 3.5 × 0.5  1 × (0.5 4) 1 × (0.5 4) 1 × (0.5 2.5)	2 x (1 2.5) <sup>1)</sup> 2 x (2.5 10) <sup>1)</sup> 2 x (2.5 10) <sup>1)</sup> 2 x (2.5 6) <sup>1)</sup> , max. 1 x 10 2 x (16 12) <sup>1)</sup> , 2 x (14 8) <sup>1)</sup> sinals  1 x (1 10) 1 x (1 6)	2 x (1 35) <sup>1)</sup> 2 x (1 25) <sup>1)</sup> , 1 x (1 35) <sup>1)</sup> , 2 x (18 2) <sup>1)</sup> , 1 x (18 1) <sup>1)</sup>
Acc. to IEC 60947-1 (pollution degree 2) For systems with grounded neutral point For systems with ungrounded neutral point Conductor cross-sections of main circuit Connection type  Terminal screw Operating devices Prescribed tightening torque Conductor cross-sections (min./max.), 1 or 2 conductors can be connected Solid or stranded Finely stranded with end sleeve (DIN 46228-1)  AWG cables, solid or stranded  Connection type  Operating devices Conductor cross-sections (min./max.), 1 conductor can be connected Solid or stranded	mm Nm mm <sup>2</sup> AWG	Screw terminals  M3, Pozidriv size 2  Ø 5 6  0.8 1.2  2 x (0.5 1.5) <sup>1)</sup> , 2 x (0.75 2.5) <sup>1)</sup> , 2 x (0.5 4) <sup>1)</sup> 2 x (0.5 4) <sup>1)</sup> 2 x (0.5 4) <sup>1)</sup> 2 x (20 16) <sup>1)</sup> , 2 x (18 14) <sup>1)</sup> , 2 x 12  Spring-type term  3.0 x 0.5 and 3.5 x 0.5	Ø 5 6 2 2.5  2 x (1 2.5) <sup>1)</sup> 2 x (2.5 10) <sup>1)</sup> 2 x (2.5 6) <sup>1)</sup> , 2 x (2.5 6) <sup>1)</sup> , max. 1 x 10 2 x (16 12) <sup>1)</sup> , 2 x (14 8) <sup>1)</sup>	2 x (1 35) <sup>1)</sup> 2 x (1 25) <sup>1)</sup> , 1 x (1 35) <sup>1)</sup>
cc. to IEC 60947-1 (pollution degree 2) For systems with grounded neutral point For systems with ungrounded neutral point Conductor cross-sections of main circuit Connection type  Ferminal screw Operating devices Prescribed tightening torque Conductor cross-sections (min./max.), or 2 conductors can be connected Solid or stranded  Finely stranded with end sleeve (DIN 46228-1)  AWG cables, solid or stranded  Connection type  Operating devices Conductor cross-sections (min./max.), conductor scan be connected Solid or stranded  Finely stranded without end sleeve Finely stranded without end sleeve Finely stranded with end sleeve (DIN 46228-1) AWG cables, solid or stranded	mm Nm mm² AWG	Screw terminals  M3, Pozidriv size 2  Ø 5 6  0.8 1.2  2 × (0.5 1.5) <sup>1)</sup> , 2 × (0.75 2.5) <sup>1)</sup> , 2 × (0.5 4) <sup>1)</sup> 2 × (0.75 2.5) <sup>1)</sup> , 2 × (0.75 2.5) <sup>1)</sup> , 2 × (10.75 2.5) <sup>1)</sup> 3.0 × 0.5 and 3.5 × 0.5  1 × (0.5 4) 1 × (0.5 4) 1 × (0.5 2.5) 1 × (0.5 2.5) 1 × (0.5 2.5) 1 × (0.5 2.5) 1 × (0.5 2.5)	2 x (1 2.5) <sup>1)</sup> , 2 x (2.5 10) <sup>1)</sup> 2 x (2.5 10) <sup>1)</sup> , 2 x (2.5 6) <sup>1)</sup> , 2 x (2.5 6) <sup>1)</sup> , max. 1 x 10 2 x (16 12) <sup>1)</sup> , 2 x (14 8) <sup>1)</sup> , cinals	2 x (1 35) <sup>1)</sup> 2 x (1 25) <sup>1)</sup> , 1 x (1 35) <sup>1)</sup> 2 x (18 2) <sup>1)</sup> , 1 x (18 1) <sup>1)</sup>
acc. to IEC 60947-1 (pollution degree 2) For systems with grounded neutral point For systems with ungrounded neutral point Conductor cross-sections of main circuit Connection type  Ferminal screw Operating devices Prescribed tightening torque Conductor cross-sections (min./max.), I or 2 conductors can be connected Solid or stranded  Finely stranded with end sleeve (DIN 46228-1)  AWG cables, solid or stranded  Connection type  Operating devices Conductor cross-sections (min./max.), I conductor cross-sections (min./max.), I conductor cross-sections (min./max.), I conductor can be connected Solid or stranded Finely stranded without end sleeve Finely stranded with end sleeve (DIN 46228-1)	mm Nm mm² AWG	Screw terminals  M3, Pozidriv size 2  Ø 5 6  0.8 1.2  2 × (0.5 1.5) <sup>1)</sup> , 2 × (0.75 2.5) <sup>1</sup> ), 2 × (0.5 4) <sup>1)</sup> 2 × (0.75 2.5) <sup>1</sup> ) 2 × (0.75 2.5) <sup>1</sup> ) 2 × (20 16) <sup>1</sup> ), 2 × (18 14) <sup>1</sup> ), 2 × 12  Spring-type term  3.0 × 0.5 and 3.5 × 0.5  1 × (0.5 4) 1 × (0.5 2.5) 1 × (0.5 2.5) 1 × (0.5 2.5) 1 × (20 12)	2 x (1 2.5) <sup>1)</sup> , 2 x (2.5 10) <sup>1)</sup> 2 x (2.5 10) <sup>1)</sup> , 2 x (2.5 6) <sup>1)</sup> , 2 x (2.5 6) <sup>1)</sup> , max. 1 x 10 2 x (16 12) <sup>1)</sup> , 2 x (14 8) <sup>1)</sup> , cinals	2 x (1 35) <sup>1)</sup> 2 x (1 25) <sup>1)</sup> , 1 x (1 35) <sup>1)</sup> 2 x (18 2) <sup>1)</sup> , 1 x (18 1) <sup>1)</sup>

<sup>1)</sup> If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.

## SIRIUS 3RB3 Electronic Overload Relays

## 3RB30, 3RB31 up to 80 A for standard applications

Туре		3RB301., 3RB311.	3RB302., 3RB312.	3RB3036, 3RB3133
Size		S00	S0	S2
Auxiliary circuit				
Number of NO contacts		1		
Number of NC contacts		1		
Auxiliary contacts – assignment		1 NO for the signal "trip 1 NC for disconnecting	oped"; g the contactor	
Rated insulation voltage U <sub>i</sub> (pollution degree 3)	V	300	,	
Rated impulse withstand voltage $U_{\rm imp}$	kV	4		
Auxiliary contacts – contact rating				
• NC contact with alternating current AC-14/AC-15, rated operational curren $I_{\rm e}$ at $U_{\rm e}$ : - 24 V	t A	4		
- 120 V	A	4		
- 125 V	Α	4		
- 250 V	Α	3		
• NO contact with alternating current AC-14/AC-15, rated operational current $I_{\rm e}$ at $U_{\rm e}$ : - 24 V	А	4		
- 120 V	A	4		
- 125 V	Α	4		
- 250 V	Α	3		
<ul> <li>NC contact, NO contact with direct current DC-13, rated operational current I<sub>e</sub> at U<sub>e</sub>:</li> <li>24 V</li> </ul>	А	2		
- 60 V	A	0.55		
- 110 V	Α	0.3		
- 125 V - 250 V	A A	0.3 0.11		
		5		
• Conventional thermal current $I_{ m th}$	Α			
Contact reliability (suitability for PLC control; 17 V, 5 mA)		Yes		
Short-circuit protection		_		
With fuse, operational class gG	Α	6		
Ground-fault protection (only 3RB31)			to sinusoidal residual cu	rrents at 50/60 Hz.
$ullet$ Tripping value $I_{\Delta}$		$> 0.75 \times I_{\mathrm{motor}}$		
<ul> <li>Operating range I</li> <li>Response time t<sub>trip</sub> (in steady-state condition)</li> </ul>	S	Lower current setting v	value $< I_{\text{motor}} < 3.5 \times \text{up}$	per current setting value
Integrated electrical remote RESET (only 3RB31)	3	<u> </u>		
Connecting terminals A3, A4		24 V DC may 200 mA	for approx. 20 ms, then	< 10 m∆
Protective separation between auxiliary current paths	V	300	Tor approx. 20 ms, then	V TO TIA
acc. to IEC 60947-1				
CSA, UL, UR rated data				
Auxiliary circuit – switching capacity		3RB30: B600, R300; 3F	RB31: B300, R300	
Conductor cross-sections for auxiliary circuit				
Connection type		Screw terminals	•	
Terminal screw		M3, Pozidriv size 2		
Operating devices	mm	Ø 5 6		
Prescribed tightening torque	Nm	0.8 1.2		
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected				
Solid or stranded	mm <sup>2</sup>	$1 \times (0.5 \dots 4)^{1)},$ $2 \times (0.5 \dots 2.5)^{1)}$		
Finely stranded with end sleeve (DIN 46228-1)	mm <sup>2</sup>	$1 \times (0.5 \dots 2.5)^{1)},$ $2 \times (0.5 \dots 1.5)^{1)}$		
AWG cables, solid or stranded	AWG	2 × (20 14)		
Connection type		Spring-type term	ninals	
Operating devices	mm	3.0 x 0.5		
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected				
Solid or stranded	mm <sup>2</sup>	2 × (0.25 1.5)		
Finely stranded without end sleeve	mm <sup>2</sup>	2 × (0.25 1.5)		
• Finely stranded with end sleeve (DIN 46228-1)	mm <sup>2</sup>	2 × (0.25 1.5)		
AWG cables, solid or stranded	AWG	2 × (24 16)		
The different conductor cross-sections are connected to one clamping.		= ·· (= · ··· 10)		

<sup>1)</sup> If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.

3RB30, 3RB31 up to 80 A for standard applications

## Selection and ordering data


### 3RB30 electronic overload relays, CLASS 10E

Features and technical specifications:

- · Connection methods
  - Sizes S00 and S0:
  - Main and auxiliary circuit: Either screw or spring-type terminals
  - Size S2:
  - Main circuit: Screw terminals with box terminal or as straight-through transformer,
  - auxiliary circuit: Either screw or spring-type terminals
- Overload protection, phase failure protection and unbalance protection
- · Internal power supply
- Auxiliary contacts 1 NO + 1 NC

- Manual and automatic RESET
- Switch position indicator
- TEST function and self-monitoring
- Sealable covers (optional accessory)

PU (UNIT, SET, M) = 1 PS\* = 1 unit PG = 41G



Maximum protection by fuse only for overload relay, type of coordination "2". Fuse values in connection with contactors, see Configuration Manual "Configuring SIRIUS Innovations – Selection Data for Fuseless and Fused Load

Feeders"http://support.automation.siemens.com/WW/view/en/39714188.

With the appropriate terminal supports (see "Accessories", page 7/122), these overload relays can also be installed as stand-alone units.

## SIRIUS 3RB3 Electronic Overload Relays

## 3RB30, 3RB31 up to 80 A for standard applications

### 3RB30 electronic overload relays, CLASS 20E

Features and technical specifications:

- Connection methods
  - Sizes S00 and S0:
  - Main and auxiliary circuit: Either screw or spring-type terminals
  - Size S2:
  - Main circuit: Screw terminals with box terminal or as straight-through transformer,
  - auxiliary circuit: Either screw or spring-type terminals
- Overload protection, phase failure protection and unbalance protection
- Internal power supply
- Auxiliary contacts 1 NO + 1 NC

- Manual and automatic RESET
- Switch position indicator
- TEST function and self-monitoring
- Sealable covers (optional accessory)

 $\begin{array}{ll} PU \text{ (UNIT, SET, M)} &= 1 \\ PS^* &= 1 \text{ unit} \\ PG &= 41G \end{array}$ 

3RB3016-1	TB0 3RB3026-1VB0	3RB3036-1.B0	3RB3036-1.W1	3RB3016	-1TE0 3RB3026-1VE0	3RB3036-1.	D0 3RB3036-1	.X1
Size contactor <sup>2)</sup>	Trip class	Current setting value of the inverse-time delayed overload release	Short-circuit protecti with fuse, type of coordination "2", operational class gG		Screw terminals	⊕ DT	Spring-type terminals	
	01.400	•	٨		Article No.	Price per PU	Article No.	Price per PU
Size S00	CLASS	<u>A</u>	A			po. 1 0		po o
S00	Devices for mou	nting onto contactor	,2)					
000		0.1 0.4	4	<b>&gt;</b>	3RB3016-2RB0	А	3RB3016-2RE0	
	20E	0.32 1.25	6	<b>&gt;</b>	3RB3016-2NB0	А	3RB3016-2NE0	
	20E	1 4	20	<b>&gt;</b>	3RB3016-2PB0	А	3RB3016-2PE0	
	20E	3 12	25	<b>&gt;</b>	3RB3016-2SB0	А	3RB3016-2SE0	
	20E	4 16	25	<b>&gt;</b>	3RB3016-2TB0	А	3RB3016-2TE0	
Size S0								
S0	Devices for mou	nting onto contactor	,2)					
	20E	0.1 0.4	4	<b>&gt;</b>	3RB3026-2RB0	А	3RB3026-2RE0	
	20E	0.32 1.25	6	<b>&gt;</b>	3RB3026-2NB0	А	3RB3026-2NE0	
	20E	1 4	20	<b>&gt;</b>	3RB3026-2PB0	А	3RB3026-2PE0	
	20E	3 12	25	<b>&gt;</b>	3RB3026-2SB0	Α	3RB3026-2SE0	
	20E	6 25	50	<b>&gt;</b>	3RB3026-2QB0	А	3RB3026-2QE0	
	20E	10 40	50	<b>&gt;</b>	3RB3026-2VB0	A	3RB3026-2VE0	
Size S2								
S2	Devices with scre for mounting ont	ew terminals (main o o contactor <sup>2)</sup>						
	20E	12 50	250	<i>NEW</i> A	3RB3036-2UB0	А	3RB3036-2UD0	
	20E	20 80	250	<i>NEW</i> A	3RB3036-2WB0	A	3RB3036-2WD0	
	Devices with stra installation	night-through transf	ormer for stand-al	lone				
	20E	12 50	250	<i>NEW</i> A	3RB3036-2UW1	А	3RB3036-2UX1	
	20E	20 80	250	<i>NEW</i> A	3RB3036-2WW1	А	3RB3036-2WX1	
1)		ally for averload relay to		2) 14511	ba anneanriata tarmina	1 /	"	- 7/100)

<sup>1)</sup> Maximum protection by fuse only for overload relay, type of coordination "2". Fuse values in connection with contactors, see Configuration Manual "Configuring SIRIUS Innovations – Selection Data for Fuseless and Fused Load Feeders"

http://support.automation.siemens.com/WW/view/en/39714188.

<sup>2)</sup> With the appropriate terminal supports (see "Accessories", page 7/122), these overload relays can also be installed as stand-alone units.

## 3RB30, 3RB31 up to 80 A for standard applications

### 3RB31 electronic overload relays, CLASS 5E, 10E, 20E or 30E (adjustable)

Features and technical specifications:

- · Connection methods
  - Sizes S00 and S0:
  - Main and auxiliary circuit: Either screw or spring-type terminals
  - Size S2:
    - Main circuit: Screw terminals with box terminal or as straightthrough transformer,
    - auxiliary circuit: Either screw or spring-type terminals
- Overload protection, phase failure protection and unbalance protection
- Internal ground-fault detection (activatable)
- Internal power supply

- Auxiliary contacts 1 NO + 1 NC
- · Manual and automatic RESET
- Electrical remote RESET integrated
- Switch position indicator
- TEST function and self-monitoring
- Sealable covers (optional accessory)

 $\begin{array}{ll} PU \text{ (UNIT, SET, M)} &= 1 \\ PS^* &= 1 \text{ unit} \\ PG &= 41G \end{array}$ 

2PP0412.4	TB0_3BB3123-4VB0	3BB3133-4-B0	3RB3133-4.W1	3RB311		38B3123-4VE0	3BB31	22.4	DO 3883133-4.	
Size contactor <sup>2)</sup>	Trip class	Current setting value of the inverse-time delayed overload release	Short-circuit prowith fuse, type coordination "2" operational class	otection of		Screw terminals	3RB3 I.	DT	Spring-type terminals	X1
	CLASS	A	A	ss ga /		Article No.	Price per PU		Article No.	Price per PU
Size S00										
S00	Devices for mour	nting onto contacto	r <sup>2)</sup>							
	5E, 10E, 20E or 30E		4		<b>&gt;</b>	3RB3113-4RB0		Α	3RB3113-4RE0	
	adjustable	0.32 1.25	6		<b>&gt;</b>	3RB3113-4NB0		Α	3RB3113-4NE0	
		1 4	20		<b></b>	3RB3113-4PB0		Α	3RB3113-4PE0	
		3 12	25		<b>&gt;</b>	3RB3113-4SB0		Α	3RB3113-4SE0	
		4 16	25		<b></b>	3RB3113-4TB0		Α	3RB3113-4TE0	
Size S0										
S0	Devices for mour	nting onto contacto	r <sup>2)</sup>							
	5E, 10E, 20E or 30E	0.1 0.4	4		<b></b>	3RB3123-4RB0		Α	3RB3123-4RE0	
	adjustable	0.32 1.25	6		<b></b>	3RB3123-4NB0		Α	3RB3123-4NE0	
		1 4	20		<b>&gt;</b>	3RB3123-4PB0		Α	3RB3123-4PE0	
		3 12	25		<b>&gt;</b>	3RB3123-4SB0		Α	3RB3123-4SE0	
		6 25	50		<b>&gt;</b>	3RB3123-4QB0		Α	3RB3123-4QE0	
		10 40	50		▶	3RB3123-4VB0		Α	3RB3123-4VE0	
Size S2										
S2	Devices with screet for mounting onto	ew terminals (main o contactor <sup>2)</sup>	current side) a	nd						
	5E, 10E, 20E or 30E	12 50	250	NEW	Α	3RB3133-4UB0		Α	3RB3133-4UD0	
	adjustable	20 80	250	NEW	Α	3RB3133-4WB0		Α	3RB3133-4WD0	
	Devices with strainstallation	ight-through transf	ormer for stand	l-alone						

NEW A

*NEW* A

20 ... 80

250

250

5E, 10E, 20E or 30E 12 ... 50

adjustable

Α

Α

3RB3133-4UW1

3RB3133-4WW1

3RB3133-4UX1

3RB3133-4WX1

Maximum protection by fuse only for overload relay, type of coordination "2". Fuse values in connection with contactors, see Configuration Manual "Configuring SIRIUS Innovations – Selection Data for Fuseless and Fused Load Feeders"

http://support.automation.siemens.com/WW/view/en/39714188.

With the appropriate terminal supports (see "Accessories", page 7/122), these overload relays can also be installed as stand-alone units.

## SIRIUS 3RB3 Electronic Overload Relays

### **Accessories**

## Overview

## Overload relays for standard applications

The following optional accessories are available for the 3RB30/3RB31 electronic overload relays:

- Size-specific terminal support for stand-alone installation, in sizes S00 and S0 also with spring-type terminals
- Mechanical RESET (for all sizes)
- Cable release for resetting devices which are difficult to access (for all sizes)
- Sealable cover (for all sizes)

	Version	Size	DT	Article No.	Price	PU	PS*	PG
	1000	0.20		, addic ric.	per PU	(UNIT, SET, M)	. 0	
erminal supp	orts for stand-alone installation							
	Terminal supports for overload relays with screw terminals			Screw terminals	<b>(1)</b>			
	For separate mounting of the overload relays;	S00	<b>&gt;</b>	3RU2916-3AA01		1	1 unit	41F
1	screw and snap-on mounting onto standard mounting rail	S0	•	3RU2926-3AA01		1	1 unit	41F
3220		S2 N	EW A	3RU2936-3AA01		1	1 unit	41F
J2916-3AA01	Terminal supports for overload relays with spring-type terminals			Spring-type terminals				
	For separate mounting of the overload relays; screw and snap-on mounting onto standard	S00	В	3RU2916-3AC01		1	1 unit	41F
M	mounting rail	SO	В	3RU2926-3AC01		1	1 unit	41F
U2926-3AA01								
U2936-3AA01								
J2916-3AC01								
RU2926-3AC01	CET							
echanical RE	Resetting plungers, holders and formers	S00 S	32 ▶	3RB3980-0A		1	1 unit	41F
Æ	Pushbuttons with extended stroke (12 mm), IP65, Ø 22 mm	S00 S		3SB3000-0EA11		1	1 unit	41J
5	Extension plungers For compensation of the distance between a pushbutton and the unlatching button of the relay	S00 S	S2 A	3SX1335		1	1 unit	41J

Resetting plungers, holders and formers	S00 S2	<b>&gt;</b>	3RB3980-0A	1	1 unit	41F
Pushbuttons with extended stroke (12 mm), IP65, Ø 22 mm	S00 S2	В	3SB3000-0EA11	1	1 unit	41J
Extension plungers For compensation of the distance between a pushbutton and the unlatching button of the relay	S00 S2	A	3SX1335	1	1 unit	41J



									Access	sories
	Version			Size	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
Cable releases	with holder for RESI	ĒΤ								
Ø	For Ø 6.5 mm holes in t max. control panel thic	the control panel;								
	• Length 400 mm	1111000 0 111111		S00 S2	<b>&gt;</b>	3RB3980-0B		1	1 unit	41F
3RB3980-0.	• Length 600 mm			S00 S2	•	3RB3980-0C		1	1 unit	41F
Sealable covers										
	For covering the setting	g knobs		S00 S2	•	3RB3984-0		1	1 unit	41F
3RB3984-0										
General access	ories									
	Version	Size	Color	For overload relays	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
Tools for opening	ng spring-type termi	inals								
						Spring-type terminals	<u> </u>			
3RA2908-1A	Screwdrivers For all SIRIUS devices with spring-type terminals	Length approx. 200 mm, 3.0 mm x 0.5 mm	Titanium gray/ black, partially insulated	Main and auxiliary circuit connection: 3RB3	A	3RA2908-1A		1	1 unit	41B
Blank labels	11.24 (-1.4.21)	00 7	D 1 1	ODDO		ADT4000 40D00		100	0.40	445
3RT1900-1SB20	Unit labeling plates <sup>1)</sup> for SIRIUS devices	20 mm x / mm	Pastel turquoise	3RB3	D	3RT1900-1SB20		100	340 units	41B
3RT2900-1SB20	om for individual income	20 mm x 7 mm	Titanium gray	3RB3	D	3RT2900-1SB20		100	340 units	41B
of unit labeling pl murrplastik Syste	em for individual inscripti lates available from: emtechnik GmbH "Appendix" → "External									

## More information

## Manuals

- System Manual "SIRIUS Innovations System Overview" http://support.automation.siemens.com/WW/view/en/60311318
- Manual "SIRIUS Innovations SIRIUS 3RU2/3RB3 Overload Relays"
  - http://support.automation.siemens.com/WW/view/en/60298164

## SIRIUS 3RB2 Electronic Overload Relays


### 3RB20, 3RB21 up to 630 A for standard applications

#### Overview

#### Note:

The 3RB20 and 3RB21 devices (sizes S00/S0 to S12) can be found

- in the Catalog Add-On IC 10 AO · 2015 at the Information and Download Center
- in the interactive catalog CA 01
- in the Industry Mall



- 1 Switch position indicator and TEST function of the wiring: Indicates a trip and enables the wiring test.
- 2 Trip class setting/internal ground-fault detection (only 3RB21): Using the rotary switch you can set the required trip class and activate the internal ground-fault detection dependent on the start-up conditions.
- Solid-state test (device test): Enables a test of all important device components and functions.
- (4) Connecting terminals (removable terminal block for auxiliary circuits): The generously sized terminals permit connection of two conductors with different cross-sections for the main and auxiliary circuits. The auxiliary circuit can be connected with screw terminals and alternatively with spring-type terminals.
- (5) Selector switch for manual/automatic RESET: With the slide switch you can choose between manual and automatic RESET.
- Motor current setting: Setting the device to the rated motor current is easy with the large rotary knob.
- 7 A device set to manual RESET can be reset locally by pressing the RESET button. On the 3RB21 overload relay a solid-state remote RESET is integrated.
- (8) Connection for mounting onto contactors: Optimally adapted in electrical, mechanical and design terms to the contactors 3RT1. These connecting pins can be used for direct mounting of the overload relay to the contactor. Stand-alone installation is possible as an alternative (partly in conjunction with a terminal bracket for stand-alone installation).

SIRIUS 3RB2143-4ED0 electronic overload relay

The 3RB20 and 3RB21 electronic overload relays up to 630 A with internal power supply have been designed for inverse-time delayed protection of loads with normal and heavy starting ("Function", see Reference Manual

"Protection Equipment – 3RU1, 3RB2 Overload Relays" http://support.automation.siemens.com/WW/view/en/35681297) against excessive temperature rises due to overload, phase

against excessive temperature rises due to overload, phase unbalance or phase failure.

An overload, phase unbalance or phase failure result in an increase of the motor current beyond the set rated motor current. This current rise is detected by the current transformers integrated into the devices and evaluated by corresponding solid-state circuits which then output a pulse to the auxiliary contacts. The auxiliary contacts then switch off the load by means of a contactor. The break time depends on the ratio between the tripping current and current setting  $I_{\rm e}$  and is stored in the form of a long-term stable tripping characteristic (see "Characteristic Curves" http://support.automation.siemens.com/WW/view/en/20357046/134300).

In addition to inverse-time delayed protection of loads against excessive temperature rises due to overload, phase unbalance and phase failure, the 3RB21 electronic overload relays also allow internal ground-fault detection (not possible in conjunction with contactor assemblies for wye-delta starting). This provides protection of loads against high-resistance short circuits due to damage to the insulation material, moisture, condensed water etc.

The "tripped" status is signaled by means of a switch position indicator. Resetting takes place either manually or automatically after the recovery time has elapsed ("Function", see Reference Manual "Protection Equipment – 3RU1, 3RB2 Overload Relays", http://support.automation.siemens.com/WW/view/en/35681297).

The 3RB2 electronic overload relays are suitable for operation with frequency converters. Please follow the instructions in the Reference Manual "Protection Equipment – 3RU1 and 3RB2 Overload Relays", see

http://support.automation.siemens.com/WW/view/en/35681297.

The devices are manufactured in accordance with environmental guidelines and contain environmentally friendly and reusable materials. They comply with all important worldwide standards and approvals.

For 3RB30 and 3RB31 overload relay sizes S00 to S2, see page 7/119 onwards.

#### Use in hazardous areas

The 3RB20/3RB21 electronic overload relays are suitable for the overload protection of motors with the following types of protection:

- II (2) G [Ex e] [Ex d] [Ex px]
- 🐼 II (2) D [Ex t] [Ex p]

EC type test certificate for Group II, Category (2) G/D exists. It has the number PTB 06 ATEX 3001.

3RB20, 3RB21 up to 630 A for standard applications

#### Article No. scheme

Digit of the Article No.	1st - 3rd	4th	5th	6th	7th		8th	9th	10th	11th
• • • • • • • • • • • • • • • • • • • •						_				
Electronic overload relays	3 R B									
SIRIUS 2nd generation		2								
Device series										
Size, rated operational current and power										
Version of the automatic RESET, electrical remote RESET										
Trip class (CLASS)										
Setting range of the overload release										
Connection methods										
Installation type										
Example	3 R B	2	0	4	6	-	1	Q	В	0

#### Note:

The Article No. scheme is presented here merely for information purposes and for better understanding of the logic behind the article numbers.

For your orders, please use the article numbers quoted in the catalog in the Selection and ordering data.

#### Benefits

The most important features and benefits of the 3RB20/3RB21 electronic overload relays are listed in the overview table (see "General Data", page 7/87 onwards).

## Application

#### Industries

The 3RB20 and 3RB21 electronic overload relays are suitable for customers from all industries who want to guarantee optimum inverse-time delayed protection of their electrical loads (e.g. motors) under normal and heavy starting conditions (CLASS 5 to 30), minimize project completion times, inventories and energy consumption, and optimize plant availability and maintenance management.

## Application

The 3RB20 and 3RB21 electronic overload relays have been designed for the protection of three-phase motors in sinusoidal 50/60 Hz voltage networks. The relays are not suitable for the protection of single-phase AC or DC loads.

The 3RU11 thermal overload relays or the 3RB22 to 3RB24 solid-state overload relays can be used for single-phase AC loads. For DC loads we recommend the 3RU11 thermal overload relay.

#### **Ambient conditions**

The devices are insensitive to external influences such as shocks, corrosive ambient conditions, ageing and temperature fluctuations.

For the temperature range from -25 C to +60 °C, the 3RB20 and 3RB21 electronic overload relays compensate the temperature in accordance with IEC 60947-4-1.

For the 3RB20 and 3RB21 electronic overload relays with the sizes S6, S10 and S12, the upper set value of the setting range must be reduced for ambient temperatures > 50 °C by a certain factor

## SIRIUS 3RB2 Electronic Overload Relays

## 3RB20, 3RB21 up to 630 A for standard applications

## Technical specifications

The following technical information is intended to provide an initial overview of the various types of device and functions.

Detailed information, see Reference Manual "Protection Equipment - Overload Relays 3RU1, 3RB2", http://support.automation.siemens.com/WW/view/en/35681297

Type		3RB2046, 3RB2143	3RB2056, 3RB2153	3RB2066, 3RB2163
Size 1 1 2 2		S3	S6	S10/S12
(overload relay with stand-alone installation	mm	70 x 86 x 124	120 x 119 x 155	145 x 147 x 156
support)				
General data				
Trips in the event of		Overload, phase failure, and + ground fault (for 3RB21 or		
Trip class acc. to IEC 60947-4-1	CLASS	3RB20: 10 or 20; 3RB21: 5, 10, 20 and 30 adj	ustable	
Phase failure sensitivity		Yes		
Overload warning		No		
Reset and recovery  Reset options after tripping		3RB20: Manual and automat 3RB21: Manual, automatic a		
<ul> <li>Recovery time</li> <li>For automatic RESET</li> <li>For manual RESET</li> <li>For remote RESET</li> </ul>		Approx. 3 min Immediately Immediately		
Features				
Display of operating state on device		Yes, by means of switch pos	ition indicator slide	
TEST function		Yes, test of electronics by pr test of auxiliary contacts and indicator slide/self-monitorin	wiring of control circuit by	actuating the switch positio
RESET button		Yes		
STOP button		No		
Protection and operation of explosion-proof motors				
EC type test certificate number according to directive 94/9/EC (ATEX)		PTB 06 ATEX 3001 ⟨	· ·	(222.112.12
A mela in the term of the term		see http://support.automatio	n.siemens.com/vvvv/view/er	/23814648
Ambient temperatures	°C	-40 +80		
• Storage/transport				
Operation     Temperature componenties	°C	-25 +60		
Temperature compensation     Provide line and a surround at	.0	+60		
<ul> <li>Permissible rated current at</li> <li>Temperature inside control cabinet 60 °C, stand-alone installation</li> </ul>	%	100	100	100 or 90 <sup>1)</sup>
<ul> <li>Temperature inside control cabinet 60 °C, mounted on contactor</li> </ul>	%	100	70	70
- Temperature inside control cabinet 70 °C	%	On request		
Degree of protection acc. to IEC 60529		IP20	IP20 (terminal compartment: IP	00 degree of protection)
Touch protection acc. to IEC 61140		Finger-safe for vertical contact from the front	Finger-safe; for busbar connection with cover	Finger-safe
Shock resistance with sine acc. to IEC 60068-2-27	<i>g</i> /ms	15/11 (signaling contact 97/s	98 in position "tripped": 4 g/	11 ms)
Electromagnetic compatibility (EMC) - Interference immunity				
Conductor-related interference     Burst acc. to IEC 61000-4-4	kV	2 (power ports), 1 (signal po	rts)	
(corresponds to degree of severity 3) - Surge acc. to IEC 61000-4-5 (corresponds to degree of severity 3)	kV	2 (line to earth), 1 (line to line	e)	
Electrostatic discharge according to IEC 61000-4-2 (corresponds to degree of severity 3)	kV	8 (air discharge), 6 (contact	discharge)	
Field-related interference acc. to IEC 61000-4-3 (corresponds to degree of severity 3)	V/m	10		
Electromagnetic compatibility (EMC) – emitted interference		Degree of severity B acc. to	EN 55011 (CISPR 11) and E	EN 55022 (CISPR 22)
Resistance to extreme climates – air humidity	%	100		
Dimensions		"Dimensional drawings", see Reference Manual "Protectio http://support.automation.sie	n Equipment - Overload Rel mens.com/WW/view/en/356	ays 3RU1, 3RB2", 81297
Installation altitude above sea level	m	Up to 2 000		
Mounting position		Any		
Type of mounting		Direct mounting/stand-alone installation with terminal support	Direct mounting/stand-alo	ne installation

 $<sup>^{\</sup>rm 1)}$  90 % for relay with current setting range 160 A to 630 A.



## 3RB20, 3RB21 up to 630 A for standard applications

Туре		3RB2046, 3RB2143
Size		S3
Main circuit		
Rated insulation voltage <i>U</i> <sub>i</sub> (pollution degree 3)	V	1 000
Rated impulse withstand voltage $U_{\rm imp}$	kV	8
Rated operational voltage U <sub>e</sub>	V	1 000
Type of current		
Direct current		No
Alternating current		Yes, 50/60 Hz ± 5 %
Current setting	Α	12.5 50, 25 100
Power loss per unit (max.)	W	0.05
Short-circuit protection		
With fuse without contactor		See "Selection and ordering data" on pages 7/130 to 7/132
With fuse and contactor		"Short-Circuit Protection with Fuses/Motor Starter Protectors for Motor Feeders", see Reference Manual "Protection Equipment – 3RU1, 3RB2 Overload Relays", http://support.automation.siemens.com/WW/view/en/35681297 ─ "Technical Specifications" → "Short-Circuit Protection with Fuses for Motor Feeders"
Protective separation between main and auxiliary current paths acc. to IEC 60947-1 (pollution degree 2)		
For systems with grounded neutral point	V	690
For systems with ungrounded neutral point	V	600
Conductor cross-sections of the main circuit		
Connection type		Screw terminals with box terminal
Terminal screw		M8, 4 mm Allen screw
Operating devices		
opolating dovices	mm	4 mm Allen screw
Prescribed tightening torque	mm Nm	4 mm Allen screw 4 6
· •		
Prescribed tightening torque Conductor cross-sections (min./max.), 1 or 2 conductors can be		
Prescribed tightening torque  Conductor cross-sections (min./max.), 1 or 2 conductors can be connected	Nm mm² mm²	4 6
Prescribed tightening torque  Conductor cross-sections (min./max.), 1 or 2 conductors can be connected  Solid	Nm	4 6
Prescribed tightening torque  Conductor cross-sections (min./max.), 1 or 2 conductors can be connected  Solid Finely stranded without end sleeve	Nm mm² mm²	4 6  2 × (2.5 16)  2 × (2.5 35) <sup>1)</sup> ,
Prescribed tightening torque  Conductor cross-sections (min./max.), 1 or 2 conductors can be connected  Solid Finely stranded without end sleeve Finely stranded with end sleeve (DIN 46228-1)	Nm  mm² mm² mm²	4 6  2 × (2.5 16)  2 × (2.5 35) <sup>1)</sup> , 1 × (2.5 50) <sup>1)</sup> 2 × (10 50) <sup>1)</sup> .
Prescribed tightening torque  Conductor cross-sections (min./max.), 1 or 2 conductors can be connected  Solid Finely stranded without end sleeve Finely stranded with end sleeve (DIN 46228-1)  Stranded	Mm  mm² mm² mm² mm² mm²	$4 6$ $2 \times (2.5 16)$ $-2 \times (2.5 35)^{1},$ $1 \times (2.5 50)^{1},$ $2 \times (10 50)^{1},$ $1 \times (10 70)^{1},$ $2 \times (10 1/0)^{1},$
Prescribed tightening torque  Conductor cross-sections (min./max.), 1 or 2 conductors can be connected  Solid Finely stranded without end sleeve Finely stranded with end sleeve (DIN 46228-1)  Stranded  AWG cables, solid or stranded  Ribbon cables	mm² mm² mm² mm²	$4 6$ $2 \times (2.5 16)$ $$ $2 \times (2.5 35)^{1},$ $1 \times (2.5 50)^{1},$ $2 \times (10 50)^{1},$ $1 \times (10 70)^{1},$ $2 \times (10 1/0)^{1},$ $1 \times (10 2/0)^{1},$
Prescribed tightening torque  Conductor cross-sections (min./max.), 1 or 2 conductors can be connected  Solid Finely stranded without end sleeve Finely stranded with end sleeve (DIN 46228-1)  Stranded  AWG cables, solid or stranded  Ribbon cables (Number x Width x Thickness)	mm² mm² mm² mm²	$4 6$ $2 \times (2.5 16)$ $-2 \times (2.5 35)^{1)},$ $1 \times (2.5 50)^{1)},$ $2 \times (10 50)^{1)},$ $1 \times (10 70)^{1)},$ $2 \times (10 1/0)^{1)},$ $1 \times (10 2/0)^{1)},$ $1 \times (10 2/0)^{1)},$ $2 \times (6 \times 9 \times 0.8)$
Prescribed tightening torque  Conductor cross-sections (min./max.), 1 or 2 conductors can be connected  Solid Finely stranded without end sleeve Finely stranded with end sleeve (DIN 46228-1)  Stranded  AWG cables, solid or stranded  Ribbon cables (Number x Width x Thickness)  Connection type	mm² mm² mm² mm²	4 6  2 × (2.5 16)   2 × (2.5 35) <sup>1)</sup> , 1 × (2.5 50) <sup>1)</sup> 2 × (10 50) <sup>1)</sup> , 1 × (10 70) <sup>1)</sup> , 1 × (10 70) <sup>1)</sup> , 1 × (10 2/0) <sup>1)</sup> 2 × (6 × 9 × 0.8)   Busbar connections
Prescribed tightening torque  Conductor cross-sections (min./max.), 1 or 2 conductors can be connected  Solid Finely stranded without end sleeve Finely stranded with end sleeve (DIN 46228-1)  Stranded  AWG cables, solid or stranded  Ribbon cables (Number x Width x Thickness)  Connection type  Terminal screw	mm² mm² mm² mm² AWG	4 6  2 × (2.5 16)   2 × (2.5 35) <sup>1)</sup> , 1 × (2.5 50) <sup>1)</sup> 2 × (10 50) <sup>1)</sup> , 1 × (10 70) <sup>1)</sup> , 1 × (10 1/0) <sup>1)</sup> , 1 × (10 2/0) <sup>1)</sup> 2 × (6 × 9 × 0.8)   Busbar connections  M6 × 20
Prescribed tightening torque  Conductor cross-sections (min./max.), 1 or 2 conductors can be connected  Solid Finely stranded without end sleeve Finely stranded with end sleeve (DIN 46228-1)  Stranded  AWG cables, solid or stranded  Ribbon cables (Number x Width x Thickness)  Connection type  Terminal screw  Prescribed tightening torque	mm² mm² mm² mm² AWG	4 6  2 × (2.5 16)   2 × (2.5 35) <sup>1)</sup> , 1 × (2.5 50) <sup>1)</sup> 2 × (10 50) <sup>1)</sup> , 1 × (10 70) <sup>1)</sup> , 1 × (10 1/0) <sup>1)</sup> , 1 × (10 2/0) <sup>1)</sup> 2 × (6 × 9 × 0.8)   Busbar connections  M6 × 20
Prescribed tightening torque  Conductor cross-sections (min./max.), 1 or 2 conductors can be connected  Solid  Finely stranded without end sleeve  Finely stranded with end sleeve (DIN 46228-1)  Stranded  AWG cables, solid or stranded  Ribbon cables (Number x Width x Thickness)  Connection type  Terminal screw  Prescribed tightening torque  Conductor cross-sections (min./max.)	mm² mm² mm² mm² AWG mm	4 6  2 × (2.5 16)   2 × (2.5 35) <sup>1)</sup> ,  1 × (2.5 50) <sup>1)</sup> 2 × (10 50) <sup>1)</sup> ,  1 × (10 70) <sup>1)</sup> ,  1 × (10 1/0) <sup>1)</sup> ,  1 × (10 2/0) <sup>1)</sup> 2 × (6 × 9 × 0.8)   Busbar connections  M6 × 20  4 6
Prescribed tightening torque  Conductor cross-sections (min./max.), 1 or 2 conductors can be connected  Solid  Finely stranded without end sleeve  Finely stranded with end sleeve (DIN 46228-1)  Stranded  AWG cables, solid or stranded  Ribbon cables (Number x Width x Thickness)  Connection type  Terminal screw  Prescribed tightening torque  Conductor cross-sections (min./max.)  Finely stranded with cable lug	Mm  mm² mm² mm² mm² mm² AWG mm	4 6  2 × (2.5 16)   2 × (2.5 35) <sup>1)</sup> ,  1 × (2.5 50) <sup>1)</sup> ,  1 × (10 50) <sup>1</sup> ,  1 × (10 70) <sup>1)</sup> ,  1 × (10 2/0) <sup>1)</sup> ,  2 × (6 × 9 × 0.8)   Busbar connections  M6 × 20  4 6
Prescribed tightening torque  Conductor cross-sections (min./max.), 1 or 2 conductors can be connected  Solid Finely stranded without end sleeve Finely stranded with end sleeve (DIN 46228-1)  Stranded  AWG cables, solid or stranded Ribbon cables (Number x Width x Thickness)  Connection type  Terminal screw  Prescribed tightening torque  Conductor cross-sections (min./max.) Finely stranded with cable lug  Stranded with cable lug	Mm  mm² mm² mm² mm² AWG mm  Nm  mm²	4 6  2 × (2.5 16)   2 × (2.5 35) <sup>1)</sup> , 1 × (2.5 50) <sup>1)</sup> , 1 × (10 50) <sup>1</sup> , 1 × (10 70) <sup>1)</sup> , 1 × (10 2/0) <sup>1)</sup> , 2 × (10 1/0) <sup>1)</sup> , 1 × (10 2/0) <sup>1)</sup> 2 × (6 × 9 × 0.8)     Oo   Busbar connections     M6 × 20   4 6

18

mm

Diameter of opening

<sup>1)</sup> If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.

## SIRIUS 3RB2 Electronic Overload Relays

## 3RB20, 3RB21 up to 630 A for standard applications

Туре		3RB2056, 3RB2153	3RB2066, 3RB2163
Size		S6	S10/S12
Main circuit			
Rated insulation voltage U <sub>i</sub> (pollution degree 3)	V	1 000	
Rated impulse withstand voltage U <sub>imp</sub>	kV	8	
Rated operational voltage U <sub>e</sub>	V	1 000	
Type of current		NI-	
Direct current     Alternating current		No Yes, 50/60 Hz ± 5 %	
Current setting	Α	50 200	55 250,
			160 630
Power loss per unit (max.)	W	0.05	
Short-circuit protection  With fuse without contactor  With fuse and contactor		See "Selection and ordering data" on pure "Short-Circuit Protection with Fuses/Mo	pages 7/130 to 7/132 otor Starter Protectors for Motor Feeders
		See Reference Manual "Protection Equ	uipment – 3RU1, 3RB2 Overload Relays n/WW/view/en/35681297 → "Technical
Protective separation between main and auxiliary current paths acc. to IEC 60947-1 (pollution degree 2)			
For systems with grounded neutral point     For systems with ungrounded neutral point	V V	690 600	
Conductor cross-sections of the main circuit			
Connection type		Screw terminals with box term	inal
Terminal screw	mm	4 mm Allen screw	5 mm Allen screw
Operating devices	mm	4 mm Allen screw	5 mm Allen screw
Prescribed tightening torque	Nm	1 12	20 22
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected	•		
Solid     Finally stranded without and classes.	mm <sup>2</sup> mm <sup>2</sup>	With 3RT1955-4G box terminal:	 2 × (50 185),
• Finely stranded without end sleeve	111111	$2 \times (1 \times \text{max. } 50, 1 \times \text{max. } 70),$	Rear clamping point only:
		1 × (10 70); With 3RT1956-4G box terminal:	1 × (70 240); rear clamping point only:
		$2 \times (1 \times \text{max. } 95, 1 \times \text{max. } 120),$	1 × (120 185)
• Finely stranded with end sleeve (DIN 46228-1)	mm <sup>2</sup>	1 × (10 120) With 3RT1955-4G box terminal:	2 × (50 185),
.,		$2 \times (1 \times \text{max. } 50, 1 \times \text{max. } 70),$	Rear clamping point only:
		1 × (10 70); With 3RT1956-4G box terminal:	1 × (70 240); rear clamping point only:
		$2 \times (1 \times \text{max. } 95, 1 \times \text{max. } 120),$	1 × (120 185)
Stranded	mm <sup>2</sup>	1 × (10 120) With 3RT1955 -4G box terminal:	2 × (70 240),
onandod		$2 \times (max. 70),$	Rear clamping point only:
		1 × (16 70); With 3RT1956-4G box terminal:	1 × (95 300); rear clamping point only:
		2 × (max. 120),	1 × (120 240)
• AWC cables solid or stranded	۸۱۸۷۵	1 × (16 120)	2 × (2/0 500 kcmil),
AWG cables, solid or stranded	AWG	With 3RT1955-4G box terminal: 2 × (max. 1/0),	rear clamping point only:
		1 × (6 2/0); With 3RT1956-4G box terminal:	1 × (3/0 600 kcmil); rear clamping point only:
		$2 \times (\text{max. } 3/0),$	1 × (250 kcmil 500 kcmil)
Dibbon cables (Number v Width v Thiskness)	mm	1 × (6 250 kcmil) With 3RT1955-4G box terminal:	$2 \times (20 \times 24 \times 0.5)$
Ribbon cables (Number x Width x Thickness)	mm	$2 \times (6 \times 15.5 \times 0.8)$ ,	$2 \times (20 \times 24 \times 0.5),$ $1 \times (6 \times 9 \times 0.8 \dots 20 \times 24 \times 0.5)$
		$1 \times (3 \times 9 \times 0.8 \dots 6 \times 15.5 \times 0.8);$	,
		With 3RT1956-4G box terminal: $2 \times (10 \times 15.5 \times 0.8)$ ,	
		$1 \times (3 \times 9 \times 0.8 \dots 10 \times 15.5 \times 0.8)$	
Connection type		Busbar connections	
Terminal screw		M8 × 25	M10 × 30
Prescribed tightening torque	Nm	10 14	14 24
Conductor cross-sections (min./max.)			
	$mm_{a}^{2}$	16 95 <sup>1)</sup>	50 240 <sup>2)</sup>
Finely stranded with cable lug		25 120 <sup>1)</sup>	70 240 <sup>2)</sup>
Finely stranded with cable lug     Stranded with cable lug	mm <sup>2</sup>		
Finely stranded with cable lug	mm <sup>2</sup> AWG mm	4 250 kcmil 15	2/0 500 kcmil 25
<ul> <li>Finely stranded with cable lug</li> <li>Stranded with cable lug</li> <li>AWG cables, solid or stranded, with cable lug</li> </ul>	mm <sup>2</sup> AWG	4 250 kcmil	2/0 500 kcmil 25

When connecting cable lugs according to DIN 46235 with conductor cross-sections of 95 mm<sup>2</sup> and more, the 3RT1956-4EA1 terminal cover must be used to ensure phase clearance.

When connecting cable lugs according to DIN 46234 with conductor cross-sections of 240 mm<sup>2</sup> and more as well as to DIN 46235 with conductor cross-sections of 185 mm<sup>2</sup> and more, the 3RT1956-4EA1 terminal cover must be used to ensure the phase clearance.

## 3RB20, 3RB21 up to 630 A for standard applications

Туре		3RB2046, 3RB2143	3RB2056, 3RB2153	3RB2066, 3RB2163
Size		S3	S6	S10/S12
Auxiliary circuit				
Number of NO contacts		1		
Number of NC contacts		1		
Auxiliary contacts – assignment		1 NO for the signal "tri 1 NC for disconnecting		
Rated insulation voltage $U_i$ (pollution degree 3)	V	300		
Rated impulse withstand voltage $U_{\rm imp}$	kV	4		
Auxiliary contacts – contact rating  ■ NC contact with alternating current AC-14/AC-15, rated operational current I <sub>e</sub> at U <sub>e</sub> :  - 24 V  - 120 V  - 125 V  - 250 V	A A A	4 4 4 3		
NO contact with alternating current AC-14/AC-15, rated operational current $I_{\rm e}$ at $U_{\rm e}$ : - 24 V - 120 V - 125 V - 250 V	A A A	4 4 4 4 3		
<ul> <li>NC contact, NO contact with direct current DC-13, rated operational current <i>I<sub>e</sub></i> at <i>U<sub>e</sub></i>: <ul> <li>24 V</li> <li>60 V</li> <li>110 V</li> <li>125 V</li> <li>250 V</li> </ul> </li> <li>Conventional thermal current <i>I<sub>th</sub></i></li> </ul>	A A A A	2 0.55 0.3 0.3 0.11		
Contact reliability (suitability for PLC control; 17 V, 5 mA)		Yes		
Short-circuit protection				
With fuse, operational class gG	Α	6		
Ground-fault protection (only 3RB21)			to sinusoidal residual c	urrents at 50/60 Hz.
$ullet$ Tripping value $I_\Delta$		$> 0.75 \times I_{\text{motor}}$	to diriadordar robiadar o	arronto at oo, oo 112.
• Operating range <i>I</i>			value < I . < 3.5 × ur	oper current setting value
Response time t <sub>trip</sub> (in steady-state condition)	s	< 1	raide < 1 motor < 0.0 × di	oper current setting value
Integrated electrical remote RESET (only 3RB21)		<u> </u>		
Connecting terminals A3, A4		24 V DC, 100 mA, 2.4	W short-term	
Protective separation between auxiliary current paths acc. to IEC 60947-1	\/	300	W Short-term	
CSA, UL, UR rated data	_	000		
Auxiliary circuit – switching capacity		B300, R300		
Conductor cross-sections of the auxiliary circuit		D300, 11300		
•		- Carau tarminal		
Connection type		Screw terminals	5	
Terminal screw		M3, Pozidriv size 2		
Operating devices	mm	Ø 5 6		
Prescribed tightening torque	Nm	0.8 1.2		
Conductor cross-sections (min./max.), 1 or 2 conductors can be				
connected  • Collid and atrandad	mm <sup>2</sup>	$1 \times (0.5 \dots 4)^{1}$ , $2 \times (0.5 \dots 4)^{1}$	5 2 5 \ 1)	
Solid and stranded     Finally stranded without and alcount	mm <sup>2</sup>	1 × (0.5 4) '', 2 × (0.	5 2.5) "	
• Finely stranded without end sleeve		1(0.5 0.5)1) 0 (	0.5 4.5\1)	
• Finely stranded with end sleeve (DIN 46228-1)		$1 \times (0.5 \dots 2.5)^{1)}, 2 \times (0.5 \dots 2.5)^{1}$	0.5 1.5) 7	
AWG cables, solid or stranded	AWG	2 × (20 14)	winala	
Connection type		Spring-type term	minals	
Operating devices	mm	3.0 x 0.5		
Operating devices Conductor cross-sections (min./max.), 1 or 2 conductors can be connected	mm	3.0 x 0.5		
Conductor cross-sections (min./max.), 1 or 2 conductors can be		3.0 × 0.5 2 × (0.25 1.5)		
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected				
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected  • Solid and stranded	mm <sup>2</sup>	2 × (0.25 1.5)		

<sup>1)</sup> If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.

## SIRIUS 3RB2 Electronic Overload Relays

## 3RB20, 3RB21 up to 630 A for standard applications

### Selection and ordering data

### 3RB20 electronic overload relays for mounting onto contactors and stand-alone installation, CLASS 10

Features and technical specifications:

- Connection methods
- Size S3
  - Main circuit: Busbar connection with box terminal or as straight-through transformer,
- auxiliary circuit: Either screw or spring-type terminals
- Size S6
- Main circuit: With busbar connection or as straight-through transformer,
- auxiliary circuit: Either screw or spring-type terminals
- Sizes S10/S12:
- Main circuit: With busbar connection,
- auxiliary circuit: Either screw or spring-type terminals

- Overload protection, phase failure protection and unbalance protection
- Internal power supply
- Auxiliary contacts 1 NO + 1 NC
- · Manual and automatic RESET
- · Switch position indicator
- TEST function and self-monitoring

PU(UNIT, SET, M) = 1PS' = 1 unit = 41G



3RB2046-1ED0



160

315

315

3RB2056-1FW2



3RB2066-1MF2

3RB2046-1UB0

3RB2046-1EB0

3RB2046-1EW1

Size contactor	Trip class	Current setting value of the inverse-time delayed overload release	Short-circuit protection with fuse, type of coordina- tion "2", operational class gG <sup>1)</sup>							
	CLASS	A	A							
Size S3										
Devices with	Devices with screw terminals,									

DΤ	Screw terminals (on auxiliary current side)	1	
	Article No.	Price per PU	

Spring-type terminals (on auxiliary current Article No.

Price per PU

## 5

## D

tor mounting	onto contactor	
S3	10	12.5 50
S3	10	25 100

Devices with	straight-through	transformer,
for stand-alo	ne installation	

ior Starie	น-ลเงกษ เกรเลกสถงเ	1		
CO	10	25	100	

S3	10
----	----

Devices with connecting bar,	
for mounting onto contactor and stand-alone installation	,

92	10	٦	50	200	215

Devices with straight-through transformer,

for mounting onto contactor and stand-alone installation

For mounting 50 ... 200 onto S6 contactors with

3RB2056-1FC2

3RB2056-1FF2

3RB2046-1UD0

3RB2046-1ED0

3RB2046-1EX1

3RB2056-1FW2 3RB2056-1FX2

Α

### box terminals Size S10/S12

## Devices with connecting bar,

## for mounting onto contactor and stand-alone installation

S10/S12	10	55 250	400
and size 14 (3TF68/ 3TF69) <sup>2)</sup>	10	160 630	800
31F691 <sup>-7</sup>			

<sup>1)</sup> Maximum protection by fuse only for overload relay, type of coordination "2". For fuse values in connection with contactors, see the Reference Manual "Protection Equipment – 3RU1, 3RB2 Overload Relays", http://support.automation.siemens.com/WW/view/en/35681297 -"Technical Specifications" → "Short-Circuit Protection with Fuses for Motor Feeders".

<sup>3</sup>RB2066-1GC2 3RB2066-1GF2 3RB2066-1MC2 3RB2066-1MF2

<sup>&</sup>lt;sup>2)</sup> For 3TF68/3TF69 contactors, direct mounting is not possible.

3RB20, 3RB21 up to 630 A for standard applications


### 3RB20 electronic overload relays for mounting onto contactors and stand-alone installation, CLASS 20

Features and technical specifications:

- · Connection methods
- Size S3
- Main circuit: Busbar connection with box terminal or as straight-through transformer,
- auxiliary circuit: Either screw or spring-type terminals
- Size Se
- Main circuit: With busbar connection or as straight-through transformer,
- auxiliary circuit: Either screw or spring-type terminals
- Sizes S10/S12:
- Main circuit: With busbar connection,
- auxiliary circuit: Either screw or spring-type terminals

- Overload protection, phase failure protection and unbalance protection
- Internal power supply
- Auxiliary contacts 1 NO + 1 NC
- · Manual and automatic RESET
- Switch position indicator
- TEST function and self-monitoring

 $\begin{array}{ll} PU \text{ (UNIT, SET, M)} &= 1 \\ PS^* &= 1 \text{ unit} \\ PG &= 41G \end{array}$ 



<sup>1)</sup> Maximum protection by fuse only for overload relay, type of coordination "2". For fuse values in connection with contactors, see the Reference Manual "Protection Equipment – 3RU1, 3RB2 Overload Relays", http://support.automation.siemens.com/WW/view/en/35681297 → "Technical Specifications" → "Short-Circuit Protection with Fuses for Motor Feeders"

<sup>&</sup>lt;sup>2)</sup> For 3TF68/3TF69 contactors, direct mounting is not possible.

## SIRIUS 3RB2 Electronic Overload Relays

#### 3RB20, 3RB21 up to 630 A for standard applications

#### 3RB21 electronic overload relays for mounting onto contactors and stand-alone installation, CLASS 5, 10, 20 and 30 adjustable

Features and technical specifications:

- · Connection methods
  - Size S3

Main circuit: Busbar connection with box terminal or as straight-through transformer,

auxiliary circuit: Either screw or spring-type terminals

- Size S6

Main circuit: With busbar connection or as straight-through transformer.

auxiliary circuit: Either screw or spring-type terminals

- Sizes S10/S12:

Main circuit: With busbar connection,

auxiliary circuit: Either screw or spring-type terminals

- Overload protection, phase failure protection and unbalance protection
- Internal ground-fault detection (activatable)
- Internal power supply
- Auxiliary contacts 1 NO + 1 NC
- Manual and automatic RESET
- · Electrical remote RESET integrated
- · Switch position indicator
- TEST function and self-monitoring

PU(UNIT, SET, M) = 1PS\* = 1 unitPG = 41G



3RB2143-4ED0

Size contactor Trip class



3RB2153-4FX2

Current setting value

of the inverse-time

delayed overload

release



3RB2163-4MC2

DT	Screw terminals (on auxiliary current side)	<b>+</b>	DT	Spring-type terminals (on auxiliary current side)	
	Article No.	Price per PU		Article No.	Price per PU

#### Devices with screw terminals, for mounting onto contactor

**CLASS** 

5, 10, 20 and 30 3RB2143-4UD0 S3 12.5 ... 50 160 3RB2143-4UB0 adjustable 25 ... 100 315 3RB2143-4EB0 3RB2143-4ED0 S3

Short-circuit protection with fuse,

type of coordina-

tion "2", operational class gG<sup>1)</sup>

Devices with straight-through transformer, for stand-alone installation

3RB2143-4EW1 S3 3RB2143-4EX1

## Size S6

#### Devices with connecting bar,

## for mounting onto contactor and stand-alone installation

S6 5, 10, 20 and 30 50 ... 200 315 3RB2153-4FC2 3RB2153-4FF2 adjustable

#### Devices with straight-through transformer, for mounting onto contactor and stand-alone installation

For mounting 5, 10, 20 and 30 3RB2153-4FW2 3RB2153-4FX2 onto S6 conadjustable tactors with box terminals

#### Size S10/S12<sup>2)</sup>

## Devices with connecting bar,

for mounting onto contactor and stand-alone installation S10/S12 5, 10, 20 and 30 55 ... 250 400

and size 14 adiustable 160 ... 630 800 (3TF68/ 3TF69)<sup>2)</sup>

<sup>1)</sup> Maximum protection by fuse only for overload relay, type of coordination "2". For fuse values in connection with contactors, see the Reference Manual "Protection Equipment – 3RU1, 3RB2 Overload Relays", http://support.automation.siemens.com/WW/view/en/35681297 → "Technical Specifications" → "Short-Circuit Protection with Fuses for Motor Feeders"

<sup>3</sup>RB2163-4GC2 3RB2163-4GF2 3RB2163-4MC2 3RB2163-4MF2

<sup>&</sup>lt;sup>2)</sup> For 3TF68/3TF69 contactors, direct mounting is not possible.

Accessories for 3RB20, 3RB21

## Overview

## Overload relays for standard applications

The following optional accessories are available for the 3RB20 and 3RB21 electronic overload relays:

• Mechanical RESET (for all sizes)

- Cable release for resetting devices which are difficult to access (for all sizes)
- Sealable cover (for all sizes)
- Terminal covers for sizes S3 to S10/S12
- Box terminal blocks for sizes S6 and S10/S12

#### Selection and ordering data

Selection and ord	ering data						
	Version	Size	DT	Article No. Pric		PS*	PG
Mechanical RESE	Т						
#	Resetting plungers, holders and formers	S3 S10/S12	<b>&gt;</b>	3RU1900-1A	1	1 unit	41F
	Pushbuttons with extended stroke (12 mm), IP65, Ø 22 mm	S3 S10/S12	В	3SB3000-0EA11	1	1 unit	41J
	Extension plungers For compensation of the distance between a pushbutton and the unlatching button of the relay	S3 S10/S12	Α	3SX1335	1	1 unit	41J
3RU1900-1A with pushbutton and extension plunger							
Cable releases wit	th holder for RESET						
A	For Ø 6.5 mm holes in the control panel; max. control panel thickness 8 mm	S3 S10/S12					
	• Length 400 mm		<b>&gt;</b>	3RU1900-1B	1	1 unit	41F
/	• Length 600 mm		<b>&gt;</b>	3RU1900-1C	1	1 unit	41F
3RU1900-1.							
Sealable covers							
Sediable Covers	For covering the setting knobs	S3	<b></b>	3RB2984-0	1	10 units	41F
	To covering the scaling Micos	S10/S12		SIG2504-0	,	10 dilito	711
3RB2984-0 Terminal covers							
Terminal covers	Covers for eable lives and bushes compessions						
Gradbadha 1	Covers for cable lugs and busbar connections  • Length 55 mm	S3	В	3RT1946-4EA1	1	1 unit	41B
	• Length 100 mm	S6	<b>□</b>	3RT1956-4EA1	1	1 unit	41B
Street,	• Length 120 mm	S10/S12		3RT1966-4EA1	1	1 unit	41B
	Covers for box terminals	010/012		OKT 1000 4EAT		1 driit	
	• Length 20.8 mm	S3	<b>&gt;</b>	3RT1946-4EA2	1	1 unit	41B
3RT1956-4EA1	• Length 25 mm	S6	<b>&gt;</b>	3RT1956-4EA2	1	1 unit	41B
South to a	• Length 30 mm	S10/S12	<b></b>	3RT1966-4EA2	1	1 unit	41B
SICMENS	Covers for screw terminals	S6	<b></b>	3RT1956-4EA3	1	1 unit	41B
3RT1956-4EA2	between contactor and overload relay, without box terminals (1 unit required per combination)	S10/S12	<b>&gt;</b>	3RT1966-4EA3	1		41B
Box terminal block	ks						
2 2	For round and ribbon cables						
Bo	• Up to 70 mm <sup>2</sup>	S6 <sup>1)</sup>	<b>&gt;</b>	3RT1955-4G	1	1 unit	41B
Sec Sec .	• Up to 120 mm <sup>2</sup>	S6	<b>&gt;</b>	3RT1956-4G	1	1 unit	41B
	• Up to 240 mm <sup>2</sup>	S10/S12	<b>&gt;</b>	3RT1966-4G	1	1 unit	41B
3RT1954G	For technical specifications for conductor cross-sec Reference Manual "Protection Equipment – 3RU1, 3F Relays", http://support.automation.siemens.com/WW/view/en	RB2 Overload	d				

<sup>1)</sup> In the scope of supply for 3RT1054-1 contactors (55 kW).

## SIRIUS 3RB2 Electronic Overload Relays

## Accessories for 3RB20, 3RB21


## General accessories

	Version	Size	Color	For over- load relays	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
Tools for opening	g spring-type termin	als								
						Spring-type terminals	$\stackrel{\circ}{\square}$			
3RA2908-1A	Screwdrivers For all SIRIUS devices with spring-type terminals	Length approx. 200 mm, 3.0 mm x 0.5 mm	Titanium gray/ black, partially insulated	Main and auxiliary circuit connection: 3RB2	Α	3RA2908-1A		1	1 unit	41B
Blank labels										
	Unit labeling plates <sup>1)</sup> for SIRIUS devices	20 mm x 7 mm	Pastel turquoise	3RB2	D	3RT1900-1SB20		100	340 units	41B
		20 mm x 7 mm	Titanium gray	3RB2	D	3RT2900-1SB20		100	340 units	41B
0.014296	Adhesive inscription labels 1)	19 mm x 6 mm	Pastel turquoise	3RB2	С	3RT1900-1SB60		100	3 060 units	41B
	For SIRIUS devices	19 mm x 6 mm	Zinc yellow	3RB2	С	3RT1900-1SD60		100	3 060 units	41B
3RT2900-1SB20										

PC labeling system for individual inscription of unit labeling plates available from: murrplastik Systemtechnik GmbH (see Chapter 16, "Appendix" → "External Partners").

3RB22, 3RB23 up to 630 A for High-Feature applications

## Overview



- 3RB2985 function expansion module:
   Enables more functions to be added, e.g. internal ground-fault detection and/or an analog output with corresponding signals.
- 2 Motor current and trip class setting: Setting the device to the motor current and to the required trip class dependent on the start-up conditions is easy with the two rotary switches
- 3 Connecting terminals (removable joint block): The generously sized terminals permit connection of two conductors with different cross-sections for the auxiliary, control and sensor circuits. Connection is possible with screw connection and alternatively with spring-type connection.
- Test/RESET button:
   Enables testing of all important device components and functions, plus resetting of the device after a trip when manual RESET is selected.
- (5) Selector switch for manual/automatic RESET: With this switch you can choose between manual and automatic RESET:
- Red LED "OVERLOAD":
   A continuous red light signals an active overload trip; a flickering red light signals an imminent trip (overload warning).
- Red LED "THERMISTOR":
  A continuous red light signals an active thermistor trip.
- Red LED "GND FAULT":
   A continuous red light signals a ground-fault tripping.
- (9) Green LED "READY": A continuous green light signals that the device is working correctly.

SIRIUS 3RB22 and 3RB23 evaluation modules

are supplied from an external voltage.

The 3RB22 and 3RB23 electronic overload relays up to 630 A (up to 820 A possible in combination with a series transformer) are from a modular system and comprise an evaluation unit, a current measuring module and a connecting cable. The 3RB22 overload relays (with monostable auxiliary contacts) and the 3RB23 overload relays (with bistable auxiliary contacts)

These units have been designed for inverse-time delayed protection of loads with normal and heavy starting ("Function", see Reference Manual

"Protection Equipment – 3RU1, 3RB2 Overload Relays", http://support.automation.siemens.com/WW/view/en/35681297) against excessive temperature rises due to overload, phase unbalance or phase failure. An overload, phase unbalance or

against excessive temperature rises due to overload, phase unbalance or phase failure. An overload, phase unbalance or phase failure result in an increase of the motor current beyond the set rated motor current.

This current rise is detected by means of a current measuring module (see page 7/152) and electronically evaluated by the evaluation module which is connected to it. The evaluation electronics sends a signal to the auxiliary contacts. The auxiliary contacts then switch off the load by means of a contactor.

The break time depends on the ratio between the tripping current and current setting  $I_{\rm e}$  and is stored in the form of a long-term stable tripping characteristic (see "Characteristic Curves" http://support.automation.siemens.com/WW/view/en/20357046/134300).

The "tripped" status is signaled by means of a continuous red "OVERLOAD" LED.

The LED indicates imminent tripping of the relay due to overload, phase unbalance or phase failure by flickering when the limit current has been violated. In the case of the 3RB22 and 3RB23 overload relays this warning can also be issued through auxiliary contacts.

In addition to the described inverse-time delayed protection of loads against excessive temperature rises, the 3RB22 and 3RB23 electronic overload relays also allow direct temperature monitoring of the motor windings (full motor protection) by connection with broken-wire interlock of a PTC sensor circuit. With this temperature-dependent protection, the loads can be protected against overheating caused indirectly by reduced coolant flow, for example, which cannot be detected by means of the current alone. In the event of overheating, the devices switch off the contactor, and thus the load, by means of the auxiliary contacts. The "tripped" status is signaled by means of a continuously illuminated "THERMISTOR" LED.

To protect the loads against high-resistance short circuits due to damage to the insulation, humidity, condensed water, etc., the 3RB22 and 3RB23 electronic overload relays offer the possibility of internal ground-fault detection in conjunction with a function expansion module (for details, see Reference Manual "Protection Equipment - Overload Relays 3RU1, 3RB2", http://support.automation.siemens.com/WW/view/en/35681297, not possible in conjunction with contactor assemblies for wye-delta starting). In the event of a ground fault the 3RB22 and 3RB23 relays trip instantaneously.

The "tripped" status is signaled by means of a continuous red "Ground Fault" LED. Signaling through auxiliary contacts is also possible.

After tripping due to overload, phase unbalance, phase failure, thermistor or ground-fault tripping, the relay is reset manually or automatically after the recovery time has elapsed ("Function", see Reference Manual

"Protection Equipment – 3RU1, 3RB2 Overload Relays" http://support.automation.siemens.com/WW/view/en/35681297). In conjunction with a function expansion module, the motor current measured by the microprocessor can be output in the form of an analog signal DC 4 mA to 20 mA for operating rotary coil instruments or for feeding into analog inputs of programmable logic controllers.

With an additional AS-Interface analog module the current values can also be transferred over the AS-i bus system.

The 3RB2 electronic overload relays are suitable for operation with frequency converters. Please follow the instructions in the Reference Manual "Protection Equipment – 3RU1 and 3RB2 Overload Relays", see

http://support.automation.siemens.com/WW/view/en/35681297.

The devices are manufactured in accordance with environmental guidelines and contain environmentally friendly and reusable materials. They comply with all important worldwide standards and approvals.

#### Use in hazardous areas

The 3RB22 electronic overload relays (monostable) with the 3RB29 current measuring module are suitable for the overload protection of explosion-proof motors.

EC type test certificate for Category (2) G/D exists. It has the number PTB 05 ATEX 3022.

## SIRIUS 3RB2 Electronic Overload Relays

## 3RB22, 3RB23 up to 630 A for High-Feature applications

#### Article No. scheme

Digit of the Article No.	1st - 3rd	4th	5th	6th	7th		8th	9th	10th	11th	
						-					
Electronic overload relays	3 R B										
SIRIUS 2nd generation		2									
Device series											
Size, rated operational current and power											
Version of the automatic RESET, electrical remote RESET											
Trip class (CLASS)											
Setting range of the overload release											
Connection methods											
Installation type											
Example	3 R B	2	2	8	3	-	4	Α	Α	1	

### Note:


The Article No. scheme is presented here merely for information purposes and for better understanding of the logic behind the article numbers.

For your orders, please use the article numbers quoted in the catalog in the Selection and ordering data.

#### Benefits

The most important features and benefits of the 3RB22 and 3RB23 electronic overload relays are listed in the overview table (see "General Data", page 7/87 onwards).

#### Advantages through energy efficiency



Overview of the energy management process

We offer you a unique portfolio for industrial energy management, using an energy management system that helps to optimally define your energy needs. We split up our industrial energy management into three phases – identify, evaluate, and realize – and we support you with the appropriate hardware and software solutions in every process phase.

The innovative products of the SIRIUS industrial controls portfolio can also make a substantial contribution to a plant's energy efficiency (see www.siemens.com/sirius/energysaving).

3RB22 and 3RB23 electronic overload relays contribute to energy efficiency throughout the plant as follows:

- Reduced inherent power loss
- · Less heating of the control cabinet
- Smaller control cabinet air conditioners can be used

## Application

#### Industries

The 3RB22 and 3RB23 electronic overload relays are suitable for customers from all industries who want to guarantee optimum inverse-time delayed and temperature-dependent protection of their electrical loads (e.g. motors) under normal and heavy starting conditions (CLASS 5 to 30), minimize project completion times, inventories and energy consumption, and optimize plant availability and maintenance management.

### Application

The 3RB22 and 3RB23 devices have been designed for the protection of three-phase asynchronous and single-phase AC motors.

If single-phase AC motors are to be protected by the 3RB22 and 3RB23 electronic overload relays, the main current paths of the current measuring modules must be series-connected ("Circuit Diagrams" see Reference Manual

("Circuit Diagrams", see Reference Manual "Protection Equipment - 3RU1, 3RB2 Overload Relays

"http://support.automation.siemens.com/WW/view/en/35681297).

#### Ambient conditions

The devices are insensitive to external influences such as shocks, corrosive ambient conditions, ageing and temperature fluctuations.

For the temperature range from  $-25\,^{\circ}\text{C}$  to  $+60\,^{\circ}\text{C}$ , the 3RB22 and 3RB23 electronic overload relays compensate the temperature in accordance with IEC 60947-4-1.

Configuration notes for use of the devices below –25  $^{\circ}\text{C}$  or above +60  $^{\circ}\text{C}$  on request.

3RB22, 3RB23 up to 630 A for High-Feature applications

## Technical specifications

The following technical information is intended to provide an initial overview of the various types of device and functions.

### Detailed information, see

- Reference Manual "Protection Equipment 3RU1, 3RB2 Overload Relays", http://support.automation.siemens.com/WW/view/en/35681297
- or specific information on a particular article number via the product data sheet,

T O . d dd		0DD0000 44 4	000000 44 4
Type – Overload relay: evaluation modules	/ /	3RB2283-4A.1	3RB2383-4A.1

Type – Overload relay: evaluation modules		3RB2283-4A.1 3RB2383-4A.1
Size contactor		S00 S10/S12
Dimensions of evaluation modules (W x H x D)	mm	45 x 111 x 95
General data		
Trips in the event of		Overload, phase failure and phase unbalance (> 40 % according to NEMA), + ground fault (with corresponding function expansion module) and activation of the thermistor motor protection (with closed PTC sensor circuit)
Trip class acc. to IEC 60947-4-1	CLASS	5, 10, 20 and 30 adjustable
Phase failure sensitivity		Yes
Overload warning		Yes, from 1.125 × $I_{\rm e}$ for symmetrical loads and from 0.85 × $I_{\rm e}$ for unsymmetrical loads
Reset and recovery		
Reset options after tripping		Manual, automatic and remote RESET
Recovery time		
- For automatic RESET	min.	<ul> <li>for tripping due to overcurrent: 3 (stored permanently)</li> <li>for tripping by thermistor: time until the motor temperature has fallen 5 K below the response temperature</li> <li>for tripping due to a ground fault: no automatic RESET</li> </ul>
- For manual RESET	min.	<ul> <li>for tripping due to overcurrent: 3 (stored permanently)</li> <li>for tripping by thermistor: time until the motor temperature has fallen 5 K below the response temperature</li> </ul>
- For remote RESET	min.	<ul> <li>for tripping due to a ground fault: Immediately</li> <li>for tripping due to overcurrent: 3 (stored permanently)</li> <li>for tripping by thermistor: time until the motor temperature has fallen 5 K below the response temperature</li> <li>for tripping due to a ground fault: Immediately</li> </ul>
Features		
Display of operating state on device		Yes, with four LEDs: - green LED "Ready" - red LED "Ground Fault" - red LED "Thermistor" - red LED "Overload"
TEST function		Yes, test of LEDs, electronics, auxiliary contacts and wiring of control circuit by pressing the button TEST/RESET / self-monitoring
RESET button		Yes, with the TEST/RESET button
STOP button		No
Protection and operation of explosion-proof motors		
EC type test certificate number according to directive 94/9/EC (ATEX)		PTB 05 ATEX 3022 ( II (2) GD, see http://support.automation.siemens.com/WW/view/en/23115758
Ambient temperatures	-	
Storage/transport	°C	-40 +80
Operation	°C	-25 +60
Temperature compensation	°C	+60
Permissible rated current     Temperature inside control cabinet 60 °C     Temperature inside control cabinet 70 °C	%	100 On request
- Temperature inside control cabinet 70 °C  Degree of protection acc. to IEC 60529	%	On request  IP20: Current measuring modules in sizes S6 and S10/S12 with busbar connectio in conjunction with cover.
Touch protection acc. to IEC 61140		Finger-safe: Current measuring modules in sizes S6 and S10/S12 with busbar connection in conjunction with cover.
Shock resistance with sine acc. to IEC 60068-2-27	<i>g</i> /ms	15/11
Electromagnetic compatibility (EMC) – Interference immunity	,	
Conductor-related interference     Burst acc. to IEC 61000-4-4     (agreement of agree of agree; it 2)	kV	2 (power ports), 1 (signal port)
(corresponds to degree of severity 3) - Surge acc. to IEC 61000-4-5 (corresponds to degree of severity 3)	kV	2 (line to earth), 1 (line to line)
Electrostatic discharge according to IEC 61000-4-2 (corresponds to degree of severity 3)	kV	8 (air discharge), 6 (contact discharge)
<ul> <li>Field-related interference according to IEC 61000-4-3 (corresponds to degree of severity 3)</li> </ul>	V/m	10
Electromagnetic compatibility (EMC) – emitted interference		Degree of severity A according to EN 55011 (CISPR 11) and EN 55022 (CISPR 22

## SIRIUS 3RB2 Electronic Overload Relays

## 3RB22, 3RB23 up to 630 A for High-Feature applications

Type – Overload relay: evaluation modules Size contactor Dimensions of evaluation modules (W x H x D)	· · mm	<b>3RB2283-4A.1</b> S00 S10/S12 45 x 111 x 95						
General data (continued)								
Resistance to extreme climates – air humidity	%	100						
Dimensions		"Dimensional drawings", see  Reference Manual "Protection Equipment – 3RU1, 3RB2 Overload Relays", http://support.automation.siemens.com/WW/view/en/35681297  Product data sheet, http://support.automation.siemens.com/WW/view/en/20357046/133200						
Installation altitude above sea level	m	Up to 2 000						
Mounting position		Any						
Type of mounting								
Evaluation modules		Stand-alone installation						
Current measuring module		S00 to S3: Stand-alone installation, S6 and S10/S12: stand-alone installation or mounting onto contactors						

Type – Overload relay: evaluation modules		3RB2283-4A.1, 3RB2383-4A.1
Size contactor		S00 S10/S12
Auxiliary circuit		
Number of NO contacts		2
Number of NC contacts		2
Number of CO contacts		**
Auxiliary contacts – assignment		Alternative 1  1 NO for the signal "tripped by overload and/or thermistor"  1 NC for disconnecting the contactor  1 NC for disconnecting the contactor  1 NC for disconnecting the contactor  or 1  Alternative 2  1 NO for the signal "tripped by overload and/or thermistor and/or ground fault"  1 NC for disconnecting the contactor  1 NC for disconnecting the contactor  1 NC for disconnecting the contactor  1 NC for disconnecting the contactor
Rated insulation voltage <i>U</i> <sub>i</sub> (pollution degree 3)	V	300
Rated impulse withstand voltage U <sub>imp</sub>	kV	4
Auxiliary contacts – contact rating		
<ul> <li>NC contact with alternating current AC-14/AC-15, rated operational current I<sub>e</sub> at U<sub>e</sub></li> <li>24 V</li> <li>120 V</li> <li>125 V</li> <li>250 V</li> </ul>	A A A	6 6 6 3
NO contact with alternating current AC-14/AC-15, rated operational current $I_e$ at $U_e$ 120 V 125 V 250 V	A A A	6 6 6 3
• NC contact, NO contact with direct current DC-13, rated operational current $I_{\rm e}$ at $U_{\rm e}$ = 24 V = 60 V = 110 V = 125 V = 250 V	A A A A	2 0.55 0.3 0.3
$ullet$ Conventional thermal current $I_{ m th}$	Α	5
Contact reliability (suitability for PLC control; 17 V, 5 mA)		Yes
Short-circuit protection		
With fuse, operational class gG	Α	6
With miniature circuit breaker, C characteristic	Α	1.6
Protective separation between auxiliary current paths acc. to IEC 60947-1	V	300
CSA, UL, UR rated data		
Auxiliary circuit – switching capacity		B300, R300

<sup>1)</sup> The assignment of auxiliary contacts may be influenced by function expansion modules.

## 3RB22, 3RB23 up to 630 A for High-Feature applications

Type – Overload relay: evaluation modules		3RB2283-4A.1, 3RB2383-4A.1
Size contactor		S00 S10/S12
Control circuit		3 4 2 2
Rated insulation voltage $U_i$	V	300
(pollution degree 3)	•	
Rated impulse withstand voltage U <sub>imp</sub>	kV	4
Rated control supply voltage U <sub>s</sub>		
• 50/60 Hz AC	V	24 240
• DC	V	24 240
Operating range		
• 50/60 Hz AC		$0.85 \times U_{\text{S min}} \le U_{\text{S}} \le 1.1 \times U_{\text{S max}}$
• DC		$0.85 \times U_{\text{S min}} \le U_{\text{S}} \le 1.1 \times U_{\text{S max}}$
Rated power		
• 50/60 Hz AC	W	0.5
• DC	W	0.5
Mains buffering time	ms	200
Sensor circuit		
Thermistor motor protection (PTC thermistor sensor)		
Summation cold resistance	kΩ	≤ 1.5
Response value	kΩ	3.4 3.8
Return value	kΩ	1.5 1.65
Ground-fault detection		The information refers to sinusoidal residual currents at 50/60 Hz.
• Tripping value $I_{\Delta}^{(1)}$		
$ \begin{split} & \bullet \text{ Tripping value } I_{\Delta}^{\ 1)} \\ & - \text{ For } 0.3 \times I_{\text{e}} < I_{\text{motor}} < 2.0 \times I_{\text{e}} \\ & - \text{ For } 2.0 \times I_{\text{e}} < I_{\text{motor}} < 8.0 \times I_{\text{e}} \end{split} $		$> 0.3 \times I_{\rm e}$ $> 0.15 \times I_{\rm motor}$
• Response time $t_{\text{trip}}$	ms	500 1 000
Analog output <sup>1)2)</sup>		
Rated values		
Output signal	mA	4 20
Measuring range		$0 \dots 1.25 \times I_{\rm P}$
		4 mA corresponds to $0 \times I_{\circ}$
		16.8 mA corresponds to 1. $\overset{\circ}{0}$ × $I_{\rm e}$ 20 mA corresponds to 1.25 × $I_{\rm e}$
• Load, max.	Ω	100
Conductor cross-sections for the auxiliary, contr		
sensor circuit as well as the analog output	oi aiia	
Connection type		Screw terminals
		Screw terminals
Terminal screw		M3, Pozidriv size 2
Operating devices	mm	3.0 x 0.5
Prescribed tightening torque	Nm	0.8 1.2
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected		
Solid or stranded	mm <sup>2</sup>	$1 \times (0.5 \dots 4)^{3)}, 2 \times (0.5 \dots 2.5)^{3)}$
Finely stranded without end sleeve	mm <sup>2</sup>	(0.0 1) , £ ^ (0.0 £.0)
Finely stranded with end sleeve (DIN 46228-1)	mm <sup>2</sup>	$1 \times (0.5 \dots 2.5)^{3}, 2 \times (0.5 \dots 1.5)^{3}$
AWG cables, solid or stranded	AWG	2 × (20 14)
Connection type	, WV G	Spring-type terminals
Operating devices	mm	3.0 x 0.5
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected		
Solid or stranded	$\rm mm^2$	2 × (0.25 1.5)
Finely stranded without end sleeve	$\rm mm^2$	
• Finely stranded with end sleeve (DIN 46228-1)	$\text{mm}^2$	2 × (0.25 1.5)
AWG cables, solid or stranded	AWG	2 × (24 16)
4)		3) ( ) ( )

<sup>1)</sup> For the 3RB22 and 3RB23 overload relays in combination with a corresponding function expansion module.

<sup>2)</sup> Analog input modules, e.g. SM 331, must be configured for 4-wire measuring transducers. In this case the analog input module must not supply current to the analog output of the 3RB22 and 3RB23 relay.

<sup>3)</sup> If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.

## 3RB22, 3RB23 up to 630 A for High-Feature applications

## Selection and ordering data

## Functions of the 3RB22 and 3RB23 evaluation modules in combination with the 3RB2985 function expansion modules

Evaluation modules	With function	Basic functions	Inputs							
	expansion module		A1/A2	T1/T2	Y1/Y2					
3		Inverse-time delayed protection, temperature-dependent protection, electrical remote RESET, overload warning	Power supply 24 240 V AC/DC	Connection for PTC sensor	Electrical remote RESET					
			Power supply 24 240 V AC/DC	Connection for PTC sensor	Electrical remote RESET					
	3RB2985-2CB1	Inverse-time delayed protection, temperature-dependent protection, internal ground-fault detection, electrical remote RESET, ground-fault signal	Power supply 24 240 V AC/DC	Connection for PTC sensor	Electrical remote RESET					
	3RB2985-2AA0	Inverse-time delayed protection, temperature-dependent protection, electrical remote RESET, overload warning, analog output	Power supply 24 240 V AC/DC	Connection for PTC sensor	Electrical remote RESET					
	3RB2985-2AA1	Inverse-time delayed protection, temperature-dependent protection, internal ground-fault detection, electrical remote RESET, overload warning, analog output	Power supply 24 240 V AC/DC	Connection for PTC sensor	Electrical remote RESET					
	3RB2985-2AB1	Inverse-time delayed protection, temperature-dependent protection, internal ground-fault detection, electrical remote RESET, ground-fault signal, analog output	Power supply 24 240 V AC/DC	Connection for PTC sensor	Electrical remote RESET					

Evaluation modules	With function	· · · · · · · · · · · · · · · · · · ·												
	expansion module	I (-) / I (+)	95/96 NC	97/98 NO	05/06 NC	07/08 NO								
3RB2283-4AA1 3RB2383-4AC1 3RB2383-4AC1 3RB2383-4AC1 3RB2985-2CA1  3RB2985-2CB1  3RB2985-2AA0  3RB2985-2AA1		No	Disconnection of the contactor (inverse- time delayed/tempe- rature-dependent protection)	Signal "tripped"	Overload warning	Overload warning								
	3RB2985-2CA1	No	Disconnection of the contactor (inverse-time delayed/temperature-dependent protection + ground fault)	Signal "tripped"	Overload warning	Overload warning								
	3RB2985-2CB1	No	Disconnection of the contactor (inverse- time delayed/tempe- rature-dependent protection)	Signal "tripped"	Disconnection of the contactor (ground fault)	Signal "ground-fault tripping"								
	3RB2985-2AA0	Analog signal	Disconnection of the contactor (inverse-time delayed/temperature-dependent protection)	Signal "tripped"	Overload warning	Overload warning								
	3RB2985-2AA1	Analog signal	Disconnection of the contactor (inverse-time delayed/temperature-dependent protection + ground fault)	Signal "tripped"	Overload warning	Overload warning								
	3RB2985-2AB1	Analog signal	Disconnection of the contactor (inverse-time delayed/temperature-dependent protection)	Signal "tripped"	Disconnection of the contactor (ground fault)	Signal "ground-fault tripping"								

## SIRIUS 3RB2 Electronic Overload Relays

3RB22, 3RB23 up to 630 A for High-Feature applications

## 3RB22 and 3RB23 electronic overload relays (evaluation modules) for full motor protection, stand-alone installation, CLASS 5, 10, 20 and 30 (adjustable)

Туре	3RB2283-4A.1, 3RB2383-4A.1
Features and technical specifications	
Overload protection, phase failure protection and unbalance protection	✓
Supplied from an external voltage	24 240 V AC/DC
Auxiliary contacts	2 NO + 2 NC
Electrical remote RESET integrated	✓
Four LEDs for operating and status displays	✓
TEST function and self-monitoring	✓
Internal ground-fault detection	(with function expansion module)
Screw or spring-type terminals for auxiliary, control and sensor circuits	✓
Input for PTC sensor circuit	✓
Analog output	(with function expansion module)

✓ Available

 $\begin{array}{ll} PU \text{ (UNIT, SET, M)} &= 1 \\ PS^* &= 1 \text{ unit} \\ PG &= 41G \end{array}$ 





3RB2283-4AA1, 3RB2383-4AA1

3RB2283-4AC1, 3RB2383-4AC1

Size contactor		Version	DT	Screw terminals	<b>+</b>	DT	Spring-type terminals	
				Article No.	Price per PU		Article No.	Price per PU
Evaluatio	n modules							
S00 S12		Monostable	<b>&gt;</b>	3RB2283-4AA1		▶	3RB2283-4AC1	
		Bistable	<b>&gt;</b>	3RB2383-4AA1		<b></b>	3RB2383-4AC1	

## Note:

Overview of overload relays – matching contactors, see page 7/93.

Current measuring modules and related connecting cables, see page 7/152, general accessories, see page 7/154 onwards.

## SIRIUS 3RB2 Electronic Overload Relays

## 3RB22, 3RB23 up to 630 A for High-Feature applications

## Function expansion modules for 3RB22 and 3RB23 overload relays (evaluation modules)

	Size contactor	Version	For overload relays	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
Sizes S00 to S12									
		For plugging into evaluation module (1 unit)							
(TIE	S00 S12	Analog Basic 1 modules <sup>1)</sup> Analog output DC 4 20 mA, with overload warning	3RB22, 3RB23	•	3RB2985-2AA0		1	1 unit	41F
3RB2985-21		Analog Basic 1 GF modules <sup>1)2)</sup> Analog output DC 4 20 mA, with internal ground-fault detection and overload warning	3RB22, 3RB23	•	3RB2985-2AA1		1	1 unit	41F
		Analog Basic 2 GF modules <sup>1)2)</sup> Analog output DC 4 20 mA, with internal ground-fault detection and overload ground-fault signaling	3RB22, 3RB23	•	3RB2985-2AB1		1	1 unit	41F
		Basic 1 GF modules <sup>2)</sup> with internal ground-fault detection and overload warning	3RB22, 3RB23	<b>&gt;</b>	3RB2985-2CA1		1	1 unit	41F
		Basic 2 GF modules <sup>2)</sup> with internal ground-fault detection and ground-fault signaling	3RB22, 3RB23	<b>&gt;</b>	3RB2985-2CB1		1	1 unit	41F


### Note:

Analog input modules, e.g. SM 331, must be configured for 4-wire measuring transducers. In this case the analog input module must not supply current to the analog output of the 3RB22/3RB23 relay.

- 1) The analog signal DC 4 mA up to 20 mA can be used for operating rotary coil instruments or for feeding into analog inputs of programmable logic controllers.
- 2) The following information on ground-fault protection refers to sinusoidal residual currents at 50/60 Hz:
  - With a motor current of between 0.3 and 2 times the current setting  $I_{\rm e}$ , the unit will trip at a ground-fault current equal to 30 % of the current setting.
  - With a motor current of between 2 and 8 times the current setting  $I_{\rm e}$  the unit will trip at a ground-fault current equal to 15 % of the current setting.
- The response delay amounts to between 0.5 s and 1 s.

3RB24 for IO-Link, up to 630 A for High-Feature applications

## Overview



- 1 Plug-in point for operator panel: enables connection of the 3RA6935-0A operator panel.
- Motor current and trip class setting: Setting the device to the motor current and to the required trip class dependent on the start-up conditions is easy with the two rotary switches.
- 3 Connecting terminals (removable terminal block): The generously sized terminals permit connection of two conductors with different cross-sections for the auxiliary, control and sensor circuits. Connection is possible with screw connection and alternatively with spring-type connection.
- (4) Test/RESET button: Enables testing of all important device components and functions, plus resetting of the device after a trip when manual RESET is selected.
- (5) Selector switch for manual/automatic RESET: With this switch you can choose between manual and automatic RESET.
- 6 Red LED "OVERLOAD": A continuous red light signals an active overload trip; a flickering led light signals an imminent trip (overload warning).
- (7) Red LED "THERMISTOR": A continuous red light signals an active thermistor trip.
- Red LED "GND FAULT": A continuous red light signals an active ground-fault trip.
- Green LED "DEVICE/IO-Link: A continuous green light signals that the device is working correctly, a green flickering light signals the communication through IO-Link.

#### SIRIUS 3RB24 evaluation module

The modular 3RB24 electronic overload relay, which is powered via IO-Link (with monostable auxiliary contacts) up to 630 A (up to 820 A possible with a series transformer) have been designed for inverse-time delayed protection of loads with normal and heavy starting ("Function", see Manual "SIRIUS 3RB24 Electronic Overload Relay for IO-Link", http://support.automation.siemens.com/WW/view/en/46165627) against excessive temperature rises due to overload, phase unbalance or phase failure. It comprises an evaluation unit, a current measuring module and a connecting cable.

The evaluation module 3RB24 also offers an engine starter function: The contactors, which are connected via the auxiliary contacts, can also be actuated for operation via IO-Link. In this way, direct, reversing and wye-delta starters up to 630 A (or 830 A) can be connected to the controller wirelessly via the IO-Link controller.

An overload, phase unbalance or phase failure result in an increase of the motor current beyond the set rated motor current.

This current rise is detected by means of the current measuring module (see page 7/152) and electronically evaluated by the evaluation module which is connected to it. The evaluation electronics sends a signal to the auxiliary contacts. The auxiliary contacts then switch off the load by means of a contactor.

The break time depends on the ratio between the tripping current and current setting  $I_{\rm e}$  and is stored in the form of a long-term stable tripping characteristic (see "Characteristic Curves", http://support.automation.siemens.com/WW/view/en/20357046/134300). The "tripped" status is signaled by means of a continuously

The "tripped" status is signaled by means of a continuously illuminated red "OVERLOAD" LED and also reported as a group fault via IO-Link.

The LED indicates imminent tripping of the relay due to overload, phase unbalance or phase failure by flickering when the limit current has been violated. This warning can also be reported to the higher-level PLC via IO-Link at the 3RB24 overload relay.

In addition to the described inverse-time delayed protection of loads against excessive temperature rises, the 3RB24 electronic overload relays also allow direct temperature monitoring of the motor windings (full motor protection) by connection with broken-wire interlock of a PTC sensor circuit. With this temperature-dependent protection, the loads can be protected against overheating caused indirectly by reduced coolant flow, for example, which cannot be detected by means of the current alone. In the event of overheating, the devices switch off the contactor, and thus the load, by means of the auxiliary contacts. The "tripped" status is signaled by means of a continuously illuminated "THERMISTOR" LED and also reported as a group fault via IO-Link.

To protect the loads against incomplete ground faults due to damage to the insulation, humidity, condensed water, etc., the 3RB24 electronic overload relays offer the possibility of internal ground-fault detection (for details, see Manual "SIRIUS 3RB24 Solid-State Overload Relay for IO-Link", http://support.automation.siemens.com/WW/view/en/46165627, not possible in conjunction with contactor assemblies for wyedelta starting). In the event of a ground fault, the 3RB24 relays trip instantaneously.

The "tripped" status is signaled by means of a flashing red LED "Ground Fault" and reported at the overload relay 3RB24 as a group fault via IO-Link.

The reset after overload, phase unbalance, phase failure, thermistor or ground-fault tripping is performed manually by key on site, via IO-Link or by electrical remote RESET or automatically after the cooling time (motor model) or for thermistor protection after sufficient cooling. Power cuts in devices due to function monitors (broken wire or short-circuit on the thermistor) can only be reset on-site ("Function", see Manual "SIRIUS 3RB24 Solid-State Overload Relay for IO-Link", http://support.automation.siemens.com/WW/view/en/46165627).

In conjunction with a function expansion module, the motor current measured by the microprocessor can be output in the form of an analog signal DC 4 to 20 mA for operating rotary coil instruments or for feeding into analog inputs of programmable logic controllers.

The current values can be transmitted to the higher-level controller via IO-Link.

The 3RB24 electronic overload relay for IO-Link is suitable for operation with frequency converters. Please follow the instructions in the manual "SIRIUS 3RB24 Solid-State Overload Relay for IO-Link", see

http://support.automation.siemens.com/WW/view/en/46165627.

The devices are manufactured in accordance with environmental guidelines and contain environmentally friendly and reusable materials. They comply with all important worldwide standards and approvals.

## SIRIUS 3RB2 Electronic Overload Relays

## 3RB24 for IO-Link, up to 630 A for High-Feature applications

#### Use in hazardous areas

The 3RB24 electronic overload relays for IO-Link with the 3RB29 current measuring module are suitable for the overload protection of motors with the following types of protection:

- 🕟 II (2) G [Ex e] [Ex d] [Ex px]
- 🐼 II (2) D [Ex t] [Ex p]

EC type test certificate for Group II, Category (2) G/D exists. It has the number PTB 11 ATEX 3014.

#### Article No. scheme

Digit of the Article No.	1st - 3rd	4th	5th	6th	7th		8th	9th	10th	11th	
						-					
Electronic overload relays	3 R B										
SIRIUS 2nd generation		2									
Device series											
Size, rated operational current and power											
Version of the automatic RESET, electrical remote RESET											
Trip class (CLASS)											
Setting range of the overload release											
Connection methods											
Installation type	·										
Example	3 R B	2	4	8	3	-	4	Α	Α	1	

#### Note:


The Article No. scheme is presented here merely for information purposes and for better understanding of the logic behind the article numbers.

For your orders, please use the article numbers quoted in the catalog in the Selection and ordering data.

#### Benefits

The most important features and benefits of the 3RB24 electronic overload relays for IO-Link are listed in the overview table (see "General Data", page 7/87 onwards).

#### Advantages through energy efficiency



Overview of the energy management process

We offer you a unique portfolio for industrial energy management, using an energy management system that helps to optimally define your energy needs. We split up our industrial energy management into three phases – identify, evaluate, and realize – and we support you with the appropriate hardware and software solutions in every process phase.

The innovative products of the SIRIUS industrial controls portfolio can also make a substantial contribution to a plant's energy efficiency (see www.siemens.com/sirius/energysaving).

3RB24 electronic overload relays for IO-Link contribute to energy efficiency throughout the plant as follows:

- Transmission of current values
- Reduced inherent power loss
- Less heating of the control cabinet
- Smaller control cabinet air conditioners can be used

### Application

#### Industries

The 3RB24 electronic overload relays are suitable for customers from all industries who want to guarantee optimum inverse-time delayed and temperature-dependent protection of their electrical loads (e.g. motors) under normal and heavy starting conditions (CLASS 5 to 30), minimize project completion times, inventories and energy consumption, and optimize plant availability and maintenance management.

#### **Application**

The 3RB24 electronic overload relays have been designed for the protection of three-phase asynchronous and single-phase AC motors.

In addition to protection function, these devices can be used together with contactors as direct or reversing starters (star-delta (wye-delta) start also possible), which are controlled via IO-Link. This makes it possible to directly control drives via IO-Link from a higher-level controller or on site via the optional

hand-held device lamps and also, for example, to return current values directly via IO-Link.

If single-phase AC motors are to be protected by the 3RB24 electronic overload relays, the main current paths of the current measuring modules must be series-connected ("Circuit Diagrams", see Manual

"SIRIUS 3RB24 Solid-State Overload Relay for IO-Link", http://support.automation.siemens.com/WW/view/en/46165627).

## Ambient conditions

The devices are insensitive to external influences such as shocks, corrosive ambient conditions, ageing and temperature fluctuations.

For the temperature range from -25 C to +60  $^{\circ}$ C, the 3RB24 electronic overload relays compensate the temperature in accordance with IEC 60947-4-1.

Configuration notes for use of the devices below -25  $^{\circ}\text{C}$  or above +60  $^{\circ}\text{C}$  on request.

3RB24 for IO-Link, up to 630 A for High-Feature applications

## Technical specifications

The following technical information is intended to provide an initial overview of the various types of device and functions.

### Detailed information, see

- Manual "SIRIUS 3RB24 Solid-State Overload Relay for IO-Link",
  - http://support.automation.siemens.com/WW/view/en/46165627
- or specific information on a particular article number via the product data sheet,

product data cricci,	
http://support.automation.siemens.com/WW/view/en/20357046/133200	

		Tittp://support.automation.siemens.com/vvvv/view/en/2000/1040/10020t
Type – Overload relay: evaluation modules	1	3RB2483-4A.1
Size contactor		S00 S10/S12
Dimensions of evaluation modules (W x H x D)	<u>↓</u> mm	45 x 111 x 95
(WX11XB)	`	
General data		
Trips in the event of		Overload, phase failure and phase unbalance (> 40 % according to NEMA), + ground fault (connectable and disconnectable) and activation of the thermistor motor protection (with closed PTC sensor circuit)
Trip class acc. to IEC 60947-4-1	CLASS	5, 10, 20 and 30 adjustable
Phase failure sensitivity		Yes
Overload warning		Yes, from 1.125 x $I_{\rm e}$ for symmetrical loads and from 0.85 x $I_{\rm e}$ for unsymmetrical loads
Reset and recovery		
Reset options after tripping		Manual and automatic RESET, electrical remote RESET or through IO-Link
Recovery time     For sustametic RESET.	min	for tripping due to evergurrent; 2 (stored normanistly)
- For automatic RESET	min.	<ul> <li>for tripping due to overcurrent: 3 (stored permanently)</li> <li>for tripping by thermistor: time until the motor temperature has fallen 5 K</li> </ul>
		below the response temperature
- For manual RESET	min.	<ul> <li>for tripping due to a ground fault: no automatic RESET</li> <li>for tripping due to overcurrent: 3 (stored permanently)</li> </ul>
. o. mandariteder		- for tripping by thermistor: time until the motor temperature has fallen 5 K
		below the response temperature - for tripping due to a ground fault: Immediately
- For remote RESET	min.	- for tripping due to a ground latar. Infinediately - for tripping due to overcurrent: 3 (stored permanently)
		- for tripping by thermistor: time until the motor temperature has fallen 5 K
		below the response temperature - for tripping due to a ground fault: Immediately
Features		for imposing due to a ground radii. Intimediately
Display of operating state on device		Yes, with 4 LEDs: - Green "DEVICE/IO-Link" LED - Red LED "Ground Fault"
		- Red LED "Thermistor" - Red "Overload" LED
TEST function		Yes, test of LEDs, electronics, auxiliary contacts and wiring of control circuit by pressing the button TEST/RESET / self-monitoring
RESET button		Yes, with the TEST/RESET button
STOP button		No
Protection and operation of explosion-proof motors		
EC type test certificate number according to		PTB 11 ATEX 3014
directive 94/9/EC (ATEX)		(x)   (2) G [Ex e] [Ex d] [Ex px] (x)   (2) G [Ex t] [Ex p],
		see
Ambient temperatures		http://support.automation.siemens.com/WW/view/en/60524083
Storage/transport	°C	-40 +80
Operation	°C	-25 +60
Temperature compensation	°C	+60
Permissible rated current	O	
- Temperature inside control cabinet 60 °C	%	100
- Temperature inside control cabinet 70 °C	%	On request
Degree of protection acc. to IEC 60529		IP20: Current measuring modules in sizes S6 and S10/S12 with busbar connection conjunction with the cover
Touch protection acc. to IEC 61140		Finger-safe: Current measuring modules in sizes S6 and S10/S12 with busbar connection in conjunction with the cover
Shock resistance with sine acc. to IEC 60068-2-27	g/ms	15/11

## SIRIUS 3RB2 Electronic Overload Relays

## 3RB24 for IO-Link, up to 630 A for High-Feature applications

Type – Overload relay: evaluation modules		3RB2483-4A.1
Size contactor	₫	S00 S10/S12
Dimensions of evaluation modules (W x H x D)	<sub>≠</sub> mm	45 x 111 x 95
General data (continued)		
Electromagnetic compatibility (EMC) – Interference immu	nity	
Conductor-related interference	-	
- Burst acc. to IEC 61000-4-4 (corresponds to degree of severity 3)	kV	2 (power ports), 1 (signal ports)
<ul> <li>Surge acc. to IEC 61000-4-5 (corresponds to degree of severity 3)</li> </ul>	kV	2 (line to earth), 1 (line to line)
Electrostatic discharge according to IEC 61000-4-2 (corresponds to degree of severity 3)	kV	8 (air discharge), 6 (contact discharge)
Field-related interference according to IEC 61000-4-3 (corresponds to degree of severity 3)	V/m	10
Electromagnetic compatibility (EMC) – emitted interference	e	Degree of severity A according to EN 55011 (CISPR 11) and EN 55022 (CISPR 22)
Resistance to extreme climates – air humidity	%	100
Dimensions		"Dimensional drawings", see  • Manual "SIRIUS 3RB24 Solid-State Overload Relay for IO-Link", http://support.automation.siemens.com/WW/view/en/46165627  • Product data sheet, http://support.automation.siemens.com/WW/view/en/20357046/133200
Installation altitude above sea level	m	Up to 2 000
Mounting position		Any
Type of mounting		
Evaluation modules		Stand-alone installation
Current measuring module	Size	S00 to S3: Stand-alone installation, S6 and S10/S12: stand-alone installation or mounting onto contactors

## 3RB24 for IO-Link, up to 630 A for High-Feature applications

Type – Overload relay: evaluation modules		3RB2483-4A.1
Size contactor		S00 S10/S12
Auxiliary circuit		
Number of auxiliary switches		1 CO contact, 1 NO contact connected in series internally
Auxiliary contacts – assignment		1 CO contact for selecting the contactor (for reversing starter function), actuated by the control system
		<ul> <li>1 NO contact for normal switching duty, actuated by the control system (opens automatically when tripping occurs)</li> </ul>
Rated insulation voltage $U_i$ (pollution degree 3)	V	300
Rated impulse withstand voltage $U_{\rm imp}$	kV	4
Auxiliary contacts – contact rating		
• NC contact with alternating current AC-14/AC-15, rated operational current $I_{\rm e}$ at $U_{\rm e}$	•	
- 24 V - 120 V	A A	6 6
- 125 V	Α	6
- 250 V	А	3
<ul> <li>NO contact with alternating current AC-14/AC-15, rated operational current I<sub>e</sub> at U<sub>e</sub></li> <li>24 V</li> </ul>	А	6
- 24 V - 120 V	Ä	6
- 125 V	A	6
250 V     NC contact, NO contact with direct current DC-13,	А	3
rated operational current $I_{ m e}$ at $U_{ m e}$ - 24 V	Α	2
- 60 V	Α	0.55
- 110 V - 125 V	A A	0.3 0.3
- 250 V	A	0.2
$ullet$ Conventional thermal current $I_{th}$	Α	5
Contact reliability		Yes
(suitability for PLC control; 17 V, 5 mA)		
Short-circuit protection		
<ul> <li>With fuse, operational class gG</li> </ul>	Α	6
With miniature circuit breaker, C characteristic	А	1.6
Protective separation between auxiliary current paths acc. to IEC 60947-1	V	300
CSA, UL, UR rated data		
Auxiliary circuit – switching capacity		B300, R300
Conductor cross-sections of the auxiliary circuit		
Connection type		Screw terminals
Terminal screw		M3, Pozidriv size 2
Operating devices	mm	3.0 x 0.5
Prescribed tightening torque	Nm	0.8 1.2
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected		
Solid or stranded	mm <sup>2</sup>	$1 \times (0.5 \dots 4)^{1)}, 2 \times (0.5 \dots 2.5)^{1)}$
Finely stranded without end sleeve	mm <sup>2</sup>	
<ul> <li>Finely stranded with end sleeve (DIN 46228-1)</li> </ul>	mm <sup>2</sup>	$1 \times (0.5 \dots 2.5)^{1)}, 2 \times (0.5 \dots 1.5)^{1)}$
AWG cables, solid or stranded	AWG	2 × (20 14)
Connection type		Spring-type terminals
Operating devices	mm	3.0 x 0.5
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected		
Solid or stranded	mm <sup>2</sup>	2 × (0.25 1.5)
Finely stranded without end sleeve	mm <sup>2</sup>	-
<ul> <li>Finely stranded with end sleeve (DIN 46228-1)</li> </ul>	$mm^2$	2 × (0.25 1.5)
<ul> <li>AWG cables, solid or stranded</li> </ul>	AWG	2 × (24 16)
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected  • Solid or stranded  • Finely stranded without end sleeve  • Finely stranded with end sleeve (DIN 46228-1)	mm² mm² mm²	2 × (0.25 1.5) - 2 × (0.25 1.5)

<sup>1)</sup> If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.

## SIRIUS 3RB2 Electronic Overload Relays

## 3RB24 for IO-Link, up to 630 A for High-Feature applications

Type - Overload relay: evaluation modules		3RB2483-4A.1
Size contactor		S00 S10/S12
Control circuit		
Rated insulation voltage $U_{\rm i}$ (pollution degree 3)	V	300
Rated impulse withstand voltage U <sub>imp</sub>	kV	4
Rated control supply voltage $U_s^{(1)}$		
• DC	V	24 through IO-Link
Operating range		
• DC		$0.85 \times U_{\text{s min}} \leq U_{\text{s}} \leq 1.1 \times U_{\text{s max}}$
Rated power		
• DC	W	0.5
Mains buffering time	ms	200
Sensor circuit		
Thermistor motor protection (PTC thermistor sensor)		
Summation cold resistance	$k\Omega$	≤ 1.5
Response value	$k\Omega$	3.4 3.8
Return value	$k\Omega$	1.5 1.65
Ground-fault detection		The information refers to sinusoidal residual currents at 50/60 Hz.
• Tripping value $I_{\Delta}$		> 0.2 × I
- For $0.3 \times I_{\rm e}$ < $I_{\rm motor}$ < $2.0 \times I_{\rm e}$ - For $2.0 \times I_{\rm e}$ < $I_{\rm motor}$ < $8.0 \times I_{\rm e}$		$> 0.3 \times I_{\rm e}$ $> 0.15 \times I_{\rm motor}$
Response time t <sub>trin</sub>	ms	500 1 000
Analog output <sup>1)</sup>		
Rated values		
Output signal	mA	4 20
Measuring range		0 1.25 $\times$ $I_{\rm e}$ 4 mA corresponds to 0 $\times$ $I_{\rm e}$ 16.8 mA corresponds to 1.0 $\times$ $I_{\rm e}$ 20 mA corresponds to 1.25 $\times$ $I_{\rm e}$
• Load, max.	Ω	100
Conductor cross-sections for the control and sensor circuit as well as the analog output		
Connection type		Screw terminals
Terminal screw		M3, Pozidriv size 2
Operating devices	mm	3.0 x 0.5
Prescribed tightening torque	Nm	0.8 1.2
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected		
• Solid	$\text{mm}^2$	$1 \times (0.5 \dots 4)^{2}$ , $2 \times (0.5 \dots 2.5)^{2}$
Finely stranded without end sleeve	$\text{mm}^2$	
• Finely stranded with end sleeve (DIN 46228-1)	$\text{mm}^2$	$1 \times (0.5 \dots 2.5)^{2)}, 2 \times (0.5 \dots 1.5)^{2)}$
• Stranded	$\rm mm^2$	
AWG cables, solid or stranded	AWG	2 × (20 14)
Connection type		Spring-type terminals
Operating devices	mm	3.0 x 0.5
Conductor cross-sections (min./max.), 1 or 2 conductors can be connected		
• Solid	mm <sup>2</sup>	2 × (0.25 1.5)
Finely stranded without end sleeve	mm <sup>2</sup>	
• Finely stranded with end sleeve (DIN 46228-1)	mm <sup>2</sup>	2 × (0.25 1.5)
• Stranded	mm <sup>2</sup>	2 × (0.25 1.5)
AWG cables, solid or stranded	AWG	2 × (24 16)
		-··(-·····)

<sup>1)</sup> Analog input modules, e.g. SM 331, must be configured for 4-wire measuring transducers. The analog input module may not supply current to the analog output of the 3RB24 overload relay.

<sup>2)</sup> If two different conductor cross-sections are connected to one clamping point, both cross-sections must be in the range specified.

3RB24 for IO-Link, up to 630 A for High-Feature applications

## Selection and ordering data

3RB24 electronic overload relays (evaluation modules) for full motor protection, stand-alone installation, CLASS 5, 10, 20 and 30 (adjustable)

Туре	3RB2483-4A.1
Features and technical specifications	
Overload protection, phase failure protection and unbalance protection	✓
Supplied from an external voltage	✓ 24 V DC through IO-Link
Direct-on-line or reversing starters (wye-delta starting also possible) controllable through IO-Link	✓
Auxiliary contacts	1 CO and 1 NO in series
Manual and automatic RESET	✓
Remote RESET	√   (electrically or via IO-Link)
Four LEDs for operating and status displays	✓
TEST function and self-monitoring	✓
Internal ground-fault detection	✓
Screw or spring-type terminals for auxiliary, control and sensor circuits	✓
Input for PTC sensor circuit	✓
Analog output	✓
IO-Link-specific functions	
Connection of direct-on-line, reversing and star-delta starters to the controller via IO-Link	✓
On-site controlling of the starter using the hand-held device	✓
<ul> <li>Accessing process data (e.g. current values in all three phases) via IO-Link</li> </ul>	✓
<ul> <li>Accessing parameterization and diagnostics data (e.g. tripped signals) via IO-Link</li> </ul>	✓

✓ Available

 $\begin{array}{ll} PU \text{ (UNIT, SET, M)} &= 1 \\ PS^* &= 1 \text{ unit} \\ PG &= 41G \end{array}$ 





3RB2483-4AA1

3RB2483-4AC1

Size contactor	Version	DT	Screw terminals	<b>+</b>	DT	Spring-type terminals	$\stackrel{\infty}{\square}$
			Article No. Pr	rice PU		Article No.	Price per PU
Evaluation modules							
S00 S12	Monostable	<b>&gt;</b>	3RB2483-4AA1		Α	3RB2483-4AC1	

## Notes:

- Overview of overload relays matching contactors, see page 7/93.
- Analog input modules, e.g. SM 331, must be configured for 4-wire measuring transducers. The analog input module may not supply current to the analog output of the 3RB24 relay.

Current measuring modules and related connecting cables, see page 7/152 onwards, "Accessories", see page 7/153 onwards.

## SIRIUS 3RB2 Electronic Overload Relays

Current measuring modules for 3RB22, 3RB23, 3RB24

### Overview



SIRIUS 3RB2906 current measuring module

The current measuring modules are designed as system components for connecting to evaluation units 3RB22 to 3RB24. Using these evaluation units the motor current is measured and the measured value sent to the evaluation unit for evaluation.

The current measuring modules in sizes up to S3 are equipped with straight-through transformers and can be snap-fitted under the evaluation units. The larger evaluation units are installed directly on the contactor or as stand-alone units.

## Technical specifications

The following technical information is intended to provide an initial overview of the various types of device and functions.

Detailed information, see Reference Manual "Protection Equipment - Overload Relays 3RU1, 3RB2", http://support.automation.siemens.com/WW/view/en/35681297

Type – Overload relays: Current measuring modules			3RB2906		3RB2956	3RB2966		
Size contactor			S00/S0	S2/S3	S6	S10/S12		
Dimensions of current measuring modules (W x H x D)	W	mm		- ,	120 x 119 x 145	145 x 147 x 148		
Main circuit								
Rated insulation voltage <i>U</i> <sub>i</sub> (pollution degree 3)		V	1 000					
Rated impulse withstand voltage U <sub>imp</sub>		kV	6		8			
Rated operational voltage U <sub>e</sub>		V	1 000					
Type of current								
Direct current			No					
Alternating current			Yes, 50/60 Hz	z ± 5 %				
Current setting		А	0.3 3; 2.4 25	10 100	20 200	63 630		
Power loss per unit (max.)		W	0.5					
Short-circuit protection								
With fuse without contactor			See "Selectio	n and orderin	g data" on page 7/152			
With fuse and contactor			See configura	ation manuals	3			
			<ul> <li>"Configuring SIRIUS Innovations – Selection Data for Fuseless and Fused Load Feeders", http://support.automation.siemens.com/WW/view/en/50250039</li> </ul>					
			<ul> <li>"SIRIUS Configuration – Selection Data for Fuseless Load Feeders", http://support.automation.siemens.com/WW/view/en/68115041</li> </ul>					
Protective separation between main and auxiliary curre acc. to IEC 60947-1 (pollution degree 2)	ent paths							
For systems with grounded neutral point		V	690					
For systems with ungrounded neutral point		V	600					

## Current measuring modules for 3RB22, 3RB23, 3RB24

Type – Overload relays:		3RB2906		3RB2956	3RB2966
Current measuring modules		000/00	00/00	00	040/040
Size contactor  Dimensions of current measuring modules	mm	S00/S0	S2/S3	S6 120 x 119 x 145	S10/S12 145 x 147 x 148
(W x H x D)	W N	40 X 04 X 40	00 X 04 X 7 Z	120 X 110 X 140	140 X 147 X 140
Conductor cross-sections of main circuit					
Connection type		Screw	terminals wi	th box terminal	
Terminal screw	mm			4 mm Allen screw	5 mm Allen screw
Operating devices	mm			4 mm Allen screw	5 mm Allen screw
Prescribed tightening torque	Nm			10 12	20 22
Conductor cross-sections (min./max.), 1 or 2 conductor					
Solid or stranded	mm <sup>2</sup>	-		With 3RT1955-4G box terminal: 2 × (max. 70), 1 × (16 70) With 3RT1956-4G box terminal:	2 × (70 240), Rear clamping point only: 1 × (95 300) Rear clamping point only:
				2 × (max. 120), 1 × (16 120)	1 × (120 240)
Finely stranded without end sleeve	mm <sup>2</sup>			With 3RT1955-4G box terminal: 2 × (1 × max. 50, 1 × max. 70), 1 × (10 70)	2 × (50 185), Rear clamping point only: 1 × (70 240)
				With 3RT1956-4G box terminal: 2 × (1 × max. 95, 1 × max. 120), 1 × (10 120)	Rear clamping point only: 1 × (120 185)
• Finely stranded with end sleeve (DIN 46228-1)	mm <sup>2</sup>			With 3RT1955-4G box terminal: 2 × (1 × max. 50, 1 × max. 70), 1 × (10 70)	2 × (50 185), Rear clamping point only: 1 × (70 240)
				With 3RT1956-4G box terminal: 2 × (1 × max. 95, 1 × max. 120), 1 × (10 120)	Rear clamping point only: 1 × (120 185)
AWG cables	AWG			With 3RT1955-4G box terminal: 2 × (max. 1/0), 1 × (6 2/0)	2 × (2/0 500 kcmil), rear clamping point only: 1 × (3/0 600 kcmil)
				With 3RT1956-4G box terminal: 2 × (max. 3/0), 1 × (6 250 kcmil)	Rear clamping point only: 1 × (250 kcmil 500 kcmil)
Ribbon cables (Number x Width x Thickness)	mm			With 3RT1955-4G box terminal: $2 \times (6 \times 15.5 \times 0.8)$ , $1 \times (3 \times 9 \times 0.8 \dots 6 \times 15.5 \times 0.8)$	$2 \times (20 \times 24 \times 0.5),$ $1 \times (6 \times 9 \times 0.8$ $20 \times 24 \times 0.5)$
				With 3RT1956-4G box terminal: $2 \times (10 \times 15.5 \times 0.8)$ , $1 \times (3 \times 9 \times 0.8 \dots 10 \times 15.5 \times 0.8)$	
Connection type		oo Busba	ar connection	,	
Terminal screw				M8 × 25	M10 x 30
Prescribed tightening torque	Nm			10 14	14 24
Conductor cross-sections (min./max.), 1 or 2 conductor					
Solid with cable lug	mm <sup>2</sup>			16 95 <sup>1)</sup>	50 240 <sup>2)</sup>
Stranded with cable lug	mm <sup>2</sup>			25 120 <sup>1)</sup>	70 240 <sup>2)</sup>
AWG cables, solid or stranded, with cable lug	AWG			4 250 kcmil	2/0 500 kcmil
With connecting bars (max. width)  Connection type	mm	Ctus!	ht through to	17	25
Connection type		Straig	ht-through tra	anstormers	
Diameter of opening	mm	7.5	14	25	

When connecting cable lugs according to DIN 46235 with conductor cross-sections of 95 mm<sup>2</sup> and more, the 3RT1956-4EA1 terminal cover must be used to ensure phase clearance.

When connecting cable lugs according to DIN 46234 with conductor cross-sections of 240 mm<sup>2</sup> and more as well as to DIN 46235 with conductor cross-sections of 185 mm<sup>2</sup> and more, the 3RT1956-4EA1 terminal cover must be used to ensure the phase clearance.

## SIRIUS 3RB2 Electronic Overload Relays

## Current measuring modules for 3RB22, 3RB23, 3RB24

## Selection and ordering data

## Current measuring modules (essential accessory)







3RB2906-2JG1



3RB2956-2TG2



3RB2966-2WH2

Size contactor	Current setting value of the inverse-time delayed overload release	Short-circuit protection with fuse, type of coordination "2", operational class gG <sup>1)</sup>	For overload relays	DT	Article No. Pric		PS*	PG
	Α	A						
Sizes S00/S0								
Devices with straight- for stand-alone install		,						
S00/S0	0.3 3	20	3RB22 to	<b>&gt;</b>	3RB2906-2BG1	1	1 unit	41G
	2.4 25	63	3RB24	<b>&gt;</b>	3RB2906-2DG1	1	1 unit	41G
Sizes S2/S3								
Devices with straight- for stand-alone installa		,						
S2/S3	10 100	315	3RB22 to 3RB24	•	3RB2906-2JG1	1	1 unit	41G
Size S6								
Devices with busbar c for mounting onto con		one installation						
S6	20 200	315	3RB22 to 3RB24	•	3RB2956-2TH2	1	1 unit	41G
Devices with straight- for mounting onto con								
For mounting onto S6 contactors with box terminals	20 200	315	3RB22 to 3RB24	•	3RB2956-2TG2	1	1 unit	41G
Sizes S10/S12 <sup>2)</sup>								
Devices with busbar c		ana installation						
for mounting onto con \$10/\$12 and size 14	63 630	800	3RB22 to	•	3RB2966-2WH2	1	1 unit	41G
(3TF68/3TF69) <sup>2)</sup>	00 000	000	3RB24		SUDTAGO-SANUT	'	i uiill	410

#### Note:

The connecting cable between the current measuring module and the evaluation module is not included in the scope of supply; please order separately (see "Accessories").

- 1) Maximum protection by fuse only for overload relay, type of coordination "2". For fuse values in connection with contactors, see Configuration Manuals
  - "Configuring SIRIUS Innovations Selection Data for Fuseless and Fused Load Feeders", http://support.automation.siemens.com/WW/view/en/39714188
  - "SIRIUS Configuration Selection Data for Fuseless Load Feeders", http://support.automation.siemens.com/WW/view/en/40625241.

### Accessories

	Size contactor	Version	For overload relays	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
Connecting cab	les (necess	sary accessories)							
		For connection between evaluation module and current measuring module							
	S00 S3	Length 0.1 m     (only for mounting of the evaluation module directly onto the current measuring module)	3RB24, 3RB29	•	3RB2987-2B		1	1 unit	41F
3RB2987-2.	S00 S12	• Length 0.5 m	3RB24, 3RB29	<b>&gt;</b>	3RB2987-2D		1	1 unit	41F

Additional general accessories, see page 7/154.

<sup>&</sup>lt;sup>2)</sup> For 3TF68/3TF69 contactors, direct mounting is not possible.

Accessories for 3RB22, 3RB23, 3RB24

## Overview

### Overload relays for High-Feature applications

The following optional accessories are available for the 3RB22 to 3RB24 electronic overload relays:

- Operator panel for the evaluation modules 3RB24
- Manuals, see "More information"
- Sealable cover for the evaluation modules 3RB22 to 3RB24
- Terminal covers for the 3RB29 current measuring modules size S6 and S10/S12
- Box terminal blocks for the 3RB29 current measuring modules size S6 and S10/S12
- Push-in lugs for screw fixing for 3RB22 to 3RB24 evaluation modules and 3RB2906 current measuring modules

### Selection and ordering data

## Accessories for 3RB24 overload relays

	Version	For overload relays	DT	Article No. Price per PU		PS*	PG
Operator panels for e	valuation modules						
3RA6935-0A	Operator panels (set) One set comprises: • 1 x operator panel • 1 x 3RA6936-0A enabling module • 1 x 3RA6936-0B interface cover • 1 x fixing terminal Note: The connecting cable between the evaluation module and the operator panel is not included in the scope of supply; please order separately.	3RB24	A	3RA6935-0A	1	1 unit	42F
	Connecting cable Length 2.5 m (round), for connecting the evaluation module to the operator panel	3RB24	<b>&gt;</b>	3UF7933-0BA00-0	1	1 unit	42J
	Enabling modules (replacement)	3RB24	Α	3RA6936-0A	1	1 unit	42F
	Interface covers	3RB24	Α	3RA6936-0B	1	5 units	42F

Additional general accessories, see next page.

## More information

## Manuals

- System Manual "SIRIUS Innovations System Overview" http://support.automation.siemens.com/WW/view/en/60311318
- Manual "SIRIUS 3RB24 Solid-State Overload Relay for IO-Link" http://support.automation.siemens.com/WW/view/en/46165627

## SIRIUS 3RB2 Electronic Overload Relays

## Accessories for 3RB22, 3RB23, 3RB24

General	accesso	ories

ries									
Version		Size	For overload relays	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
for evaluation mo	dules								
			3RB22 to 3RB24	<b>&gt;</b>	3RB2984-2		1	10 units	41F
for current measu	ırina modules								
		nnections							
• Length 100 mm	J	S6	3RB2956	<b>&gt;</b>	3RT1956-4EA1		1	1 unit	41B
• Length 120 mm		S10/S12	3RB2966	<b>&gt;</b>	3RT1966-4EA1		1	1 unit	41B
Covers for box ter	minals								
<ul> <li>Length 25 mm</li> </ul>		S6	3RB2956	<b>&gt;</b>	3RT1956-4EA2		1	1 unit	41B
Length 30 mm		S10/S12	3RB2966	<b>&gt;</b>	3RT1966-4EA2		1	1 unit	41B
		S6	3RB2956	<b>&gt;</b>	3RT1956-4EA3		1	1 unit	41B
		S10/S12	3RB2966	<b></b>	3RT1966-4EA3		1	1 unit	41B
cks for current me	pasuring module	26							
		<i>-</i> 5							
	on cables	S6 <sup>1)</sup>	3RR2956		3RT1955-4G		1	1 unit	41B
									41B
				<b>•</b>	3RT1966-4G		1		41B
	cations for conducto			ence					
Manual "Protection I	Equipment – 3RU1, 3	3RB2 Overl	oad Relays",						
				D	2DD4002			10 unito	41H
modules	e evaluation		3RB24	Б	3KP1903		'	TO UTILIS	4111
For screw fixing the current measuring modules (2 units per module)		S00 S3	3RB2906	A	3RB1900-0B		100	10 units	41F
oply for 3RT1054-1 co	ontactors (55 kW).								
Version	Size	Color	For overload relays	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
g spring-type tern	ninals								
					Spring-type	<u></u>			
Screwdrivers For all SIRIUS devices with spring-type terminals	Length approx. 200 mm, 3.0 mm x 0.5 mm	Titanium gray/ black, partially insulated	Main and auxiliary circuit connection: 3RB2	Α	3RA2908-1A		1	1 unit	41B
Unit labeling plates <sup>1)</sup>	20 mm x 7 mm	Pastel turquoise	3RB2	D	3RT1900-1SB20		100	340 units	41B
	20 mm x 7 mm	- Titanium	3RB2	D	3RT2900-1SB20		100	340 units	41B
		gray							
	for evaluation mo For covering the se  Covers for cable is Length 100 mm Length 120 mm Covers for box ter Length 25 mm Length 30 mm Covers for screw to contactor and over without box termina (1 unit required per contactor and over without box termina (1 unit required per contactor and over without box termina (1 unit required per contactor and over without box termina (1 unit required per contactor and over without box termina for round and ribb. Up to 70 mm² Up to 120 mm² Up to 120 mm² Up to 240 mm² For technical specific Manual "Protection Inttp://support.autor evaluation module For screw fixing the measuring modules  For screw fixing the measuring modules  For screw fixing the measuring modules  Version  Screwdrivers For all SIRIUS devices with spring-type terminals  Unit labeling plates¹)	For covering the setting knobs  For covering the setting knobs  For covering the setting knobs  Covers for cable lugs and busbar co  Length 100 mm  Length 120 mm  Covers for box terminals  Length 25 mm  Length 30 mm  Covers for screw terminals between contactor and overload relay, without box terminals  To trequired per combination)  Covers for current measuring module  For round and ribbon cables  Up to 70 mm²  Up to 120 mm²  Up to 240 mm²  For technical specifications for conductor Manual "Protection Equipment — 3RU1, whitp://support.automation.siemens.comevaluation modules and current in For screw fixing the evaluation modules  For screw fixing the current measuring modules  (2 units per module)  Screwdrivers  For all SIRIUS  devices with spring-type terminals  Unit labeling 100 mm x 7 mm years with a contractor of the product of t	For evaluation modules  For covering the setting knobs  For covering the setting knobs  Covers for cable lugs and busbar connections  • Length 100 mm	For covering the setting knobs  For covers for cable lugs and busbar connections  Length 100 mm  So 3RB2956  Length 120 mm  So 3RB2956  Covers for box terminals  Length 25 mm  Length 25 mm  Covers for screw terminals between contactor and overload relay, without box terminals (1 unit required per combination)  Coks for current measuring modules  For round and ribbon cables  Up to 70 mm²  Up to 70 mm²  So 3RB2956  So 3RB2956  So 3RB2956  Sol/S12  So 3RB2966  Sol/S12  So 3RB2956  Sol/S12  So 3RB2956  Sol/S12  So 3RB2956  Sol/S12  Sol/S12  Sol 3RB2956  Sol/S12  Sol 3RB2956  Sol 3RB2	for evaluation modules  For covering the setting knobs	Version	Version	Version	Version

<sup>1)</sup> PC labeling system for individual inscription of unit labeling plates available from:

murrplastik Systemtechnik GmbH (see Chapter 16, "Appendix" → "External Partners").

## Load Feeders and Motor Starters for Use in the Control Cabinet





	Price groups PG 12W, 14O, 230, 241, 250, 260, 41B, 41D, 41E, 41L, 42C, 42D, 42F, 471, 4N1, 5K1, 5K2, 5N2, 764, 815, 816
8/2	Introduction
	SIRIUS 3RA2 load feeders
8/5	General data
8/17	3RA21 direct-on-line starters For snapping onto standard mounting rails or for screw fixing
8/21	For 60 mm busbars 3RA22 reversing starters
8/25	For snapping onto standard mounting rails or for screw fixing
8/29	For 60 mm busbars
8/33	<u>Accessories</u>
8/41	3RV29 infeed system for
	load feeders
0/40	SIRIUS 3RA1 load feeders
8/42	General data 3RA11 direct-on-line starters
8/46	For snapping onto standard mounting
0/40	rails or for screw fixing  3RA12 reversing starters
8/47	For snapping onto standard mounting
3,	rails or for screw fixing
8/48	<u>Accessories</u>
	SIRIUS 3RA6 compact starters
8/51	General data
	3RA61, 3RA62 compact starters
8/60	3RA61 direct-on-line starters
8/61	3RA62 reversing starters
	3RA64, 3RA65 compact starters for IO-Link
8/62	3RA64 direct-on-line starters
8/63	3RA65 reversing starters
8/64	<u>Accessories</u>
8/70	Add-on modules for AS-Interface
8/72	Infeed systems for 3RA6
	SIRIUS 3RM1 motor starters
8/79	General data
8/85	3RM10 direct-on-line starters
8/86	3RM12 reversing starters
8/87	3RM11 Failsafe direct-on-line starters
8/88 8/89	3RM13 Failsafe reversing starters Accessories
-0/09	/10003301103

#### safety motor starters General data 8/101 Standard motor starters 8/102 Standard terminal modules 8/104 High-Feature motor starters **NEW** 8/106 High-Feature terminal modules 8/107 Power modules 8/108 Power module terminal module 8/109 ET 200S Failsafe motor starters 8/111 Failsafe terminal modules

Safety modules local and PROFIsafe

ET 200S motor starters and

8/128 ET 200S - interface modules 8/136 ET 200S - I/O modules 8/146 ET 200S - fail-safe I/O modules 8/150 ET 200S - IO-Link master modules

Safety modules local and

8/151 ET 200S software

PROFIsafe

Accessories

terminal modules

#### Notes:

8/94

8/121

8/123

The 3RA1 load feeders (sizes S00/S0 to S3) can be found

- in the Catalog Add-On IC 10 AO · 2014 at the Information and **Download Center**
- in the interactive catalog CA 01
- in the Industry Mall

Conversion tool, see

www.siemens.com/sirius/conversion-tool

Click on the Article No. in the catalog PDF to access it in the Industry Mall and get all related information.



Or directly in the Internet, e. g. www.siemens.com/ product?3RA1943-2C